

# 2005 CVO Electra Glide 2 - Owner's Manual

---

## Safety First

### Safe Operating Rules: Touring Models

---

Before operating your new motorcycle it is your responsibility to read and follow the operating and maintenance instructions in this manual, and follow these basic rules for your personal safety.

- Know and respect the rules of the road (see RULES OF THE ROAD section). Carefully read and observe the rules contained in the RIDING TIPS booklet accompanying this Owner's Manual. Read and familiarize yourself with the contents of the MOTORCYCLE HANDBOOK for your state.
- Before starting engine, check for proper operation of brake, clutch, shifter, throttle controls, correct fuel and oil supply.

#### **⚠ WARNING**

**Do not use aftermarket parts and custom made front forks which can adversely affect performance and handling. Removing or altering factory installed parts can adversely affect performance and could result in death or serious injury. (00001a)**

- Use only Harley-Davidson approved parts and accessories. Use of certain other manufacturer's performance parts will void your new motorcycle warranty. See your Harley-Davidson dealer for details.

#### **⚠ WARNING**

**Stop the engine when refueling or servicing the fuel system. Do not smoke or allow open flame or sparks near gasoline. Gasoline is extremely flammable and highly explosive, which could result in death or serious injury. (00002a)**

When refueling your motorcycle, the following rules should be observed.

- Refuel in a well ventilated area with the engine turned off.
- Remove fuel filler cap slowly.
- Do not smoke or allow open flames or sparks when refueling or servicing the fuel system.
- Always close the fuel supply valve when the engine is not running. This prevents flooding of the carburetor and the surrounding area with gasoline.
- Do not fill fuel tank above the bottom of the filler neck insert.
- Leave air space to allow for fuel expansion.

#### **⚠ WARNING**

**Do not store motorcycle with gasoline in tank within the home or garage where open flames, pilot lights, sparks or**

electric motors are present. Gasoline is extremely flammable and highly explosive, which could result in death or serious injury. (00003a)

**⚠WARNING**

Engine exhaust from this product contains chemicals known to the State of California to cause cancer and birth defects or other reproductive harm. (00004e)

**⚠WARNING**

Wheel weights on wheels without spokes contain lead and lead compounds, chemicals known to the State of California to cause cancer and birth defects or other reproductive harm. (00356b)

**⚠WARNING**

Do not run motorcycle in a closed garage or confined area. Inhaling motorcycle exhaust, which contains poisonous carbon monoxide gas, could result in death or serious injury. (00005a)

**⚠WARNING**

The jiffy stand locks when placed in the full forward (down) position with vehicle weight on it. If the jiffy stand is not in the full forward (down) position with vehicle weight on it, the vehicle can fall over which could result in death or serious injury. (00006a)

**⚠WARNING**

Be sure jiffy stand is fully retracted before riding. If jiffy stand is not fully retracted, it can contact the road surface causing a loss of vehicle control, which could result in death or serious injury. (00007a)

- A new motorcycle must be operated according to the special break-in procedure. See Break-in Riding Rules.
- Operate motorcycle only at moderate speed and out of traffic until you have become thoroughly familiar with its operation and handling characteristics under all conditions.

*NOTE:*

*We recommend that you obtain information and formal training in the correct motorcycle riding technique. The Motorcycle Safety Foundation® offers beginning and advanced rider safety courses. Call (949)727-3227 for information.*

## **⚠WARNING**

**Travel at speeds appropriate for road and conditions and never travel faster than posted speed limit. Excessive speed can cause loss of vehicle control, which could result in death or serious injury. (00008a)**

- Do not exceed the legal speed limit or drive too fast for existing conditions. Always reduce speed when poor driving conditions exist. High speed increases the influence of any other condition affecting stability and increases the possibility of loss of control.
- Pay strict attention to road surfaces and wind conditions. Any two wheeled vehicle may be subject to upsetting forces such as wind blasts from passing trucks, holes in the pavement, rough road surfaces, rider control error, etc. These forces may influence the handling characteristics of your motorcycle. If this happens, reduce speed and guide the motorcycle with a relaxed grip to a controlled condition. Do not brake abruptly or force the handlebar. This may aggravate an unstable condition.
- Keep cargo weight concentrated close to the motorcycle and as low as possible to minimize the change in the motorcycle's center of gravity. Distribute weight evenly on both sides of the vehicle and do not load bulky items too far behind the rider or add weight to the handlebars or front forks. Do not exceed maximum specified load in each saddlebag.

*NOTE:*

*New riders should gain experience under various conditions while driving at moderate speeds.*

- Operate your motorcycle defensively. Remember, a motorcycle does not afford the same protection as an automobile in an accident. One of the most common accident situations occurs when the driver of the other vehicle fails to see or recognize a motorcycle and turns left into the on-coming motorcyclist. Operate only with headlamp on.
- Wear an approved helmet, clothing, and foot gear suited for motorcycle riding. Bright or light colors are best for greater visibility in traffic, especially at night. Avoid loose, flowing garments and scarves.

## **⚠WARNING**

**Avoid contact with exhaust system and wear protective clothing that completely covers legs while riding. Exhaust pipes and mufflers get very hot when engine is running and remain too hot to touch, even after engine is turned off. Failure to wear protective clothing could result in burns or other serious injury. (00009a)**

- When carrying passengers, it is your responsibility to instruct them on proper riding procedures. (See Riding Tips for Motorcyclist included in your Harley-Davidson Owner's Kit.)
- Do not allow other individuals, under any circumstances, to operate your motorcycle unless you know they are experienced, licensed riders and are thoroughly familiar with the operation of your particular motorcycle.
- Protect your motorcycle against theft. After parking your motorcycle, lock the steering head and remove ignition key from switch. Set security alarm if present.
- Safe motorcycle operation requires alert mental judgment combined with a defensive driving attitude. Do not allow fatigue, alcohol or drugs to endanger your safety or that of others.
- Vehicles equipped with a sound system should have the volume adjusted to a nondistracting

level before operating vehicle.

- Maintain your motorcycle in proper operating condition in accordance with Regular Service Intervals: 2005 FLHTCSE2. Particularly important to motorcycle stability is proper tire inflation pressure, tread condition, and proper adjustment of wheel bearings and steering head bearings.

**⚠WARNING**

**Do not operate vehicle with forks locked. Locking the forks restricts the vehicle's turning ability, which could result in death or serious injury. (00035a)**

**⚠WARNING**

**Perform the service and maintenance operations as indicated in the regular service interval table. Lack of regular maintenance at the recommended intervals can affect the safe operation of your motorcycle, which could result in death or serious injury. (00010a)**

**⚠WARNING**

**Do not operate motorcycle with loose, worn or damaged steering or suspension systems. Contact a Harley-Davidson dealer for repairs. Loose, worn or damaged steering or suspension components can adversely affect stability and handling, which could result in death or serious injury. (00011a)**

**⚠WARNING**

**Regularly inspect shock absorbers and front forks. Replace leaking, damaged or worn parts that can adversely affect stability and handling, which could result in death or serious injury. (00012a)**

**⚠WARNING**

**Use Harley-Davidson replacement fasteners. Aftermarket fasteners can adversely affect performance, which could result in death or serious injury. (00013a)**

- See Harley-Davidson service manual for proper torque values.
- Aftermarket fasteners may not have the specific property requirements to perform properly.

**⚠WARNING**

**Be sure tires are properly inflated, balanced and have adequate tread. Inspect your tires regularly and see a Harley-Davidson dealer for replacements. Riding with**

**excessively worn, unbalanced or under-inflated tires can adversely affect stability and handling, which could result in death or serious injury. (00014a)**

**⚠WARNING**

**Replace punctured or damaged tires. In some cases, small punctures in the tread area may be repaired from within the demounted tire by a Harley-Davidson dealer. Speed should NOT exceed 50 mph (80 km/h) for the first 24 hours after repair, and the repaired tire should NEVER be used over 80 mph (130 km/h). Failure to follow this warning could result in death or serious injury. (00015a)**

**⚠WARNING**

**Do not exceed the motorcycle Gross Vehicle Weight Rating (GVWR). Exceeding the GVWR can affect stability and handling, which could result in death or serious injury. (00016a)**

- GVWR is the sum of the weight of the motorcycle, accessories, and the maximum weight of the rider, passenger and cargo that can be safely carried.
- The GVWR is shown on the information plate located on the frame steering head.

**⚠WARNING**

**Do not tow a disabled motorcycle. Towing can adversely affect stability and handling, which could result in death or serious injury. (00017a)**

**⚠WARNING**

**Do not pull a trailer with a motorcycle. Pulling a trailer can cause tire overload, reduced braking efficiency and adversely affect stability and handling, which could result in death or serious injury. (00018b)**

**⚠CAUTION**

**Direct contact of D.O.T. 4 brake fluid with eyes can cause irritation. Avoid eye contact. In case of eye contact flush with large amounts of water and get medical attention. Swallowing large amounts of D.O.T. 4 brake fluid can cause digestive discomfort. If swallowed, obtain medical attention. Use in well ventilated area. KEEP OUT OF REACH OF CHILDREN. (00240a)**

**⚠WARNING**

**Batteries, battery posts, terminals and related accessories**

**Batteries, battery posts, terminals and related accessories contain lead and lead compounds, and other chemicals known to the State of California to cause cancer and birth defects or other reproductive harm. Wash hands after handling. (00019d)**

### **⚠WARNING**

**Consult a Harley-Davidson dealer regarding any questions or problems that occur in the operation of your motorcycle. Failure to do so can aggravate an initial problem, cause costly repairs, cause an accident and could result in death or serious injury. (00020a)**

- Be sure all equipment required by federal, state and local law is installed and in good operating condition.

### **⚠WARNING**

**Do not open storage compartments while riding. Distractions while riding can lead to loss of control, which could result in death or serious injury. (00082a)**

## **Rules of the Road**

---

- Keep to the right side of the road centerline when meeting other vehicles coming in the opposite direction. Ride to left of center of your lane to avoid oily pavement ahead.
- Always sound your horn, actuate your turn signals, and exercise caution when passing other vehicles going in the same direction. Never try to pass another vehicle going in the same direction at street intersections, on curves, or when going up or down a hill.
- At street intersections give the right-of-way to the vehicle on your right. Do not presume you have the right-of-way, as the other driver may not know it is your turn.
- Always signal when preparing to stop, turn or pass.
- All traffic signs, including those used for the control of traffic at intersections, should be obeyed promptly. SLOW DOWN signs near schools and CAUTION signs at railroad crossings should always be observed and your actions governed accordingly.
- When intending to turn to the left, signal at least 100 feet (30.5 meters) before reaching the turning point. Move over to the centerline of the street (unless local rules require otherwise), slow down, enter the intersection of the street and then turn carefully to the left.
- Never anticipate a traffic light. When a change is indicated from GO to STOP (or vice versa) in the traffic control systems at intersections, slow down and wait for the light to change. Never run through a yellow or red traffic light.
- While turning either right or left, watch for pedestrians, animals, as well as vehicles.
- Do not leave the curb or parking area without signaling. Be sure your way is clear to enter moving traffic. A moving line of traffic always has the right-of-way.
- Be sure your license plate is installed in the position specified by law and is clearly visible at all times. Keep the plate clean.
- Ride at a safe speed that is consistent with the type of highway you are on. Pay strict attention to whether the road is dry, oily, icy or wet.
- Watch for debris such as leaves or loose gravel.
- Weather and traffic conditions on the highway dictate adjusting your speed and driving habits accordingly.

## Accessories and Cargo: FLHTCSE2

---

Harley-Davidson Motor Company cannot test and make specific recommendations concerning every accessory or combination of accessories sold. Therefore, the rider must be responsible for safe operation of the motorcycle when installing accessories or carrying additional weight.

### **⚠WARNING**

**See the Accessory and Cargo section in your Owner's Manual. Improper loading of cargo or installation of accessories can affect motorcycle stability and handling, which could result in death or serious injury. (00021a)**

### **⚠WARNING**

**Do not exceed the motorcycle Gross Vehicle Weight Rating (GVWR). Exceeding the GVWR can affect stability and handling, which could result in death or serious injury. (00016a)**

- GVWR is the sum of the weight of the motorcycle, accessories, and the maximum weight of the rider, passenger and cargo that can be safely carried.
- The GVWR is shown on the information plate which is located on the frame down tube.

### **⚠WARNING**

**Do not pull a trailer with a motorcycle. Pulling a trailer can cause tire overload, reduced braking efficiency and adversely affect stability and handling, which could result in death or serious injury. (00018b)**

## Accessory and Cargo Guidelines

---

The following guidelines should be used when equipping a motorcycle, carrying passengers and/or cargo.

### **⚠WARNING**

**Travel at speeds appropriate for road and conditions and never travel faster than posted speed limit. Excessive speed can cause loss of vehicle control, which could result in death or serious injury. (00008a)**

- Do not exceed the legal speed limit or drive too fast for existing conditions. Always reduce speed when poor driving conditions exist. High speed increases the influence of any other condition affecting stability and increases the possibility of loss of control.
- Pay strict attention to road surfaces and wind conditions. Any two wheeled vehicle may be subject to upsetting forces such as wind blasts from passing trucks, holes in the pavement, rough road surfaces, rider control error, etc. These forces may influence the handling

characteristics of your motorcycle. If this happens, reduce speed and guide the motorcycle with a relaxed grip to a controlled condition. Do not brake abruptly or force the handlebar. This may aggravate an unstable condition.

- Keep cargo weight concentrated close to the motorcycle and as low as possible. This minimizes the change in the motorcycle's center of gravity.
- Distribute weight evenly on both sides of the vehicle.
- Do not load bulky items too far behind the rider or add weight to the handlebars or front forks.
- Do not exceed maximum specified load in each saddlebag.
- Luggage racks are designed for lightweight items. Do not overload racks.
- Be sure cargo is secure and will not shift while riding and recheck the cargo periodically. Accessories that change the operator's riding position may increase reaction time and affect handling of the motorcycle.
- Additional electrical equipment may overload the motorcycle's electrical system possibly resulting in electrical system and/or component failure.

### **⚠WARNING**

**The front and/or rear guard(s) can provide limited leg and cosmetic vehicle protection under unique circumstances. (Fall over while stopped, very slow speed slide.) It is not made or intended to provide protection from bodily injury in a collision with another vehicle or any other object. (00022a)**

Large surfaces such as fairings, windshields, back rests, and luggage racks can adversely affect handling. Only genuine Harley-Davidson items designed specifically for the motorcycle model should be used with proper installation.

### **⚠WARNING**

**Do not use aftermarket parts and custom made front forks which can adversely affect performance and handling. Removing or altering factory installed parts can adversely affect performance and could result in death or serious injury. (00001a)**

### **⚠WARNING**

**Do not add a sidecar to the Screamin' Eagle FLHTCSE2 motorcycle, as it is not designed for sidecar use. Use of the vehicle for this purpose can cause loss of vehicle control, which could result in death or serious injury. (00364a)**

## **Identification**

### **2005 FLHTCSE2 Models**

---

This section provides left and right side views of your 2005 FLHTCSE2 motorcycle. Please refer





to the CONTROLS AND INDICATORS and OPERATION sections for specific details about each component.

NOTE:

*Specifications in this publication may not match those of official certification in some markets due to timing of publication printing, variance in testing methods, and/or vehicle differences.*

*Customers seeking officially recognized regulatory specifications for their vehicle should refer to certification documents and/or contact their respective dealer or distributor.*



## Vehicle Identification Number: Touring Models


---

The full 17-digit serial or Vehicle Identification Number (V.I.N.) is stamped on the left side of the frame backbone at the rear of the steering head. A label bearing the V.I.N. code is also affixed to the left side of the steering head.

An abbreviated V.I.N. is stamped on the left side crankcase at the base of the rear cylinder.

*NOTE:*

*Always give the full 17-digit Vehicle Identification Number when ordering parts or making any inquiry about your motorcycle.*



1 HD 1 BJ Y 1 3 5 K 111000

1. Market designation (1 character)
2. Manufacturer (2 characters)
3. Motorcycle type (1 character)
4. Model (2 characters)
5. Engine type (1 character)
6. Introduction date (1 character)
7. V.I.N. check digit (1 character)
8. Model year (1 character)
9. Assembly plant (1 character)
10. Sequential number (6 characters)

**Typical Harley-Davidson Vehicle Identification Number**

**2005 Harley-Davidson FLHTCSE2 V.I.N. Breakdown**

POSITION	DESCRIPTION	POSSIBLE VALUES
1	Market designation	1=Domestic 5=International
2	Manufacturer	HD=Harley-Davidson
3	Motorcycle type	1=Heavyweight motorcycle
4	Model	see model V.I.N. table
5	Engine type	E=1690cc fuel injected
6	Introduction date	1=Regular 2=Mid-year 3=California
7	V.I.N. check digit	Can be 0-9 or X
8	Model year	5=2005
9	Assembly plant	Y=York, PA K=Kansas City, MO
10	Sequential number	varies

**V.I.N. Codes: 2005 FLHTCSE2 Models**

CODE	MODEL
PK	FLHTCSE2

## Specifications

### Specifications: 2005 FLHTCSE2 Models

**Engine: 2005 FLHTCSE2**

ITEM	SPECIFICATION	
Number of cylinders	2	
Type	4-cycle, 45 degree V-Type, air cooled	
Compression ratio	9-1	
Bore	3.87 in.	98.30 mm
Stroke	4.37 in.	111.0 mm
Displacement	103 cu. in.	1690 cc
Torque	100.0 ft-lbs @ 3500 RPM	138 Nm @ 3500 RPM

**Ignition System: 2005 FLHTCSE2**

<b>COMPONENT</b>	<b>SPECIFICATION</b>	
Ignition timing	not adjustable	
Battery	12 volt, 28 amp/hr, sealed and maintenance free	
Spark plug type	HD-6R12	
Spark plug size	12 mm	
Spark plug gap	0.038-0.043 in.	0.97-1.09 mm
Spark plug torque	12-18 ft-lbs	16.3-24.4 Nm

**Transmission Specifications**

<b>TRANSMISSION</b>	<b>SPECIFICATION</b>
Type	Constant mesh, foot shift
Speeds	5 forward

**Sprocket Teeth: 2005 Touring Models**

<b>DRIVE</b>	<b>ITEM</b>	<b>NUMBER OF TEETH</b>
Primary	Engine	25
	Clutch	36
Final	Transmission	32
	Rear wheel	70

**Capacities: 2005 FLHTCSE2**

<b>ITEM</b>	<b>U.S.</b>	<b>LITERS</b>
Fuel tank (total)	5.0 gal	18.9
Oil tank with filter	4.0 qt.	3.8
Transmission (approximate)	20-24 oz.	0.59-0.71
Primary chaincase (approximate)	32.0 oz.	0.95

**Gear Ratios: 2005 Touring Models**

GEAR	RATIO
1st Gear	10.11
2nd Gear	6.958
3rd Gear	4.953
4th Gear	3.862
5th Gear	3.150

NOTE:

Gross Vehicle Weight Rating (GVWR) (maximum allowable loaded vehicle weight) and corresponding Gross Axle Weight Ratings (GAWR) are given on a label located on the frame below the steering head.

**Weights: 2005 FLHTCSE2**

ITEM	LB.	KG
Weight as shipped from factory	808	366.5
GVWR	1259	572
GAWR front	500	227
GAWR rear	827	375

**Dimensions: 2005 FLHTCSE2**

ITEM	IN.	MM
Wheel base	63.5	1612.9
Overall length	96.93	2462
Overall width	38.5	977.9
Road clearance	4.21	106.93
Overall height	53.27	1353
Saddle height	26.89	683

**Tire Pressures: 2005 Touring Models**

MODEL	LOAD	TIRE PRESSURE (COLD)			
		FRONT		REAR	
		PSI	kPa	PSI	kPa
All	solo rider	36	248	36	248
	rider and passenger	36	248	40	276

2005 vehicles use Dunlop Harley-Davidson tires only.

**Tire Sizes: 2005 Touring Models**

MODEL	MOUNT	SIZE	NUMBER
All	front	16 in.	D402F MT90B16
All	rear	16 in.	D402 MU85B16

**Bulb Chart: 2005 FLHTCSE2**

LAMP	DESCRIPTION (ALL LAMPS 12 VOLT)	BULBS REQUIRED	CURRENT DRAW AMPERAGE	HARLEY- DAVIDSON PART NUMBER
Headlamp	headlamp	1	4.58/5.0	68329-03
	position lamp international	1	0.32	53438-92
Tail and stop lamp	tail lamp	1	0.59	68167-04
	stop lamp	1	2.10	68167-04
	tail lamp international	1	0.59	68167-04
	stop lamp international	1	2.10	68167-04
Turn signal lamp	front/running	2	2.25/0.59	69331-02
	front international	2	1.75	68163-84
	rear	2	2.25	69330-02
	rear international	2	1.75	68163-84
Auxiliary lighting	License plate lamp	2	0.35	52441-95
	License plate lamp international	1	0.37	53436-97
	Tour-Pak lamp	1	1.2	54304-98
	Auxiliary lamps	2	2.1	68351-05
	Auxiliary lamps international	2	2.7	68851-98
Instrument panel lamps	high beam indicator	1	0.15	68024-94
	oil pressure indicator	1	0.15	68024-94
	neutral indicator	1	0.15	68024-94
	turn signal indicator	2	0.08	68024-94
Gauge lamps	speedometer*	N/A	N/A	N/A
	tachometer*	N/A	N/A	N/A
	voltmeter	1	0.24	67454-04
	oil pressure	1	0.24	67454-04
	air temperature	1	0.24	67454-04
	fuel	1	0.24	67454-04
Items with *	Illuminated with LEDs. Replace entire assembly upon failure.			

**Tire Data**

**⚠WARNING**

**Match tires, tubes, air valves and caps to the correct wheel rim. Contact a Harley-Davidson dealer. Mismatching can result in damage to the tire bead, allow tire slippage on the rim or cause tire failure, which could result in death or serious injury. (00023a)**

**⚠WARNING**

**Use only Harley-Davidson approved tires. See a Harley-Davidson dealer. Using non-approved tires can adversely affect stability, which could result in death or serious injury. (00024a)**

Tubeless tires fitted with the correct size inner tubes may be used on all Harley-Davidson laced (wire spoked) wheels. Protective rubber rim strips must be used with tubeless tires (fitted with correct size inner tubes) when mounted on laced (wire spoked) wheels.

**⚠WARNING**

**Use inner tubes on laced (wire spoked) wheels. Using tubeless tires on laced wheels can cause air leaks, which could result in death or serious injury. (00025a)**

Tubeless tires are used on all Harley-Davidson cast and disc wheels.

Tire sizes are molded on the tire sidewall. Inner tube sizes are printed on the tube.

**⚠WARNING**

**Harley-Davidson front and rear tires are not the same. Interchanging front and rear tires can cause tire failure, which could result in death or serious injury. (00026a)**

**⚠WARNING**

**Do not inflate tire beyond maximum pressure as specified on sidewall. Over inflated tires can blow out, which could result in death or serious injury. (00027a)**

**⚠WARNING**

**Harley-Davidson tires are equipped with wear bars that run horizontally across the tread. When wear bars become visible and only 1/32 in. (0.8 mm) tread depth remains, replace tire immediately. Using a worn tire can adversely affect stability and handling, which could result in death or serious injury. Use only Dunlop Harley-Davidson replacement tires. (00090a)**

See Specifications: 2005 FLHTCSE2 Models for tire pressures and sizes.

## Gasoline Blends

---

Your motorcycle was designed to get the best performance and efficiency using unleaded gasoline. Most gasoline is blended with alcohol and/or ether to create oxygenated blends. The type and amount of alcohol or ether added to the fuel is important.

### CAUTION

**Do not use gasoline that contains methanol. Doing so can result in fuel system component failure, engine damage and/or equipment malfunction. (00148a)**

- Gasoline containing METHYL TERTIARY BUTYL ETHER (MTBE): Gasoline/MTBE blends are a mixture of gasoline and as much as 15% MTBE. Gasoline/MTBE blends can be used in your motorcycle.
- ETHANOL is a mixture of 10% ethanol (Grain alcohol) and 90% unleaded gasoline. Gasoline/ethanol blends can be used in your motorcycle if the ethanol content does **not** exceed 10%.
- REFORMULATED OR OXYGENATED GASOLINES (RFG): Reformulated gasoline is a term used to describe gasoline blends that are specifically designed to burn cleaner than other types of gasoline, leaving fewer tailpipe emissions. They are also formulated to evaporate less when you are filling your tank. Reformulated gasolines use additives to oxygenate the gas. Your motorcycle will run normally using this type of gas and Harley-Davidson recommends you use it when possible, as an aid to cleaner air in our environment.

You may find that some gasoline blends adversely affect the starting, driveability or fuel efficiency of your motorcycle. If you experience one or more of these problems, it is recommended you operate your motorcycle on straight unleaded gasoline.

## Fuel

---

Refer to Octane Ratings. Always use a good quality unleaded gasoline. Octane ratings are usually found on the pump.

### ⚠WARNING

**Avoid spills. Slowly remove filler cap. Do not fill above bottom of filler neck insert, leaving air space for fuel expansion. Secure filler cap after refueling. Gasoline is extremely flammable and highly explosive, which could result in death or serious injury. (00028a)**

### ⚠WARNING

**Use care when refueling. Pressurized air in fuel tank can force gasoline to escape through filler tube. Gasoline is extremely flammable and highly explosive, which could**



**result in death or serious injury. (00029a)**

Modern service station pumps dispense a high flow of gasoline into a motorcycle fuel tank making air entrapment and pressurization a possibility.

**Octane Ratings**

<b>SPECIFICATION</b>	<b>RATING</b>
Pump Octane (R+M)/2	91 (95 RON)

## **Catalytic Converters**

---

California and all international motorcycles are equipped with catalytic converters.

**CAUTION**

**Do not operate catalytic converter-equipped vehicle with engine misfire or a non-firing cylinder. If you operate the vehicle under these conditions, the exhaust will become abnormally hot, which can cause vehicle damage, including emission control loss. (00149a)**

**CAUTION**

**Use only unleaded fuel in catalytic converter-equipped motorcycles. Using leaded fuel will damage the emission control system. (00150b)**

## **Controls and Indicators**

### **General: Controls and Indicators**

---

**⚠WARNING**

**Read the CONTROLS AND INDICATORS section before riding your motorcycle. Failure to understand the operation of the motorcycle could result in death or serious injury. (00043a)**

Some features explained are unique to certain models. These features may be available as accessories for your Harley-Davidson motorcycle. See a Harley-Davidson dealer for a complete list of accessories that will fit your specific motorcycle.

Refer to the side view photographs in the front of the manual to locate the items discussed in this section. See 2005 FLHTCSE2 Models.

### **Ignition/Headlamp Key Switch: FLHTCSE2**

---

## **⚠WARNING**

**The automatic-on headlamp feature provides increased visibility of the rider to other motorists. Be sure headlamp is on at all times. Poor visibility of rider to other motorists can result in death or serious injury. (00030b)**

See YOUR OWNER'S MANUAL section. Be sure to record all your key numbers in the space provided at the front of this book.

See Ignition/Headlamp Key Switch: FLHTCSE2. The ignition/headlamp key switch controls electrical functions of the motorcycle.

## **CAUTION**

**Protect your vehicle against theft. After parking your motorcycle, lock the steering head and remove ignition key from switch. Failure to lock your motorcycle may result in theft and/or equipment damage. (00151a)**

## **⚠WARNING**

**Do not operate vehicle with forks locked. Locking the forks restricts the vehicle's turning ability, which could result in death or serious injury. (00035a)**

## **CAUTION**

**Do not lubricate barrel locks with petroleum based lubricants or graphite. Inoperative locks may result. (00152a)**

## **CAUTION**

**Do not switch lubricant brands indiscriminately because some lubricants interact chemically when mixed. Use of inferior lubricants can damage the engine. (00184a)**


1. To remove the key from the ignition on FLHTCSE2 models, push the key in and turn clockwise.
2. Remove the key.

### **NOTES:**

- *Harley-Davidson recommends removing key from ignition/fork lock before operating motorcycle. If you do not remove key, it can fall out during operation.*
- *ACCESS/ACCESSORY - Accessories and hazard warning flasher can be turned on. Instrument lamps are on. Brake lamp and horn can be activated. Key may be removed.*
- *The lamps illuminate when the switch is in the IGNITION position, as required by law in some localities.*

**Ignition/Headlamp Switch Positions: 2005 FLHTCSE2**

LOCATION	SWITCH POSITIONS/FUNCTIONS
At bottom of instrument panel.	To unlock the switch and the front fork, push the key in and turn it counterclockwise. Be sure you push key in to move key to either position. On international models, the switch knob will pop up. Ignition/headlamp key switch can be locked in the accessory position however, forks will remain unlocked.
	To lock the fork, move fork to the full left position. Push down on knob and turn it to the left, to the FORK LOCK position. Turn key to lock. Remove the key. On international models, turn fork to full left position. Turn switch knob to fork lock, push knob down and turn key to LOCK. Remove the key.
	ACCESS/ACCESSORY - Accessories and hazard warning flasher can be left on. Instrument lamps are on. Brake lamp and horn can be activated. Key may be removed.  The ignition, lamps and accessories work when the switch is in the IGNITION position, as required by law in some localities.*
* International models have an additional function. Position lamp and tail lamp are also on.	



**Hand Controls: FLHTCSE2**

**CAUTION**

**Control wiring is routed inside handlebar and may be pinched or cut if controls are rotated too far. Electrical damage to control wiring can result. See Service Manual Supplement or see a Harley-Davidson dealer. (00363a)**

**Electric Starter Switch**

*NOTE:*

*Off/Run switch MUST be in RUN position to operate engine.*

See Basic Handlebar Controls: FLHTCSE2. The electric starter switch is located on the right handlebar control group. See Starting the Engine: EFI Models for detailed operation procedures.

1. Put the engine off/run switch in the RUN position and the transmission in neutral. Neutral (green) indicator lamp should be illuminated.
2. See Ignition/Headlamp Key Switch: FLHTCSE2. Turn ignition/headlamp key switch to ON and push the START switch to operate starter motor.

## Engine OFF/RUN Switch

---

See Basic Handlebar Controls: FLHTCSE2. The engine off/run switch (7) turns the ignition power ON or OFF. The engine off/run switch is located on the right handlebar control. Push the top portion of the engine off/run switch to turn off ignition power and shut the engine off. Push the bottom portion of the engine off/run switch to turn on ignition power.

### NOTES:

- *The engine off/run switch must be in the ON position to start or operate the engine.*
  - *The engine off/run switch should be used to shut the engine off.*
1. To shut the engine off, push the top of the off/run switch to the ignition OFF position.
  2. See Ignition/Headlamp Key Switch: FLHTCSE2. Turn the ignition key to the OFF position to turn the ignition power completely OFF.

## Throttle Control Grip

---

See Basic Handlebar Controls: FLHTCSE2. The throttle control grip (9) is located on the right handlebar control and is operated with the right hand.

## Clutch Hand Lever

---

### **⚠WARNING**

**Do not position fingers between hand control lever and handlebar grip. Improper hand positioning can impair control lever operation and cause loss of vehicle control, which could result in death or serious injury. (00032a)**

The clutch hand lever (1) is located on the left handlebar and is operated with the fingers of the left hand.

1. Slowly pull clutch hand lever in against handlebar grip to fully disengage clutch.
2. Shift to first gear using the gear shifter lever. See Gear Shift Lever.
3. Slowly release the clutch hand lever to engage clutch.

## Horn Switch

---

The horn is operated by pushing on the horn switch (2) located on the left handlebar control group.

## Headlamp Dimmer Switch

---

The headlamp dimmer switch (3) is located on the left handlebar. The switch has two positions to activate the headlamps high or low beams.

- Press the top of the headlamp dimmer beam switch to activate the high beam.
- Press the bottom of the headlamp dimmer switch to return to the low beam.

See Indicator Lamps: FLHTCSE2. The (blue) high beam indicator lamp will illuminate when the high beam is on.

## Turn Signal Switches


---

Each handlebar control group contains a turn signal switch.

- The right turn signal switch (11) operates the right front and right rear flashing lamps.
- The left turn signal switch (4) operates the left front and left rear flashing lamps.

*NOTE:*

*Front turn signal lamps also function as running lamps.*



## Turn Signal Switch Operation

---

The turn signal switches are used by the turn signal module to control turn signal operation based

on vehicle speed, vehicle acceleration and turn completion.

Momentarily depress the desired turn signal switch. The turn signal lamps will begin and continue flashing until they are manually or automatically cancelled. As long as the motorcycle is stationary, the signals will flash.

*NOTES:*

- *If you want the turn signals on longer, hold the switch in. The turn signals will begin flashing immediately, but the microprocessor will not begin computing distance until you release the switch.*
- *If you are signaling to turn in one direction and you depress the switch for the opposite turn signal, the first signal is cancelled and the opposite side begins flashing.*
- *If you want to stop the lamps from flashing, briefly depress the turn signal switch a second time. The turn signal lamps will stop flashing.*

## **Hazard Warning 4-Way Flasher**

---

Use the following method to activate the four-way flashers.

1. With the ignition key ON and security system disarmed (models with security only), press the left and right turn signal switches at the same time.
2. Turn the ignition key OFF and arm the security system if present and desired. The four-way flashers will continue for two hours.
3. To cancel four-way flashing, disarm the security system if necessary, turn the ignition key ON and press the left and right turn signal switches at the same time.

This system allows a stranded vehicle to be left in the four-way flashing mode and secured until help is found.

## **Indicator Lamps**

---

See Indicator Lamps. Five indicator lamps are provided.

- The green TURN indicators will flash when turn signals are activated; therefore, flashing indicates the chosen turn direction. When the 4-way hazard flashers are operating, both turn indicators will flash simultaneously.
- The blue BEAM indicator lamp, when lit, signals high beam headlamp operation.
- The green NEUTRAL lamp, when lit, signals the transmission is in neutral gear.
- The red OIL indicator lamp, when lit, signals that oil is not circulating through the engine.

*NOTE:*

*The OIL indicator lamp will glow when the ignition is turned on prior to starting engine. With engine running, lamp should be off when engine speed is above idle.*


Several other circumstances that could cause the red oil indicator lamp to signal, include the following:

- If the oil pressure indicator lamp does not go off at speeds above idling, it is usually because of an empty oil tank or diluted oil.
- In freezing weather the oil feed may clog with ice and sludge, preventing oil circulation.
- A grounded oil signal switch wire.
- A faulty signal switch.

- A damaged or improperly installed check valve.
- Trouble with the pump.

### CAUTION

If the oil pressure indicator lamp remains lit, always check the oil supply first. If the oil supply is normal and the lamp is still lit, stop the engine at once and do not ride further until the trouble is located and the necessary repairs are made. Failure to do so may result in engine damage. (00157a)



## Instruments: FLHTCSE2

### Speedometer

### WARNING

Travel at speeds appropriate for road and conditions and never travel faster than posted speed limit. Excessive speed can cause loss of vehicle control, which could result in death or serious injury. (00008a)

See Indicator Lamps: FLHTCSE2. The speedometer registers miles per hour (U.S. models only) or kilometers per hour (international models only) of forward speed. The odometer registers the number of miles/kilometers the vehicle has traveled.

The electronic speedometer has a single display window for both the odometer and trip-odometer.

1. Press the function switch to change the display window on the speedometer face to either

odometer or trip-odometer.

2. To reset the trip-odometer to zero, press button to reset speedometer display to the ODOMETER mode and hold the button in for approximately 2-3 seconds. The speedometer will switch to the trip-odometer mode and reset the display to zero.

## Tachometer

---

### CAUTION

**See OPERATING RECOMMENDATIONS section. Do not operate the engine above maximum safe RPM as shown under OPERATION (red zone on tachometer). Lower the RPM by upshifting to a higher gear or reducing the amount of throttle. Failure to lower RPM may cause equipment damage. (00159a)**

See Indicator Lamps: FLHTCSE2. The tachometer measures the engine speed in revolutions per minute (RPM).

## Trip Odometer

---

Use the trip-odometer A or trip-odometer B to register number of miles/kilometers traveled on a trip or between refueling.

Odometer will display mileage when bike is OFF when function switch is pressed. There is no need to turn the bike on to check the odometer reading.

### CAUTION

**Never attempt to tamper with or alter the vehicle odometer. This is illegal. Tampering with or altering a vehicle odometer may cause equipment damage. (00160a)**

## Tip Indicator Lamp

---

### ⚠ WARNING

**If tip occurs, check all controls for proper operation. Restricted control movement can adversely affect the performance of the brakes, clutch or ability to shift, which could result in loss of vehicle control and death or serious injury. (00350a)**

Should motorcycle be tipped over, the word "tip" will appear in the odometer window. Engine will not start until reset. To reset, cycle ignition/headlamp key switch ON-OFF-ON.

## Fuel Gauge



---

The fuel gauge indicates the approximate amount of fuel in the fuel tank(s) and is located to left of the speedometer or on the left front panel of the fairing.

## Oil Pressure Gauge

---

The oil pressure gauge indicates engine oil pressure and is found on the front panel of the fairing. Engine oil pressure will normally vary from 5 psi (34 kN/m<sup>2</sup>) at idle speed to 30-38 PSI (207-262 kN/m<sup>2</sup>) at 2000 RPM when engine is at normal operating temperature of 230° F (110° C).

## Voltmeter

---

The voltmeter indicates electrical system voltage and is found on the front panel of the fairing. With the engine running above 1500 RPM, the voltmeter should register 13-14.5 volts with battery at full charge.

## Air Temperature Gauge


---

The air temperature gauge indicates the ambient air temperature in degrees fahrenheit. This gauge is found on the front panel of the fairing.

## Clock (In Radio)

---

The clock runs continuously as long as there is battery power. See the premium sound system section in this manual to reset clock.



## Indicator Lamps: FLHTCSE2

---

## Engine Check Lamp

---

See Indicator Lamps: FLHTCSE2. The engine check lamp is located near the lower left side of the speedometer. Its purpose is to indicate whether or not the engine/engine management system is operating normally. The engine lamp color is amber.

The engine lamp normally comes on when the bike's ignition is first turned on and remains on for approximately 4 seconds, as the engine management system runs a series of self-diagnostics.

If the engine lamp comes on at any other time, see a Harley-Davidson dealer.

## Low Fuel Lamp (EFI Models)

---

See Indicator Lamps: FLHTCSE2. Fuel injected motorcycles have a low fuel lamp on the speedometer, lower center by check engine lamp. The low fuel lamp illuminates to indicate that you have approximately 1 gallon (3.8 liters) of gasoline left in the tank. The low fuel lamp color is amber.

## Cruise Control Equipped Models

---

See Indicator Lamps: FLHTCSE2. Cruise control equipped models feature two additional indicator lamps.

- A red lamp on the cruise control switch which indicates the cruise control is ON or OFF.
- A green lamp on the tachometer which indicates the cruise control is SET or NOT SET.

*NOTE:*

*Touring Models are either equipped with cruise control or are cruise control ready. See a Harley-Davidson dealer for more information.*

## Cruise Control: Touring Models

---

## Operating Controls

---

The cruise control system provides automatic vehicle speed control.

### **⚠WARNING**

**Do not use the cruise control system in heavy traffic, on roads with sharp or blind curves or on slippery roads of any kind. Using the cruise control in these circumstances can cause loss of control, which could result in death or serious injury. (00083a)**


See Cruise Control Fairing Cap Switch: FLHTCSE2. A fairing cap cruise control switch located to the right of the ignition/headlamp key switch turns the cruise control system ON and OFF.

NOTE:


The cruise control icon on the speedometer or tachometer will turn red to indicate the cruise control is ON. If the red icon does NOT come on, the system is NOT ON. You cannot SET cruise speed, see your dealer.

See RESUME/SET Switch. RESUME/SET switch located in the right handlebar control group.

The RESUME/SET switch controls several system functions, including set, resume, accelerate and decelerate.



om00336



## Cruise Control Operation

---

### Theory of Operation

---

The cruise control is designed to be safely operated with minimum movement by the rider and all rider control actions are natural and easy.

#### NOTES:

- *The rider always over-rides and controls the system.*
- *The system will not work at vehicle speeds below 30 mph (48 kph) or above 85 mph (137 kph).*
- *The system is managed by a small computer. The tachometer provides information to disengage the system if the engine RPM suddenly increases.*
- *Besides the computer, the system has other components: a stepper-motor (controlled by the computer), which operates the throttle during CRUISE operation, a clutch which disengages the stepper-motor during non-cruise operation and several internal switches, all sending information to the computer.*
- *The system will allow rider to increase speed 10 mph (16 kph) or more (depending on how hard the rider rolls on the throttle and the condition of the bike) over the SET point before deactivating. This feature allows the rider to momentarily increase speed, if necessary. Rolling on the throttle to greatly increase speed may deactivate the system.*

### Engaging Cruise Control

---

1. See Indicator Lamps: FLHTCSE2. Turn the cruise control switch to the ON position. The

red icon on the cruise gauge face will light when activated.

2. With the motorcycle traveling at the desired cruise speed of 30-85 mph (48-137 kph), momentarily push the RESUME/SET switch on the right handlebar to SET. After a delay of about 1-1/2 seconds, the icon will turn green on the face of the gauge to indicate the selected cruising speed is locked in.

## Disengaging Cruise Control

---

The cruise control automatically disengages whenever the cruise control module receives one of the following inputs:

1. Front and/or rear brake is applied.
2. Throttle is rolled back or closed, thereby actuating idle cable roll-off (disengage) switch.
3. Motorcycle clutch is disengaged (module senses too great an increase in RPM).
4. Vehicle speed is out of the operating range.

*NOTE:*

*Rolling on the throttle more than 10 mph (16 kph) above the set speed may also deactivate the cruise control.*

When the cruise is disengaged, the green cruise engaged icon on the face of the gauge changes to red. The red cruise control system icon remains ON until the main switch is turned off.

However, should you decide to SET a cruise speed, RESUME last set speed, ACCELERATE or DECELERATE, simply press the RESUME/SET switch.

## Resuming Cruise Speed

---

If the system is deactivated using one of the methods described under DEACTIVATING CRUISE CONTROL, the system is still ON should you decide to RESUME the set speed. To accomplish this, simply press the RESUME/SET switch to RESUME.

*NOTE:*

*The computer will hold the SET speed in memory for the RESUME function. If the vehicle speed drops more than 15 mph (72 kph) below the SET speed, speed can no longer be RESUMED. If cruise operation is still desired, press the RESUME/SET switch to SET to reset the cruise speed.*

## Accelerating Above Cruise Speed

---

1. With the cruise speed set, momentarily press the RESUME/SET switch to RESUME to increase the speed by 1 mph (1.6 kph).
2. Pressing and holding the RESUME/SET switch at RESUME will cause the system to continue to increase speed in increments of approximately 1 mph (1.6 kph) until the switch is released. There is a delay of about 2 seconds before the speed increases.

## Decelerating Cruise Control

- 
1. With the cruise speed set, momentarily press the RESUME/SET switch to SET to reduce the speed by 1 mph (1.6 kph).
  2. Pressing and holding the RESUME/SET switch at SET will cause the system to continue to reduce speed in increments of approximately 1 mph (1.6 kph) until the switch is released. There is a delay of about 2 seconds before the speed decreases.

## Deactivating Cruise Control

---

Turn cruise control switch to the OFF position. The red icon in the gauge is extinguished to indicate the system is OFF.

### NOTES:

*System will NOT work if:*

- *An uphill grade is so long and/or steep; the throttle cables are pulled their full length when the system tries to maintain vehicle speed. This feature prevents stretching the cables.*
- *Rider operates bike at vehicle speeds below 30 mph (48 kph) or above 85 mph (137 kph).*
- *Throttle cables are too tight. See dealer.*
- *Brake lamps are on constantly. See dealer.*

## Gear Shift Lever

---

### CAUTION

**The clutch must be fully disengaged before attempting a gear shift. Failure to fully disengage the clutch can result in equipment damage. (00182a)**

The gear shift lever is located on the left side of the motorcycle and is operated with the left foot.

1. Push the gear shift lever all the way down (full stroke) to shift the transmission to the next lower gear.
2. Lift the gear shift lever all the way up (full stroke) to shift the transmission to the next higher gear.

### NOTES:

- *Release the gear shift lever after each gear change.*
- *The lever must return to its central position before another gear change can be made.*

See Shifting Sequence: Downshift. First gear is the last gear position that can be found by pushing the gear shift lever full stroke downward.

Neutral is located between first and second gear. The green neutral indicator lamp on the dash will illuminate when the transmission is in neutral.

1. To shift from first gear to neutral, lift the gear shift lever 1/2 of its full stroke.
2. To shift from second gear to neutral, push the gear shift lever downward 1/2 of its full stroke.

When the motorcycle is standing still and the engine is not running, shifting gears requires a


different technique. Before shifting in this condition, move the motorcycle backward and forward with the clutch fully disengaged (clutch lever pulled in). While maintaining slight pressure on the shift lever, shift from one gear to another.

Even with the engine running and the motorcycle standing still, difficulty may be experienced in shifting gears. This difficulty occurs because transmission gears are not turning and shifting parts are not lined up to permit engagement.

### CAUTION

**When difficulty of shifting gears is experienced, do not under any circumstances, attempt to force the shift. The results of such abuse will be a damaged or broken shifter mechanism. (00161a)**

See Shifting Gears for more information.




### Heel-Toe Foot Shifter

See Heel-Toe Foot Shift Lever. Some motorcycles have a heel-toe shifter lever. With this shift lever, upshifts can be made with the heel of the left foot. Downshifts can be made with the toe.

- Pushing heel-toe foot shift lever all the way down (full stroke) shifts the transmission to the next lower gear.
- Lifting the foot shift lever all the way up (full stroke) shifts the transmission into the next higher gear.

Release the foot shift lever after each gear change. This allows the lever to return to its central position before another gear change can be made.



## Brake System

### ⚠ WARNING

**Do not apply brake strongly enough to lock the wheel. A locked wheel will skid and can cause loss of vehicle control, which could result in death or serious injury. (00053a)**

The rear brake pedal controls the rear wheel brake and is located on the motorcycle's right side. Operate the rear brake pedal with the right foot.

The front brake hand lever controls the front wheel brake and is located on the right handlebar. Operate the hand lever with the fingers of the right hand.

### ⚠ WARNING

**Do not position fingers between hand control lever and handlebar grip. Improper hand positioning can impair control lever operation and cause loss of vehicle control, which could result in death or serious injury. (00032a)**

Brakes should be applied uniformly and evenly to prevent wheels from locking up. A balance between rear and front braking is generally best.

## Jiffy Stand





**Objects in mirrors are closer than they appear. Use caution when judging distance of objects in mirrors. Failure to judge correct distances could result in death or serious injury. (00033a)**

Your vehicle is equipped with two convex rear view mirrors.

This type of mirror is designed to give a much wider view to the rear than a flat mirror. However, cars and other objects seen in this type of mirror will look smaller and farther away than when seen in a flat mirror.

- Use caution when judging the size or relative distance of objects seen in rear view mirrors.
- Always adjust the rear view mirrors to clearly reflect the area behind the motorcycle before riding.

*NOTE:*

*Adjust mirrors so you can see a small portion of your shoulders in each mirror. This will help you establish the relative distance of vehicles to the rear of your motorcycle.*

## **Fuel Filler Cap: FLHTCSE2**

---

To open, turn fuel filler cap counterclockwise and lift up. To close, turn fuel filler cap clockwise until it clicks. The ratchet action of the cap prevents overtightening.

Remove the fuel filler cap slowly. Fill fuel tank slowly to prevent fuel spillage. Do not fill above the bottom of the filler neck insert. Leave enough air space to allow for fuel expansion. Expansion can cause an overfilled tank to overflow fuel through the filler cap vent onto surrounding areas. After refueling, be sure filler cap is securely tightened. Gasoline is extremely flammable and highly explosive. Inadequate safety precautions could result in death or serious injury.

*NOTES:*

*Fuel filler cap turns approximately a 3/4 turn before it starts unscrewing.*

See SAFE OPERATING RULES and review safety procedures listed below.

### **CAUTION**

**Do not spill fuel onto the motorcycle while refueling. Immediately wipe up fuel spills on your motorcycle. Fuel can cause damage to painted surfaces. (00147a)**

### **CAUTION**

**Use only unleaded fuel in catalytic converter-equipped motorcycles. Using leaded fuel will damage the emission control system. (00150b)**

### **⚠WARNING**

**Do not store motorcycle with gasoline in tank within the home or garage where open flames, pilot lights, sparks or**

electric motors are present. Gasoline is extremely flammable and highly explosive, which could result in death or serious injury. (00003a)

### **⚠WARNING**

Avoid spills. Slowly remove filler cap. Do not fill above bottom of filler neck insert, leaving air space for fuel expansion. Secure filler cap after refueling. Gasoline is extremely flammable and highly explosive, which could result in death or serious injury. (00028a)

### **⚠WARNING**

Do not use aftermarket fuel caps. Aftermarket fuel caps may fit improperly and leak, which could lead to death or serious injury. See a Harley-Davidson dealer for approved fuel caps. (00034a)

## **Fork Lock: FLHTCSE2**

---

### **CAUTION**

Protect your vehicle against theft. After parking your motorcycle, lock the steering head and remove ignition key from switch. Failure to lock your motorcycle may result in theft and/or equipment damage. (00151a)

*NOTE:*

*The fork lock is integrated into the ignition switch.*

Using the fork lock immediately after parking your motorcycle will discourage unauthorized use or theft when parking your motorcycle. For fork lock detail, refer to Ignition/Headlamp Switch Positions: 2005 FLHTCSE2.

### **⚠WARNING**

Do not operate vehicle with forks locked. Locking the forks restricts the vehicle's turning ability, which could result in death or serious injury. (00035a)

## **To Lock Fork**

---

1. Turn fork to full left position.
2. Push down on knob and turn left to FORK LOCK position.
3. Turn key to lock and remove key.

## Air Suspension Adjustment: FLHTCSE2

---


### General

---

See Rear Air Suspension Air Valve. All models feature air-adjustable rear suspension. Air pressure may be varied to suit personal comfort. Refer to Recommended Pressures for Air Suspension Adjustments: 2005 FLHTCSE2.

*NOTE:*

*An AIR SUSPENSION PUMP AND GAUGE HD-34633 is available at your Harley-Davidson dealer.*



### Rear Air Suspension

---

See Rear Air Suspension Air Valve. Adjust the rear shock air suspension pressure by adding or removing air from the air valve located just below the frame cover on the left side of the vehicle.

#### **CAUTION**

**Do not exceed maximum air pressure for rear suspension. Air components fill rapidly. Therefore, use low air line pressure. Failure to do so may result in possible damage**

to components. (00165a)

NOTE:

Using pressures outside the recommended loading range will result in a reduction of available suspension travel and reduced rider comfort.

### **⚠WARNING**

**Use caution when bleeding air from the suspension. Moisture combined with lubricant may leak onto the rear wheel, tire and/or brake components and adversely affect traction, which could result in death or serious injury. (00084a)**

NOTES:

- Do not exceed max GVWR.
- Always clear the line by adding 3-5 psi (21-35 kPa) before releasing air from the pump's valve, but do not exceed 35 psi (241 kPa).
- These are recommended starting points. Adjust to suit load conditions, riding style and comfort desired. Less initial pressure does not necessarily result in a softer ride.

Recommended Pressures for Air Suspension Adjustments: 2005 FLHTCSE2

SHOCK LOAD	TOTAL WEIGHT		PRESSURE	
	LB.	KG	PSI	kPa
Solo rider	up to 160	0-73	0-5	0-35
Solo rider	160-200	73-91	0-10	0-69
Solo rider	over 200	91	5-10	35-69
Rider with passenger weight of	up to 150	0-68	20-30	138-207
Rider with passenger weight of	over 150	0-68	25-35	172-241
Maximum GVWR	see label		40-50	276-345

## **Luggage**

### **⚠WARNING**

**Do not exceed the motorcycle Gross Vehicle Weight Rating (GVWR). Exceeding the GVWR can affect stability and handling, which could result in death or serious injury. (00016a)**

GVWR is the sum of the weight of the motorcycle, accessories, and the maximum weight of the rider, passenger and cargo that can be safely carried.

The GVWR is shown on the information plate, located on the frame steering head.

## **Saddlebags: FLHTCSE2**

## Opening

---

1. See Saddlebags: FLHTCSE2. Unlock latch.
2. Place fingers under latch and lift.
3. Place one hand at OUTSIDE CORNER of cover and other hand at opposite outside corner.
4. Lift outside edge of cover, pivoting inside edge of cover in brackets.
5. Lift inside edge of cover to disengage brackets.
6. Bring cover towards you, over saddlebag.
7. As you bring cover toward you, let it flip over, so the inside faces up. Let cover rest against rub bars and nylon check strap.

*NOTE:*

*The saddlebag lids are designed to stay attached to the bags at all times.*

## Closing

---

1. See Saddlebags: FLHTCSE2. Use both hands to hold OUTSIDE corners of cover up and slide inside edge back into place so brackets slide together.
2. Close lid and secure latch. Brackets will engage automatically.

*NOTE:*

*Saddlebag latch and Tour-Pak draw catches should be closed and locked whenever motorcycle is in operation.*

## Removing

---

See Saddlebags: FLHTCSE2. The saddlebags are secured to the support brackets by 1/4 turn fasteners called bail head studs.

*NOTE:*

*If your vehicle (international only) does not have the wire form "bail", use a flat bladed screwdriver to turn the studs.*

1. Unscrew saddlebag fasteners by turning 1/4 turn counterclockwise.
2. Remove saddlebag.

## Installing

---

Carefully place saddlebag in position on saddlebag rail and align the bail head studs with the support bracket fasteners.

1. See Saddlebags: FLHTCSE2. Fasten studs by pushing into support bracket fasteners and

turning 1/4 turn clockwise.

2. Check that studs are securely fastened.

## Adjustments


---

If the latches become loose, you can adjust the latch fingers.

### CAUTION

**Adjust the latch fingers only enough to enable them to properly engage the latch hinge. Bending latch fingers back and forth can overstress the metal and weaken the fingers. (00169a)**

1. Bend the fingers until they firmly engage the hinge.
2. See Miscellaneous Lubrication for lubrication details.



## Accessory Switch: FLHTCSE2

---

See Switch Indicators: FLHTCSE2. All touring models have an accessory switch (3) for the owner's use. This switch is located on the right side of the fairing.


See Accessory Connector. There is an accessory connector located under the seat that can be activated with the ACC switch. See a Harley-Davidson dealer for possible uses.

### CAUTION

**It is possible to overload your motorcycle's charging system by adding too many electrical accessories. If your combined electrical accessories operating at any one time**

consume more electrical current than your vehicle's charging system can produce, the electrical consumption can discharge the battery and cause vehicle electrical system damage. See a Harley-Davidson dealer for advice about the amount of current consumed by additional electrical accessories, or for necessary wiring changes.  
(00211b)


om00477



1. Auxiliary (SPOT)
2. Cruise control
3. ACC switch (ACCESSORY)

**Switch Indicators: FLHTCSE2**





Accessory Connector

## Auxiliary Lamps: FLHTCSE2

---

See Switch Indicators: FLHTCSE2. Use the auxiliary lamp switch (1) to turn ON the auxiliary lamps as required.

*NOTES:*

- *On the FLHTCSE2, the auxiliary lamp switch (SPOT) is on the left side of the ignition/headlamp key switch on fairing cap.*
- *The auxiliary lamps (SPOT) do not work when the headlamp is on high beam.*

## Fairing Lower Vents

---

See Fairing Lower Vent Control. Vents in fairing lowers are controlled by the lever shown. Adjust vent openings to control air flow.



## Passenger Footboards: FLHTCSE2

---

Passenger footboards can be adjusted to one of three positions. Before moving to a new position, remove plastic plugs from holes in rear swingarm brackets as necessary.

1. See Passenger Footboards: FLHTCSE2. Remove socket screw with lockwasher to remove footboard bracket from rear swingarm bracket.
2. Insert pin on footboard bracket into hole in swingarm bracket at position required.
3. Install socket screw with lockwasher. Tighten socket screw to 15-18 ft-lbs (20-24 Nm).



## Premium Sound System

### Premium Sound System: FLHTCSE2

---

This section will acquaint you with the premium sound system on your new Harley-Davidson motorcycle. The premium sound system consists of a radio frequency (AM, MW, LW, FM, and/or WB) stereo receiver that supports a compact disc (CD) player, an auxiliary (AUX) input and special features that will add to your enjoyment.

Since there are many unique aspects in this system, we recommend that you read this section to thoroughly understand its operation.

#### **⚠WARNING**

**Do not change compact discs while riding, and do not select a volume level that blocks out traffic noise. Distractions or a volume level that blocks out traffic noise, could cause loss of control resulting in death or serious injury. (00086a)**

#### **CAUTION**


**There are no serviceable parts inside the unit; leave all servicing to qualified service personnel. Disassembly of the unit could result in equipment damage and/or equipment malfunction. (00172a)**


#### **⚠WARNING**

**Do not disassemble unit. Laser radiation is present if disc player is disassembled and the interlock fails or is defeated. Exposure to laser radiation could lead to death or serious injury. (00087a)**

**⚠WARNING**

**Set intercom volume level and other controls before riding to minimize adjustments on the road. Distractions can lead to loss of control, resulting in death or serious injury. (00088a)**





## Stereo Receiver

---

For receiver frequency bands refer to Receiver Frequency Bands: 2005 FLHTCSE2 at the end of this section. The Harley-Davidson stereo receiver is a radio (3 band maximum) with a full function Compact Disc (CD) player and an auxiliary (AUX) input.

Receiver features include:

- Electronic single in-line CD player featuring track up/down, forward and reverse scan, and random play.
- Remotely located controls for tuning, band change/CD select, volume, and bass/treble/fader mixing.
- Electronic digital volume control.
- Automatic volume control (AVC) - automatically adjusts volume to compensate for ambient noise due to motorcycle speed. See Automatic Volume Control (AVC).
- Time-of-day clock.
- Weather band frequencies are displayed as NOAA channel numbers (active on North American units only).

## Sound System Front Panel Controls: FLHTCSE2

---

The front panel consists of a set of pushbuttons, a liquid crystal display, (LCD), a protective door for the Compact Disc (CD) slot and a covered input port for auxiliary (AUX) devices.

### 1

---

First (1) preset button is used to store and then recall a selected radio frequency.

### 2

---

2: Second (2) preset button is used to store and then recall a selected radio frequency.

### 3

---

3: Third (3) preset button is used to store and then recall a selected radio frequency.

## 4\*RND

---

4: Fourth (4) preset button is used to store and then recall a selected radio frequency.

RND: Random (RND) play button used to initiate random CD track play. See CD Operation.

## SE\*SC

---

Radio tuning seek (SE) or scan (SC) mode. Continue pressing the SE\*SC button stopping at the desired mode. The word SEEK appears in the LCD when the seek mode is selected. SCAN is displayed when the scan mode is selected. When SEEK and SCAN do not appear in the LCD, the receiver is in the MANUAL tuning mode. See Receiver Operation: FLHTCSE2.

## POWER

---

Power on and off. Press POWER to turn the receiver on and off.

## EJECT

---

CD eject button found under the CD cover. Press EJECT to eject the CD.

## LO\*DX

---

The two-position LO\*DX button alternates between local and distant. LO or DX is displayed in the LCD.

**LO:** The local (LO) position reduces the sensitivity of the receiver and can improve performance in urban areas.

**DX:** The distant (DX) position increases the sensitivity of the radio receiver to pick up weak signals. At times, this may mean more noise and unwanted signals. However, DX can improve performance in rural areas.

**LO\*DX Switch**

<b>LOCAL (LO)</b>	<b>DISTANCE (DX)</b>
Reduced sensitivity	Increased sensitivity
Strong signals	Weak signals
Less noise	More noise

## MIN

---

Time-of-day minutes (MIN) set button. With the radio POWER off, press MIN to increment the

minutes in the time-of-day display by one. Pressing and holding MIN will cause the minutes to continue to increment until MIN is released.

---

## **HRS**

Time-of-day hours (HRS) set button. With receiver POWER off, press HRS to increment the hours in the time-of-day display by one. Pressing and holding HRS will cause the hours to continue to increment until HRS is released.

---

## **LCD**

The operational status of the stereo receiver is displayed in a liquid crystal display (LCD).

---

## **CD Door**

The CD door is a spring-loaded cover and will stay open when exchanging CDs. To close the door, push the door down until it latches.

---

## **AUX**

Auxiliary (AUX) cover and input port connects the receiver to an auxiliary device such as a cassette or MP3 player.

See K in LCD Screen Examples: FLHTCSE2. Using a 1/8 in. (3.5 millimeter) male to male extension cord, plug the line out or headset out from the auxiliary device into the AUX port. AUX appears in the LCD as a mode selectable with the MODE SEL switch.

The user has control of volume, bass and treble and fader if so equipped but all other player functions are performed with the auxiliary device. The volume level of the AUX device must be set to normal or average.

*NOTE:*

*Close the protective cap whenever the AUX port is not in use.*

---

## **Sound System Left Handlebar Controls: FLHTCSE2**

---

### **+ /AUDIO/- Switch**

**AUDIO:** Press and hold the AUDIO switch for at least 0.5 seconds to access the audio menu on the LCD. The LCD indicates the function selected. Press and release AUDIO to toggle to the next function in sequence from VOLUME to BASS, TREBLE and then back to VOLUME.

If the AUDIO switch is left on any selection other than VOLUME, the function automatically reverts back to VOLUME after a period of approximately 2-3 seconds.

±: Pressing the AUDIO switch upward (+) raises the level for the currently selected AUDIO (volume, bass, or treble). Pressing the switch downward (-) lowers the level. The level is raised or lowered as long as the switch is held until the minimum or maximum level is reached.

See I and J in LCD Screen Examples: FLHTCSE2. The LCD displays a horizontal dashed line to indicate the level. In the center of the line is a single thin dash. When the level is at the center, the selected audio is at a mid-point of its range.

*NOTE:*

*Bass is rolled off as the volume is increased, so the effect of any change is less noticeable at higher volumes.*

## Sound System Right Handlebar Controls: FLHTCSE2

---

### UP/MODE and SEL/DN Switch

---

The mode select (MODE SEL) switch is located on the right handlebar switch assembly.

**MODE SEL:** With the radio POWER on, press and release the MODE SEL switch to sequence between the radio band modes.

When a CD is inserted into the CD player the CD function is added to the selections. When a 1/8 in. (3.5 mm) connector is plugged into the AUX input port the AUX function is added to the selections.

See LCD Screen Examples: FLHTCSE2. The front panel LCD indicates the function selected with the MODE SEL switch.

**UP/DN:** Allows up or down radio station tuning in Manual, SEEK and SCAN. In CD mode, changes tracks and performs fast advance and fast reverse.

For a detailed description of the various modes, see Receiver Operation: FLHTCSE2 and Automatic Volume Control (AVC).

**Mode Selections**

STYLE	DOMESTIC	INT.	JAPANESE
Default	AM	LW	MW
	FM1	MW	FM1
	FM2	FM1	FM2
	WB	FM2	
If present	CD	CD	CD
	AUX	AUX	AUX

## Receiver Operation: FLHTCSE2

---

See Premium Sound System: FLHTCSE2 for a picture of your receiver's front panel controls and hand controls.

### Setting Time-of-Day

---



The time-of-day is set with the Ignition/headlamp Key Switch to IGNITION or ACCESS but with the receiver off. See Turning Receiver Power On/Off which follows.

See D in LCD Screen Examples: FLHTCSE2. Press the hours (HRS) button on the receiver front panel to increment the hours in the display. Pressing and holding HRS will cause the hours to continue to increment until the button is released.

Press the minutes (MIN) button on the receiver front panel to increment the minutes in the display. Pressing and holding MIN will cause the minutes to continue to increment until the button is released.

## Turning Receiver Power On/Off

---

To turn the receiver on or off, turn the Ignition/headlamp Key Switch to IGNITION or ACCESS and press the POWER button on the front panel.

If the receiver is on when the ignition is turned OFF, the receiver will power up when the ignition/headlamp key switch is turned to IGNITION.

## Selecting a Frequency Band

---

See FLHTCSE2 Handlebar Audio Controls. Using the right thumb, press the mode sel switch on the right hand grip and release to cycle through the frequency bands.

Refer to Radio Frequency Bands. The LCD indicates the selected band.

Radio Frequency Bands

DOMESTIC	INT.	JAPANESE
AM	LW	MW
FM1	MW	FM1
FM2	FM1	FM2
WB	FM2	-

NOTE:

*Each band can store 4 preset frequencies. Separate FM1 and FM2 bands allow the rider to store 2 sets of 4 preset FM frequencies (8 total). The full range of FM frequencies can be selected in either FM1 or FM2. See Preset Memory/Tuning which follows.*

## Band Jump Feature

---

Band Jump allows you to switch between 2 bands without having to cycle through each band individually. Press and hold the MODE SEL switch for 1 second and the receiver will jump from the currently selected band to FM1. Press and hold the MODE SEL switch again and it will jump back to the originally selected band.

If a CD is inserted, Band Jump will allow you to jump between any previously selected band and CD instead of FM1.

## AM vs FM Reception

---

Commercial radio broadcasting is either AM (Amplitude Modulation) or FM (Frequency Modulation).

*NOTE:*

*Refer to AM Bands: 2005 FLHTCSE2. The long wave (LW) and medium wave (MW) bands found in International and Japanese versions of the Premium Sound System are also amplitude modulated bands.*

### AM

---

AM radio waves reflect off the ionosphere which results in consistent signal reception at a long range (up to 100 miles or 160 kilometers).

However, AM radio can be displaced by loud humming, popping and crackling noises. This is electrical interference caused by noise from vehicle ignitions, electric signs, power lines and electrical storms.

### FM

---

The advantages of FM radio are high fidelity sound, stereo reception, a wide range of broadcasting formats, and a signal that is free of electrical interference.

The disadvantage of FM radio is its short range. FM radio waves travel in straight lines, called "line-of-sight," therefore, FM signals cannot be received over the horizon. At the limit of a station's range, the reception may fade in and out when objects pass between the transmitter and the motorcycle.

### FM Stereo vs FM Mono

---

Normally, the Harley-Davidson Premium Sound System plays FM signals in stereo. The LCD will indicate ST.

However, the stereo receiver has circuits which eliminate or minimize FM flutter due to weak stereo signals. The circuits detect a weak FM stereo signal and automatically blend it into a stronger FM mono signal. The transition is smooth and flutter free because it occurs over a range of signal conditions, rather than at a minimum threshold.

When the system is automatically blending or is receiving an FM mono signal, the stereo indicator (ST) will disappear from LCD screen.

### Tuning-in a Radio Station

---

The radio has three tuning modes in each of the frequency bands: MANUAL, SEEK and SCAN.


With the receiver POWER on, press the seek or scan (SE\*SC) button on the front panel to sequence the tuning modes.

See C in LCD Screen Examples: FLHTCSE2. When neither SEEK nor SCAN appear in the LCD, the system is in the MANUAL mode.

See A in LCD Screen Examples: FLHTCSE2. The word SEEK appears in the LCD when the SEEK mode is selected.

See B in LCD Screen Examples: FLHTCSE2. SCAN is displayed when the SCAN mode is selected.

Tuning in all three modes continuously wraps around the ends of the band.



## Manual Tuning

---

See C in LCD Screen Examples: FLHTCSE2. Press the SE\*SC button on the front panel until neither SEEK nor SCAN appear in the LCD.

To manually tune the radio to a different frequency:

Press MODE SEL up (UP) to select the next highest frequency. Hold the switch UP, and after a short delay of 1.5 seconds, the radio will continue to change frequencies until the switch is released.

or

Press MODE SEL switch down (DN) to select the next lowest frequency. Hold the switch DN, and after a delay of 1.5 seconds, the radio will continue to change frequencies until the switch is released.

## Seek Tuning

---

In the SEEK mode, the radio tunes in to the next strong station.

See A in LCD Screen Examples: FLHTCSE2. Press the SE\*SC button until SEEK appears in the LCD.

Press the MODE SEL switch up (UP) to tune in the next strong station upward in the band. Press the switch down (DN) to tune in the next strong station downward in the band.

## SCAN Tuning

---

In the SCAN mode, the radio continuously tunes from one strong station to the next until the SCAN is cancelled.

See B in LCD Screen Examples: FLHTCSE2. Press the SE\*SC button until SCAN appears in the LCD.

Press the MODE SEL switch UP or DN to scan the band for strong station signals. Each strong station remains tuned in for 10 seconds before the radio moves to the next station.

To select a station, cancel SCAN while the radio is tuned to that station. Press the MODE SEL switch UP to cancel a SCAN moving up the band. Press the MODE SEL switch DN to cancel a SCAN moving down the band.

## Adjusting Volume

---

See FLHTCSE2 Handlebar Audio Controls. Volume is adjusted with the AUDIO switch on the left hand grip. Using left thumb, press the AUDIO switch up (+) to raise the volume or down (-) to lower the volume.

See N in LCD Screen Examples: FLHTCSE2. The LCD displays the word VOLUME and a dashed line that changes length with the volume. The thin center dash indicates a middle setting.

Five (5) seconds after the AUDIO switch is released, the display switches to the time-of-day.

*NOTE:*

*Bass is rolled off as the volume is increased, so the effect of any change is less noticeable at higher volume.*

## Preset Memory/Tuning

---

Use the preset buttons to store frequently tuned stations. Four station frequencies may be stored per band.

To store a current station, press and hold any one of the four preset buttons for 1.5 seconds. The audio will be muted. When the audio level returns, the station's frequency has been stored.

To tune to a stored station, press the same preset button.

*NOTE:*

*Separate FM1 and FM2 bands allow 2 sets of 4 preset FM frequencies (8 total) to be stored.*

## Mixing Bass and Treble

---

Bass and treble range adjustments can be applied to any Premium Sound System audio source.

**BASS:** Press and hold AUDIO to sequence to BASS. Using the left thumb, press the AUDIO switch up (+) to increase the bass range or down (-) to lower the bass range.

See I in LCD Screen Examples: FLHTCSE2. The LCD displays the word BASS and a dashed line that changes length with the setting. The thin center dash indicates a middle setting.

**TREBLE:** Press and hold AUDIO to sequence to TREBLE. Using the left thumb, press the AUDIO switch up (+) to increase the treble range or down (-) to lower the treble range.

See J in LCD Screen Examples: FLHTCSE2. The LCD displays the word TREBLE and a dashed line that changes length with the setting. The thin center dash indicates a middle setting.

## **Automatic Volume Control (AVC)**

---

### **General**

---

Automatic Volume Control (AVC) automatically adjusts volume level to compensate for ambient noise associated with motorcycle speed.

If the AVC does not adequately compensate for ambient noise (or if it overcompensates), enter the diagnostic screens.

Press and hold any two preset buttons on the front panel while turning the Ignition/Light Key Switch from OFF to IGNITION or ACCESS.

See Diagnostic Screen D1. Diagnostic group 1 (d1), the first of several diagnostic screens will appear in the LCD.

See AVC Adjustment Screen. Press the local/distant (LO\*DX) button to cycle through the diagnostic screens. Stop at the AVC adjustment screen. AVC is displayed in the upper portion of the display, while the AVC level appears in the lower portion.


- To ramp the AVC up, press the MODE SEL switch UP.
- To ramp the AVC down, press the switch DN.

*NOTE:*

*Although the factory presets the AVC level at 2, it is adjustable from 0 (off) to 4 (most compensating).*


After selecting an AVC level, repeatedly press the LO\*DX button until the receiver reverts back to normal radio operation.

om00300



Diagnostic Screen D1

om00301



1. AVC (automatic volume control)
2. AVC level

AVC Adjustment Screen

## AVC Model Year Selection

---


Earlier model year motorcycles use a different type of AVC signal. The 2005 radio can be set to accept either type of AVC signal.

Enter the diagnostic screens to select AVC model year. Press and hold any two preset buttons on the front panel while turning the ignition/light switch from OFF to IGNITION or ACCESS. Press the local/distant (LO-DX) button to cycle through the diagnostic screen. Stop at the AVC model year selection screen.

A scrolling message is displayed in the upper portion of the display, while the current AVC model year selection is displayed in the lower portion. The scrolling message says, "Press "1" for bikes before MY2004.....Press "2" for MY 2004 or later bikes". Your selection is displayed in the lower portion of the display by a "1" or a "2". See AVC Model Year Selection Screen.

*NOTE:*

*The radio retains the AVC model year selection, however if power is removed from the radio, AVC model year selection defaults to MY 2004 setting number 2.*



## CD Operation

---

**CAUTION**

**There are no serviceable parts inside the unit; leave all**

servicing to qualified service personnel. Disassembly of the unit could result in equipment damage and/or equipment malfunction. (00172a)

### **⚠WARNING**

Do not change compact discs while riding, and do not select a volume level that blocks out traffic noise. Distractions or a volume level that blocks out traffic noise, could cause loss of control resulting in death or serious injury. (00086a)

### **⚠WARNING**

Do not disassemble unit. Laser radiation is present if disc player is disassembled and the interlock fails or is defeated. Exposure to laser radiation could lead to death or serious injury. (00087a)

## **Auto Load**

---

With the receiver POWER on, raise the CD door and gently insert a CD, label side up, into the CD slot until the unit automatically pulls the CD into the player.

The receiver will automatically switch to CD operation. The CD track number and play time will appear in the LCD display. With a CD in the player, CD is added to the modes selectable with MODE SEL.

### **⚠WARNING**

Set intercom volume level and other controls before riding to minimize adjustments on the road. Distractions can lead to loss of control, resulting in death or serious injury. (00088a)

## **BAD DISC Error Message**

---

See BAD DISC Error Message. If the CD loaded into the CD player is damaged, of incorrect format, or if upside down, the LCD will display the BAD DISC error message.

Eject and replace the CD. See Recommendations for Handling CDs.



om00303

**bad disc**

**00**

**BAD DISC Error Message**

## CD Eject

---

### **⚠WARNING**

**Do not change compact discs while riding, and do not select a volume level that blocks out traffic noise. Distractions or a volume level that blocks out traffic noise, could cause loss of control resulting in death or serious injury. (00086a)**

Press the EJECT button found under the CD door to eject a CD. The CD will be partially ejected. Remove the CD. Close and latch the CD door.

The receiver will automatically return to the band and frequency playing when the CD was loaded and the CD mode is no longer selectable.

## Changing CD Tracks

---

To change CD tracks, use the right thumb and press the MODE SEL switch on the right hand grip. Press UP and release to select higher numbered tracks or press DN and release to select lower number tracks.

The track selection number will be displayed in the LCD.

*NOTE:*

*If the MODE SEL switch is pressed and held UP or DN longer than 1.5 seconds, the track selections will fast advance or reverse as long as the switch is held.*

See F in LCD Screen Examples: FLHTCSE2. CD track selection wraps around the first and last track.

## Repeating Tracks

---

To repeat a CD track while it is playing, press the MODE SEL switch DN and quickly release.

*NOTE:*

*If the play time has been less than 2 seconds, the previous track will be played.*

## Fast Advance and Reverse

---

To fast advance a track, press the MODE SEL switch UP and hold longer than 1.5 seconds. The current track will fast advance while the switch is pressed UP. The audio will advance to the subsequent track as long as the switch is held UP.

See F in LCD Screen Examples: FLHTCSE2. The play time display in the LCD will also fast advance.

To fast reverse a track, press MODE SEL DN and hold longer than 1.5 seconds. The current track will fast reverse while the switch is pressed DN.

The play time display in the LCD will also fast reverse.

## Random Play

---

To play CD tracks randomly, press the 4\*RND button on the front panel while in the CD mode. No selection is repeated until all other selections have been played.

*NOTE:*

*The 4\*RND button toggles between normal and random play. Press once for random play. Press a second time to return to normal play. Random can also be cancelled by pushing the MOD SEL switch up or down.*

See G in LCD Screen Examples: FLHTCSE2. RND will appear in the LCD.

## Recommendations for Handling CDs

---

- Use caution when handling a CD. Avoid touching the bottom (shiny) side.
- Store CDs in acrylic jewel cases to protect against dust, scratches, light, and changes in humidity. Store CDs in a cool dry place away from direct sunlight.
- Use commercially available cleaning tissue to clean the CDs. Never use solvents that can damage the CD.

**⚠ WARNING**

**Do not disassemble unit. Laser radiation is present if disc**

**player is disassembled and the interlock fails or is defeated. Exposure to laser radiation could lead to death or serious injury. (00087a)**

*NOTE:*

*A laser that cannot focus properly may cause skipping. A clouded lens can be caused by dirty CDs, dust, smoke, high humidity, and airborne particles may cause the laser lens to cloud. Operating the CD without allowing the motorcycle to warm up can also cause a CD to skip.*

Keep protective CD door closed at all times.

## **Sound System Troubleshooting: FLHTCSE2**

---

### **Operational Troubleshooting**

---


See the Touring Models Electrical Diagnostic Manual and FLHTCSE2 Service Supplement for all system diagnosis and electrical troubleshooting information.

#### **CAUTION**

**There are no serviceable parts inside the unit; leave all servicing to qualified service personnel. Disassembly of the unit could result in equipment damage and/or equipment malfunction. (00172a)**

#### **⚠WARNING**

**Do not disassemble unit. Laser radiation is present if disc player is disassembled and the interlock fails or is defeated. Exposure to laser radiation could lead to death or serious injury. (00087a)**



## Radio Fuses

If it is necessary to replace the radio fuses, follow the fuse replacement procedures in this manual or see your Harley-Davidson dealer for service.

See Radio Fuses: FLHTCSE2. Radio fuses are located in the fuse block under the left side cover.

- The 15 amp fuse (1) provides direct and continuous power to the radio memory and time-of-day clock, and when the internal relay is activated, feeds the main circuits of the radio as well.
- The 10 amp fuse (2) allows power to the radio through activation of an internal relay.
- The 15 amp fuse (3) provides power to the amplifier inside the radio.

Remove the radio fuses and inspect the element. Replace the fuse if the element is burned or broken. Automotive type ATO fuses are used.

*NOTE:*

*Spare fuses (10 amp and 15 amp) can be found in the fuse block cover.*

## Sound System Specifications: FLHTCSE2

**Speaker Output Power: 2005 FLHTCSE2**

TOTAL WATTS	SPEAKERS	OHMS PER SPEAKER
120	2 speakers, 60 watts each	4

**AM Bands: 2005 FLHTCSE2**

ITEM	DOMESTIC	INTERNATIONAL	
	AM BAND	MW	LW
Tuning range	530-1700 kHz	522-1629 kHz	155-281 kHz
20 dB S/N sensitivity	15 uV Typ.	15 uV Typ.	35 uV Typ.
Image rejection	55 dB minimum	55 dB minimum	55 dB minimum
If rejection	60 dB minimum	60 dB minimum	55 dB minimum
Bandwidth (-6 dB)	6 kHz (+4, -2)	6 kHz (+4, -2)	6 kHz (+4, -2)
Strong signal distortion	5 %	5 %	5 %
S/N ratio, large signal	45 dB minimum	45 dB minimum	40 dB minimum

**FM Bands: 2005 FLHTCSE2**

ITEM	DOMESTIC	DOMESTIC (WB)	INTERNATIONAL
Tuning range	88.1-107.9 MHz	162.400-162.550 MHz	87.5-108 MHz
Limiting sensitivity (3 dB)	1.8 uV Typ. @ 75 ohms	1.5 uV Typ. @ 75 ohms	1.8 uV Typ. @ 75 ohms
Quieting sensitivity (30 dB)	1.5 uV Typ. @ 75 ohms	1.5 uV Typ. @ 75 ohms	1.5 uV Typ. @ 75 ohms
Spurious signal rejection	75 dB minimum	60 dB minimum	75 dB minimum
Image rejection	50 dB minimum	35 dB minimum	50 dB minimum
IF rejection	75 dB	80 dB	75 dB
AFC PLL circuit	Receiver always on station frequency	Receiver always on station frequency	Receiver always on station frequency
Audio frequency response	30-15,000 Hz	550-1,700 Hz	30-15,000 Hz
Bass boost	11 DB @ 100 HZ		11 DB @ 100 HZ
Treble boost	10 dB @ 10 kHz		10 dB @ 10 kHz
Stereo separation	35 dB @ 1 kHz		35 dB @ 1 kHz
High blend separation	Less than 4 dB @ 10 uV		Less than 4 dB @ 10 uV

**Receiver Frequency Bands: 2005 FLHTCSE2**

MARKET	BAND	FREQUENCY	STEPS
Domestic	AM	530-1700 kHz	10 kHz
	FM	88.1-107.9 MHz	200 kHz
	WB	162.400-162.550 MHz	25 kHz
International	LW	155-281 kHz	9 kHz
	MW	522-1629 MHz	9 kHz
	FM	87.5-108 MHz	50 kHz

**CD Player: All Models**

SPECIFICATION	DATA
THD	0.2% nominal
S/N	85 dB nominal
Frequency response	20 Hz - 20 KHz
Digital filter	8x oversampling

**One Watt Distortion (1 kHz at Audio Output)**

SPECIFICATION	DATA
FM (input)	less than 0.5% THD
AM (input)	less than 0.5% THD
WB (input)	less than 2.0% THD

## H-D Factory Security System

### Basic Security System Operation

---

The security system provides security and immobilization functions. The security system will disable the starter and the ignition or EFI system. Additional functions include the ability to flash all four turn signals and sound a factory-installed siren if a theft attempt is detected.

Conditions that activate the security alarm when the system is armed include:

- Detecting vehicle movement.
- Detecting tampering of the ignition switch circuit.
- Detecting tampering of the security lamp circuit.
- Detecting that a battery disconnect has occurred while armed.

### Security System Options

---

The following configurations are available on the security system unit:

- Alarm sensitivity.

- Auto-arming feature.
- Storage mode.

Factory settings for the security system include:

- Medium motion alarm sensitivity.
- Key fob arming mode.
- Storage mode set to 20 days.

## FCC Regulations

---

This device complies with Part 15 of the FCC Rules and with RSS-210 of Industry Canada rules.

Operation is subject to the following conditions:

- This device may not cause harmful interference.
- This device must accept any interference received, including interference that may cause undesired operation.

## Arming The System

---

There are two methods to arm the security system:

- **Remote-arming:** See Key Fob. Owners may enable security alarm and immobilization functions with a remote, personally carried transmitter. This transmitter is referred to as a key fob within this document.
- **Auto-arming:** Arms the security system within 30 seconds after IGNITION switch is turned OFF. To enable auto-arming see Using Auto-arming below.

### NOTES:

- *The vehicle cannot be armed with the engine running or the ignition ON.*
- *International vehicles are configured for auto-arming. This cannot be changed.*

## Using Key Fob

---

See Key Fob. Hold down the key fob button until the system responds with two turn signal flashes and two chirps from optional siren. To assign a key fob to a motorcycle, refer to Key Fob Assignment.

## Using Auto-arming


---

Auto-arming causes the security system to automatically arm itself (without the use of the key fob) within 30 seconds after the ignition key is turned OFF. During this period, the security lamp stays on solid to indicate auto-arming is starting up.

The vehicle may be moved during these 30 seconds without triggering the alarm. However, any motion after that period will trigger the security alarm. Upon expiration of the auto-arming period, the turn signals flash twice, the security lamp begins to flash and the siren (if installed) chirps twice.

To set the auto-arming selection, refer to Auto-arming Configuration (Not Available on

International Vehicles).



## Disarming The System

---

There are two ways to disarm the system:

- **Remote disarming:** See Key Fob. Owners may disable security alarm and immobilization functions with a remote, personally carried transmitter. This transmitter is referred to as a key fob within this document.
- **Personal code:** If a key fob is not available, the security system allows the rider to disable the security alarm and immobilization functions if the rider knows the previously entered personal code.

*NOTE:*

*Do not forget to enter a personal code for security system vehicles. If a code is not assigned and the key fob is lost or damaged while the vehicle is armed, the security system module must be replaced. Refer to Programming a Personal Code for personal code setup.*

## Using Key Fob

---

See Key Fob. Quickly press the key fob button twice. The system will respond with one turn signal flash.

*NOTES:*

- **Disarming function may require practice.** The key fob button must be pressed twice within 1.5 seconds to send the disarm command. The action is very similar to double-



clicking a computer mouse. Light quick taps work best; very hard or very slow taps are less likely to work.

- If the system is remotely disarmed (with the key fob) but the ignition key is not turned ON within 30 seconds, the system will rearm itself when auto-arming is enabled.

## Using Personal Code

Enter the five digit personal code you have chosen using the left and right turn signal switches. For complete procedure refer to Entering a Personal Code to Disarm Security System. To create a personal code, refer to Programming a Personal Code.

NOTE:

If you make an error while disarming the security system using the personal code, the alarm will activate for 30 seconds after the last digit is entered. After a failed attempt, the security lamp will flash once every second for 10 minutes. During this time, the vehicle will not accept any attempt to enter a personal code.

### Entering a Personal Code to Disarm Security System

STEP NO.	ACTION	WAIT FOR CONFIRMATION	NOTES
<i>NOTE: The left turn signal switch is used for code number entry and the right turn signal is used as the "enter" key.</i>			
1	Know your 5 digit personal code		
2	Turn <b>IGN</b> key to <b>ACC</b>		
3	Hold <b>both</b> turn switches in until confirmation	Security lamp blinks at fast rate	
4	Enter first digit of code ( <b>a</b> ) by pressing <b>left</b> turn switch <b>a times</b>		
5	Press <b>right</b> turn switch <b>1 time</b>		Serves as enter key for first digit
6	Enter second digit of code ( <b>b</b> ) by pressing <b>left</b> turn switch <b>b times</b>		
7	Press <b>right</b> turn switch <b>1 time</b>		Serves as enter key for second digit
8	Enter third digit of code ( <b>c</b> ) by pressing <b>left</b> turn switch <b>c times</b>		
9	Press <b>right</b> turn switch <b>1 time</b>		Serves as enter key for third digit
10	Enter fourth digit of code ( <b>d</b> ) by pressing <b>left</b> turn switch <b>d times</b>		
11	Press <b>right</b> turn switch <b>1 time</b>		Serves as enter key for fourth digit
12	Enter fifth digit of code ( <b>e</b> ) by pressing <b>left</b> turn switch <b>e times</b>		
13	Press <b>right</b> turn switch <b>1 time</b>	Security lamp stops blinking	System is disarmed. You may use the vehicle or program another key fob.

## Security Status Lamp


---

See Security System Icon. A lamp within the speedometer face tells the rider if the system is armed or disarmed.

Refer to Security Lamp Status for an explanation of the lamp's activity.

**Security Lamp Status**

<b>SECURITY LAMP STATUS</b>	<b>MODE</b>
Does not flash.	No security system (TSSM), security system not armed or storage mode active.
Flashes every second.	10 minute time-out after failed personal code entry attempt.
Flashes every 2 seconds.	Security system armed.
Flashes 3 times a second.	Personal code entry mode.
Stays ON solid with ignition key OFF.	Auto-arming is started up. You have 30 seconds before system armed.
Stays ON solid with ignition key ON.	If solid for more than 8 seconds after key is ON, a current trouble code is present.



## Transport Mode

---

It is possible to arm the security system without enabling the motion detector for one ignition cycle. This allows the vehicle to be moved in an immobilized state for transport.

The transport mode is used for moving the vehicle or transporting on a trailer with the security system armed and without tripping the alarm. When the vehicle is in the transport mode, the security system does not respond to motion detection.

1. To exit the transport mode, use the key fob to disarm the vehicle.
2. To enter the transport mode, refer to Transport Mode.

NOTE:

*Transport mode is especially useful when working on international vehicles. If it is not used, the alarm will activate under many typical service activities.*

#### Transport Mode

STEP NO.	ACTION	WAIT FOR CONFIRMATION	NOTES
1	Turn <b>IGN</b> key <b>ON</b>		
2	Press and hold <b>key fob</b> button until confirmation is received	3 flashes turn signals & indicators	
3	Turn <b>IGN</b> key <b>OFF</b>		
4	Press and hold <b>key fob</b> button until confirmation is received	3 flashes turn signals & indicators	The vehicle can be moved without tripping the alarm

## Security System Custom Setup

---

### Key Fob Assignment

---

The key fob on security system motorcycles must be set so it will operate the alarm system on the vehicle. This assignment must be completed with no pauses greater than 10 seconds between steps. Turn the ignition OFF after both key fobs have been assigned. The programming mode will also exit after 60 seconds has elapsed without detecting any key fob sign up messages or turn signal activity.

### Procedure

---

To assign a key fob to a motorcycle, refer to Key Fob Assignment.

Two key fobs may be assigned to the security system. The first successful attempt to program a key fob will disable all previously assigned key fobs. If a second key fob is to be programmed, it must be done in the same programming sequence as the initial key fob.

#### Key Fob Assignment

STEP NO.	ACTION	WAIT FOR CONFIRMATION	NOTES
1	Turn <b>IGN</b> key <b>ON-OFF-ON-OFF-ON</b>		
2	Press <b>left</b> turn switch <b>2 times</b> and release	2-3 flashes turn signals & indicators depending on vehicle configuration  (See BATTERY DISCONNECTS AND CONFIGURING section)	2 flashes - North American/Domestic configuration security system  3 flashes - international configuration security system
3	Press <b>right</b> turn switch <b>1 time</b> and release	1 flash turn signals & indicators	
4	Press <b>left</b> turn switch <b>1 time</b> and release	2 flashes turn signals & indicators	
5	Press and hold <b>key fob</b> button until confirmation is received	2 flashes turn signals & indicators	This may take 10-25 seconds
6	If you have two key fobs, press and hold button on second <b>key fob</b> until confirmation is received	2 flashes turn signals & indicators	Optional step
7	Turn <b>IGN</b> key OFF		

## Personal Code

---

### Creating Code for the First Time

---

The personal code consists of five digits entered using the left and right turn signal switches. Each digit can be any number from 1-9. The personal code is intended to be used to disarm the vehicle in case the key fob is not functioning.

Record your personal code on the card(s) provided in the rear of the Owner's Manual. Carry one for reference in your wallet when riding.

To set a personal code on a motorcycle with no code previously installed, refer to Programming a Personal Code. The procedure listed uses 3-1-3-1-3 as the sample personal code.

*NOTE:*

*For better security, do not use 3-1-3-1-3 as a personal code. It is shown as an example only.*

Decide what five digit code the owner would like to use. The code will be programmed using the turn signal switches and key fob. Record your personal code on the card(s) provided in the rear of the Owner's Manual. Carry one for reference in your wallet when riding.

- When programming the personal code, the security lamp flashes to provide feedback when entering each digit.
- The number of security lamp flashes corresponds to the number currently selected for a

- given digit. Therefore, the lamp may flash 1-9 times depending on the number entered.
- Press the left turn switch one time to increment each digit of the code.
  - Quickly press the key fob button twice to advance to the next digit of the code.

*NOTE:*

*The programming mode exits upon turning the key switch to OFF or if no turn signal switch/key fob button activity occurs for 60 seconds. No data is saved for partial configuration attempts of a first time entry.*

## **Modifying Existing Codes**

---

If a code was previously entered, the lamp will flash the equivalent digit. Each additional press of the left turn switch will increment the digit.

- To advance from 5 to 6, press and release the left turn switch 1 time.
- To advance from 8 to 2, press and release the left turn switch 3 times (9-1-2).

**Programming a Personal Code**

STEP NO.	ACTION	WAIT FOR CONFIRMATION	NOTES
<i>NOTE: For better security, do not use 3-1-3-1-3 as a personal code. It is shown as an example only.</i>			
1	Set <b>RUN/OFF</b> switch to <b>OFF</b>		Verify that security lamp is <b>not</b> blinking (vehicle is disarmed)
2	Turn <b>IGN</b> key <b>ON-OFF-ON-OFF-ON</b>		
3	Press <b>left</b> turn switch <b>2 times</b> and release	1-3 flashes turn signals & indicators depending on vehicle configuration  (See BATTERY DISCONNECTS AND CONFIGURING section)	1 flash - Worldwide TSSM, no security  2 flashes - North American/Domestic configuration security system  3 flashes - international configuration security system
4	Quickly press <b>key fob</b> button <b>2 times</b> and release	1 flash turn signals & indicators	Vehicle is in personal code entry mode
5	Press <b>left</b> turn switch <b>1 time</b> and release	None if no code entered  1-9 flashes if code previously entered	A lack of confirmation flashes indicates no digit is entered
6	In this example, you will press and release three times  If code previously entered, count flashes for number and then press and release <b>left</b> turn switch to advance through the digits	Security lamp flashes to indicate each digit selected  Digit will display on odometer  In this example, the lamp will flash 3 times	You've selected 3 as a number for the first digit
7	Quickly press <b>key fob</b> button <b>2 times</b> and release	2 flashes turn signals & indicators	You've confirmed 3 as a number for the first digit and have advanced to entering the second digit
8	Press <b>left</b> turn switch <b>1 time</b> and release	None if no code entered  1-9 flashes if code previously entered	A lack of confirmation flashes indicates no digit is entered
9	In this example, you will perform this step one time  If code previously entered, count flashes for number and then press and release <b>left</b> turn switch to	Security lamp flashes to indicate each digit selected  Digit will display on odometer	You've selected 1 as a number for the second digit

	advance through the digits	In this example, the lamp will flash 1 time	
10	Quickly press <b>key fob</b> button <b>2 times</b> and release	3 flashes turn signals & indicators	You've confirmed 1 as a number for the second digit and have advanced to entering the third digit
11	Press <b>left</b> turn switch <b>1 time</b> and release	None if no code entered 1-9 flashes if code previously entered	A lack of confirmation flashes indicates no digit is entered
12	In this example, you will repeat this step three times  If code previously entered, count flashes for number and then press and release <b>left</b> turn switch to advance through the digits	Security lamp flashes to indicate each digit selected  Digit will display on odometer  In this example, the lamp will flash 3 times	You've selected 3 as a number for the third digit
13	Quickly press <b>key fob</b> button <b>2 times</b> and release	4 flashes turn signals & indicators	You've confirmed 3 as a number for the third digit and have advanced to entering the fourth digit
14	Press <b>left</b> turn switch <b>1 time</b> and release	None if no code entered 1-9 flashes if code previously entered	A lack of confirmation flashes indicates no digit is entered
15	In this example, you will perform this step one time  If code previously entered, count flashes for number and then press and release <b>left</b> turn switch to advance through the digits	Security lamp flashes to indicate each digit selected  Digit will display on odometer  In this example, the lamp will flash 1 time	You've selected 1 as a number for the fourth digit
16	Quickly press <b>key fob</b> button <b>2 times</b> and release	5 flashes turn signals & indicators	You've confirmed 1 as a number for the fourth digit and have advanced to entering the fifth digit
17	Press <b>left</b> turn switch <b>1 time</b> and release	None if no code entered 1-9 flashes if code previously entered	A lack of confirmation flashes indicates no digit is entered
18	In this example, you will repeat this step three times  If code previously entered, count	Security lamp flashes to indicate each digit selected	You've selected 3 as a number for the fifth digit

	flashes for number and then press and release <b>left</b> turn switch to advance through the digits	Digit will display on odometer  In this example, the lamp will flash 3 times	
19	Quickly press <b>key fob</b> button <b>2 times</b> and release	1 flashes turn signals & indicators	You've confirmed 3 as a number for the fifth digit and have gone back to the first digit
20	Turn <b>IGN</b> key OFF		
21	Write down code in owner's manual		
22	Arm the security system and attempt to disarm using personal code entry		

## Enable Auto-arming Selection

---

The security system allows remote arming via the key fob at anytime. However, if the system is remotely disarmed (with the key fob) but the ignition key is not turned ON within 30 seconds, the system will rearm itself when auto-arming is enabled.

To set the auto-arming selection, refer to Auto-arming Configuration (Not Available on International Vehicles).

*NOTE:*

*Auto-arming configuration cannot be altered on international vehicles.*

**Auto-arming Configuration (Not Available on International Vehicles)**



STEP NO.	ACTION	WAIT FOR CONFIRMATION	NOTES
1	Turn <b>IGN</b> key <b>ON-OFF-ON-OFF-ON</b>		
2	Press <b>left</b> turn switch <b>2 times</b> and release	2 or 3 flashes turn signals & indicators depending on vehicle configuration  (See BATTERY DISCONNECTS AND CONFIGURING section)	2 flashes - North American/Domestic configuration security system  3 flashes - international configuration security system
3	Press and hold <b>key fob</b> button until confirmation is received	1 flash turn signals & indicators	
4	Press and hold <b>key fob</b> button until confirmation is received	2 flashes turn signals & indicators	
5	Press <b>left</b> turn switch <b>1 time</b> and release	Turn signals & indicators flash to indicate the current option selected	1 flash - auto-arming disabled  2 flashes - auto-arming enabled
6	Press and release <b>left</b> turn switch to advance through options	Turn signals & indicators flash to indicate the new option selected	1 flash - auto-arming disabled  2 flashes - auto-arming enabled
7	Turn <b>IGN</b> key OFF		

## Alarm Sensitivity

---

The tamper warning has four sensitivity settings:

- Extremely low.
- Low.
- Medium.
- High.

The selection chosen controls the sensitivity of the security system in regard to short disturbances of the vehicle (i.e. someone bumps into the vehicle).

To set alarm sensitivity, refer to Alarm Sensitivity Adjustment.

### Alarm Sensitivity Adjustment

STEP NO.	ACTION	WAIT FOR CONFIRMATION	NOTES
1	Turn <b>IGN</b> key <b>ON-OFF-ON-OFF-ON</b>		
2	Press <b>left</b> turn switch <b>2 times</b> and release	2 or 3 flashes turn signals & indicators depending on vehicle configuration  (See BATTERY DISCONNECTS AND CONFIGURING section)	2 flashes - North American/Domestic configuration security system  3 flashes - international configuration security system
3	Press and hold <b>key fob</b> button until confirmation is received	1 flash turn signals & indicators	
4	Press <b>left</b> turn switch <b>1 time</b> and release	Turn signals & indicators flash to indicate the current option selected	1 flash - extremely low  2 flashes - low sensitivity  3 flashes - medium sensitivity  4 flashes - high sensitivity
5	Press and release <b>left</b> turn switch to advance through options	Turn signals & indicators flash to indicate the new option selected	1 flash - extremely low  2 flashes - low sensitivity  3 flashes - medium sensitivity  4 flashes - high sensitivity
6	Turn <b>IGN</b> key OFF		

## Storage Mode Configuration

The security system has a special mode for long term storage. This mode prevents the security system from discharging the battery after a period of days without any ignition key switch activity. Refer to Storage Mode Options.

- If the security system is set to infinite, the system will not go into storage mode. In this case, the customer must use a trickle charger to keep the battery from discharging after 60 days of storage.
- Vehicles will enter storage mode whether the security system is armed or disarmed.

In storage mode, all alarm functions are suspended and the receiver is shut down and will not respond to the key fob. The vehicle is immobilized because the starter motor and Ignition/EFI controllers are disabled. When the storage mode is entered, the security lamp stops flashing to conserve power.

To wake up the security system from storage mode, the ignition key must be turned ON. This will trigger the alarm if the system was previously armed. You must use the key fob or personal code

to disarm the system and stop the alarm.

If the ignition is switched from ON-OFF quickly, then the security system will wake-up without activating the alarm.

To set the storage mode preferences, refer to Storage Mode Configuration.

**Storage Mode Options**

<b>FLASHES</b>	<b>TIME</b>
1 flash	20 days (factory settings)
2 flashes	60 days
3 flashes	90 days
4 flashes	infinite

**Storage Mode Configuration**

<b>STEP NO.</b>	<b>ACTION</b>	<b>WAIT FOR CONFIRMATION</b>	<b>NOTES</b>
1	Turn <b>IGN</b> key <b>ON-OFF-ON-OFF-ON</b>		
2	Press <b>left</b> turn switch <b>2 times</b> and release	2 or 3 flashes turn signals & indicators depending on vehicle configuration  (See BATTERY DISCONNECTS AND CONFIGURING section)	2 flashes - North American/Domestic configuration security system  3 flashes - international configuration security system
3	Press and hold <b>key fob</b> button until confirmation is received	1 flash turn signals & indicators	
4	Release and then hold <b>key fob</b> button until confirmation is received	2 flashes turn signals & indicators	
5	Release and then hold <b>key fob</b> button until confirmation is received	3 flashes turn signals & indicators	
6	Press <b>left</b> turn switch <b>1 time</b> and release	Turn signals & indicators flash to indicate the current option selected	see Storage Mode Options table
7	Press <b>left</b> turn switch to advance through options	Turn signals & indicators flash to indicate the new option selected	see Storage Mode Options table
8	Turn <b>IGN</b> key OFF		

## Security System Maintenance

---

### Key Fob Battery Replacement

---


Replace the key fob battery every 2 years.

1. See Key Fob Open Case: Front. Place a thin blade between the 2 halves of the key fob case and slowly turn to open.
2. See Key Fob Battery Replacement. Remove the old battery and discard.


*NOTE:*

*Dispose of old battery in accordance with local regulations.*

3. Install a new battery (Panasonic® 2032 or equivalent) with the positive (+) side down.
4. Verify the button rubber is fully seated.
5. Close the case by aligning the two halves and snap together.
6. While standing next to the motorcycle, press and hold the key fob button for 10-15 seconds until the security system responds with two turn signal flashes/siren chirps.



om00101



1. Battery
2. Battery contact
3. Circuit board

**Key Fob Battery Replacement**

## Disabling the System

---

Disarm the security system using the key fob or personal code. At this point, the security fuse may be removed or battery disconnected.

## Battery Disconnects and Configuring

---

After reconnecting a battery, the security system will not enter the configuration mode on the first attempt. Therefore, after all battery reconnects, the configuration sequence must be modified as follows.

1. Set run switch to **OFF**, cycle ignition key **ON-OFF-ON-OFF-ON** and press left turn signal switch twice.
2. Wait for one to three confirmation flashes of the turn signals and then set ignition key switch to **OFF**.
3. Repeat steps listed above.
4. Continue with configuration sequence listed.

## Troubleshooting the Security System

---


If the key fob button has been pressed numerous times while away from the vehicle, the key fob may fall out of synchronization with the security system. If this happens, the security system might fail to recognize the key fobs commands.

To solve this problem, press and hold the key fob button for 10-15 seconds until the security system responds with two turn signal flashes. After confirmation, you may resume normal key fob operation.

## Siren Diagnostics

---

- See Siren. If the siren is armed and the internal siren battery is dead, shorted, disconnected, or has been charging for a period longer than 24 hours, the siren will respond with three chirps on arming instead of two.
- The internal siren battery may not charge if the vehicle's battery is less than 12.5 volts.
- If the siren does not chirp two or three times on a valid arming command from the security system, the siren is either not connected, not working, or the siren wiring was opened or shorted while the siren was disarmed.
- If the siren enters the self-driven mode where it is powered from the siren internal 9 volt battery, the turn signal lamps may or may not alternately flash. If the security system activates the siren, the turn signal lamps will alternately flash. If the siren has been armed and a security event occurs, and the siren is in self-driven mode, the siren will alarm for 20 to 30 seconds and then turn off for 5 to 10 seconds. This alarm cycle will be repeated ten times if the siren is in the self-driven mode.



### Operation

#### Operating Recommendations: Touring Models

---

#### **CAUTION**

**Do not run the engine at extremely high RPM with clutch disengaged or transmission in neutral. Running an engine at high RPM can result in engine damage. (00177a)**

- The maximum recommended safe engine speed is 5500 RPM.
- Do not idle engine unnecessarily for more than a few minutes with motorcycle standing still.

### CAUTION

**Do not exceed the maximum safe RPM specified below under any conditions. Exceeding the maximum safe engine RPM can result in equipment damage. (00248a)**

*NOTE:*

*The maximum recommended engine speed for FLT/FLH model motorcycles is 5500 RPM.*

### CAUTION

**Air-cooled engines require air movement over the cylinders and heads to maintain proper operating temperature. Extended periods of idling or parade duty can overheat the engine, resulting in serious engine damage. (00178a)**

An engine running long distances at high speed must be given closer than ordinary attention to avoid overheating and possible engine damage.

This applies particularly to a motorcycle equipped with windshield and fairing.

*NOTE:*

*Have the engine checked regularly and keep it well tuned.*

### ⚠WARNING

**When riding on wet roads, brake efficiency and traction are greatly reduced. Failure to use care when braking, accelerating or turning on wet roads can cause loss of control, which could result in death or serious injury. (00041a)**

*NOTE:*

*When descending upon a long, steep grade, downshift and use engine compression together with intermittent application of both brakes to slow the motorcycle.*

### ⚠WARNING

**Continuous use of brake causes overheating and reduced efficiency, which could result in death or serious injury. (00042a)**

### CAUTION

**Do not coast for long distances with the engine off. The transmission is properly lubricated only when the engine**

is running. Coasting long distances can result in transmission damage. (00180a)

**⚠WARNING**

Do not tow a disabled motorcycle. Towing can adversely affect stability and handling, which could result in death or serious injury. (00017a)

## Break-in Riding Rules

---

### The First 500 Miles (800 Kilometers)

---

The sound design, quality materials and workmanship that are built into your new Harley-Davidson will give you optimum performance right from the start.

To allow your engine to seat in its critical parts we recommend for the first 500 miles (800 kilometers) you observe the riding rules provided below. Adherence to these recommendations will help to assure good future durability and performance.

1. While riding the first 50 miles (80 kilometers) avoid operating at any steady engine speed for long distances. Keep the engine speed below 3000 RPM in any gear. Do not lug the engine in higher gears by running or accelerating at very low RPM. Do not exceed speed for each gear as noted in Break-in Speeds: 0-50 Miles (0-80 Kilometers).
2. Up to 500 miles (800 kilometers), avoid operating at any steady engine speed for long distances. Engine speed up to 3500 RPM in any gear is permissible. Do not exceed speed for each gear as noted in Break-in Speeds: 50-500 Miles (80-800 Kilometers).
3. Avoid fast starts at wide open throttle. Drive slowly until the engine has warmed up.
4. Avoid hard braking. New brakes need to be broken-in by moderate use for the first 200 miles (300 kilometers).

**Break-in Speeds: 0-50 Miles (0-80 Kilometers)**

SPEED	GEAR				
	1st	2nd	3rd	4th	5th
MPH	22	32	45	57	70
KPH	35	51	72	92	113

**Break-in Speeds: 50-500 Miles (80-800 Kilometers)**

SPEED	GEAR				
	1st	2nd	3rd	4th	5th
MPH	25	37	52	66	80
KPH	40	60	84	106	129



## Pre-Riding Checklist

---

### **⚠WARNING**

**Read the CONTROLS AND INDICATORS section before riding your motorcycle. Failure to understand the operation of the motorcycle could result in death or serious injury. (00043a)**

Before riding your motorcycle at any time, make a general inspection to be sure it is in safe riding condition.

### **⚠WARNING**

**Stop the engine when refueling or servicing the fuel system. Do not smoke or allow open flame or sparks near gasoline. Gasoline is extremely flammable and highly explosive, which could result in death or serious injury. (00002a)**

### **⚠WARNING**

**Avoid spills. Slowly remove filler cap. Do not fill above bottom of filler neck insert, leaving air space for fuel expansion. Secure filler cap after refueling. Gasoline is extremely flammable and highly explosive, which could result in death or serious injury. (00028a)**

### **⚠WARNING**

**Use care when refueling. Pressurized air in fuel tank can force gasoline to escape through filler tube. Gasoline is extremely flammable and highly explosive, which could result in death or serious injury. (00029a)**

1. Verify fuel is present in tank and add fuel if required.
2. Adjust mirrors to proper riding positions.
3. Verify oil is present in oil tank.
4. Check controls to make sure they operate properly. Operate the front and rear brakes, throttle, clutch and shifter. All controls should operate freely without binding.
5. Check steering for proper operation by turning the handlebars through the full operating range. Handlebars should turn smoothly without binding.

### **⚠WARNING**

**Be sure tires are properly inflated, balanced and have adequate tread. Inspect your tires regularly and see a Harley-Davidson dealer for replacements. Riding with excessively worn, unbalanced or under-inflated tires can adversely affect stability and handling, which could result in death or serious injury. (00014a)**

6. Check tire condition and pressure. Incorrect pressure will result in poor riding characteristics and can affect handling and stability. Refer to tire specifications for correct inflation pressure to use.
7. Check all electrical equipment and switches including the headlamp, stop lamp, turn signals and horn for proper operation.
8. Check for any fuel, oil or hydraulic fluid leaks.
9. Check secondary belt for wear or damage.
10. Service your motorcycle as necessary.

## **Starting the Engine: EFI Models**

---

### **General**

---

#### **CAUTION**

**The engine should be allowed to run slowly for 15-30 seconds. This will allow the engine to warm up and let oil reach all surfaces needing lubrication. Failure to comply can result in engine damage. (00181a)**

There are some differences between a carbureted Harley-Davidson and a fuel injected Harley-Davidson. The sequential port fuel injection system simplifies the starting procedure, compared to carbureted Harley-Davidsons.

Do not roll the throttle before starting. Rolling the throttle before starting the motorcycle is unnecessary.

There is no choke or enrichener or fuel supply valve on a fuel injected Harley-Davidson. The engine management system handles starting and running the engine at all temperatures and conditions.

### **Starting**

---

#### **⚠WARNING**

**Shift transmission to neutral before starting engine to prevent accidental movement, which could result in death or serious injury. (00044a)**

1. Turn ignition/headlamp key switch to IGNITION position. Do not roll the throttle.


*NOTE:*

*The engine lamp will light for approximately 4 seconds and you will hear the fuel pump purr for approximately 2 seconds as it operates to fill the fuel lines with gasoline.*

2. See Right Handlebar Controls: FLHTCSE2. Turn the off/run switch to RUN position.
3. Press the starter button to start the motorcycle.
4. When the engine has started, you can operate your motorcycle as you normally would after raising the jiffy stand.

*NOTE:*

*If the fuel tank becomes completely dry, it may take a few seconds longer to start the motorcycle after filling the tank. It will not be necessary to take any extraordinary measures before starting the motorcycle.*



## **EFI Engine Heat Management**

---

### **Injected Twin Cam High Temperature Idle**

---

Fuel injected Twin Cam engines use a three phase heat management system to reduce engine temperature under extreme conditions. A rider with a very hot engine may notice the affects of this

three phase heat management system and incorrectly assume an idle problem exists.

- **Phase 1:** When the engine temperature sensor signals that the cylinder head has reached approximately 320° F (160° C) the ECM will gradually reduce engine idle speed until the engine temperature drops or the engine reaches 800 RPM.
- **Phase 2:** If engine temperature reaches 338° F (170° C), the ECM richens the air/fuel ratio to provide additional cooling.
- **Phase 3:** If the engine temperature reaches 356° F (180° C), fuel injector pulses are interrupted. The air drawn in and expelled helps cool the engine further. Since there is no combustion it would be perceived as a misfire. This third stage will only happen when the motorcycle is stationary.

## Stopping The Engine

---

1. Stop the engine by turning OFF the engine stop switch on the right handlebar.
2. Turn OFF the ignition/headlamp key switch. If the engine should be stalled or stopped in any way, turn off the ignition/headlamp key switch at once to prevent battery discharge.

## Shifting Gears

---

## Getting Started

---

### CAUTION

**The clutch must be fully disengaged before attempting a gear shift. Failure to fully disengage the clutch can result in equipment damage. (00182a)**

Gear shift pattern is first gear down, next four gears up.

*NOTE:*

*Always start engine with transmission in neutral. Always start motorcycle forward motion from first gear.*

1. With motorcycle engine running and jiffy stand retracted, pull the clutch hand lever in against handlebar grip to fully disengage clutch.
2. Push the foot shift lever down to end of its travel and release. The transmission is now in first gear.
3. To start forward motion, release the clutch lever slowly to engage the clutch and at the same time, open throttle gradually.

## Upshift (Acceleration)

---

Refer to Upshift (Acceleration) Gear Speeds. Engage second gear after the motorcycle has reached at the appropriate shifting speed.

**Upshift (Acceleration) Gear Speeds**

GEAR CHANGE	MPH	KPH
First to second	15	25
Second to third	25	40
Third to fourth	35	55
Fourth to fifth	45	70

1. Close the throttle.
2. Disengage the clutch (pull clutch lever in).
3. See Shifting Sequence: Upshift. Lift the gear shift lever up to the end of its travel and release.
4. Engage the clutch (release clutch lever) and gradually open the throttle.
5. Repeat the previous steps to engage third, fourth, and fifth gears.

*NOTES:*

- *Disengage the clutch completely before each gear change.*
- *Partially close the throttle so the engine will not drag when clutch is again engaged (clutch lever released).*

## Downshift (Deceleration)

### ⚠WARNING

**Do not downshift at speeds higher than those listed in the Changing Gear Speeds table. Shifting to lower gears when speed is too high can cause the rear wheel to lose traction and lead to loss of vehicle control, which could result in death or serious injury. (00045a)**

Gear shift pattern is first gear down; next four gears up. Refer to Downshift (Deceleration) Gear Speeds for shifting speeds.

**Downshift (Deceleration) Gear Speeds**

GEAR CHANGE	MPH	KPH
Fifth to fourth	40	65
Fourth to third	30	50
Third to second	20	30
Second to first	10	15

*NOTE:*

*The shifting points shown in the tables constitute a recommendation. Vehicle owners may determine that their own individual shifting patterns may differ than those stated and are*

additionally appropriate for individual riding styles.

See Shifting Sequence: Downshift. When engine speed decreases, as in climbing a hill or running at a reduced speed, shift to the next lower gear while partially closing the throttle so the engine accelerates as soon as the clutch lever is released.


NOTES:

- *Disengage the clutch completely before each gear change.*
- *Partially close the throttle so the engine will not drag when clutch is again engaged (clutch lever released).*


### CAUTION

**Shift to neutral before stopping engine. Shifting mechanism can be damaged by shifting gears while engine is stopped. (00183a)**

The gear shifter mechanism permits shifting the transmission to neutral from either first or second gear.



om00014



Shifting Sequence: Downshift

## Maintenance and Lubrication

### Safe Operating Maintenance

#### ⚠WARNING

**Perform the service and maintenance operations as indicated in the regular service interval table. Lack of regular maintenance at the recommended intervals can affect the safe operation of your motorcycle, which could result in death or serious injury. (00010a)**

Good maintenance creates a safe motorcycle. A careful check of certain equipment must be made after periods of storage. Also, frequently inspect the motorcycle between the regular service intervals to determine if additional maintenance is necessary.

Check the following items:

1. Tires for correct pressure, abrasions or cuts.
2. Belt and primary chain for proper tension, wear or damage.
3. Brakes, steering and throttle for responsiveness and freedom from binding.
4. Brake fluid level and condition. Hydraulic lines and fittings for leaks. Also, check brake pads and discs for wear.
5. Cables for fraying or crimping and free operation.
6. Engine oil and primary chaincase/transmission fluid levels.

7. Headlamp, tail lamp, brake lamp and turn signals for proper operation.

NOTE:

Refer to the side view photographs in the front of this manual to locate the items discussed in this section.

## Break-in Maintenance

---

NOTE:

The performance of new motorcycle initial service is required to keep your new motorcycle warranty in force and to assure proper emissions system operation.

Refer to Regular Service Intervals: 2005 FLHTCSE2. After a new motorcycle has been ridden its first 1000 miles (1600 kilometers), it should be taken to the dealer from whom it was purchased for initial service operations.

## Engine Lubrication: Synthetic Oil

---

Engine oil is a major factor in the performance and service life of the engine. Always use the proper grade of oil for the lowest temperature expected before the next scheduled oil change. Your authorized dealer has the proper oil to suit your requirements.

Your motorcycle comes equipped with Screamin' Eagle SYN3 Synthetic Motorcycle Lubricant. If SYN3 is not available and addition of motor oil is required, the first choice would be to add H-D 360 SAE 20W50 to the SYN3 for engine lubrication. Although H-D 360 is compatible with SYN3, we suggest the mixture of the fluids be changed as soon as possible.

If H-D 360 is not available, the second choice would be to add an acceptable diesel engine oil. We again suggest the mixture of the fluids be changed as soon as possible. DO NOT add diesel engine oil to the primary chaincase or transmission.

To switch lubricant to H-D 360, completely drain the SYN3 before filling with H-D 360. A residual amount of fluid will remain. It is not required to flush out the residual fluid.

### CAUTION

**Do not switch lubricant brands indiscriminately because some lubricants interact chemically when mixed. Use of inferior lubricants can damage the engine. (00184a)**

Refer to Recommended Synthetic Engine Oils. If it is necessary to add oil and Screamin' Eagle SYN3 Synthetic Motorcycle Lubricant is not available, use an oil certified for diesel engines. Acceptable diesel engine oil designations include: CF-4, CG-4, CH-4 and CI-4.

The preferred viscosities for the diesel engine oils in descending order are: 20W50, 15W40 and 10W40.

At the first opportunity, see an authorized dealer to change back to 100 percent Harley-Davidson oil.



H-D TYPE	VISCOSITY	H-D RATING	LOWEST AMBIENT TEMPERATURE	COLD WEATHER STARTS BELOW 50 F (10 C)
Screamin' Eagle SYN3 Synthetic Motorcycle Lubricant	SAE 20W50	HD 360	Above 40 F (4 C)	Excellent
H-D Multi-grade	SAE 10W40	HD 360	Below 40 F (4 C)	Excellent
H-D Multi-grade	SAE 20W50	HD 360	Above 40 F (4 C)	Good
H-D Regular Heavy	SAE 50	HD 360	Above 60 F (16 C)	Poor
H-D Extra Heavy	SAE 60	HD 360	Above 80 F (27 C)	Poor

## Oil Cooler: FLHTCSE2

---

Your motorcycle comes with a factory installed oil cooler. Always keep the cooler clean and free from dirt and debris. This will help maintain maximum cooling efficiency.

## Checking Oil Level: Touring Models


---

### CAUTION

**Oil level cannot be accurately measured on a cold engine. For pre-ride inspection, with motorcycle leaning on jiffy stand on level ground, oil should register on dipstick between arrows when engine is cold. Do not add oil to bring the level to the FULL mark on a COLD engine. (00185a)**

For dipstick location, see Oil Dipstick Location: Touring Models.

om00309



## Oil Level Cold Check

---

Perform engine oil level **COLD CHECK** as follows:

1. See Engine Oil Level: Touring Models. For preride inspection with the vehicle resting on the jiffy stand on level ground, wipe off the dipstick. Insert it back into the oil pan with the plug pushed completely into the fill spout.
2. Remove the dipstick and verify the level of the oil. The correct oil level should register between the two marks on the dipstick.

*NOTE:*

*If oil level is at or below the lower arrow, add only enough oil to bring the level to the middle of the two marks on the dipstick.*

## Oil Level Hot Check

---

Perform engine oil level **HOT CHECK** as follows:

1. Ride motorcycle until engine is at normal operating temperature.
2. With the vehicle resting on the jiffy stand on level ground, allow engine to idle for 1-2 minutes. Turn engine off.
3. Remove and wipe off the dipstick. Insert it back with the plug pushed completely into the fill spout.

4. Remove the dipstick and note the level of the oil. Add only enough oil to bring the level to the FULL mark on the dipstick. Do not overfill.

*NOTE:*

*Refer to Recommended Synthetic Engine Oils. Use only recommended oil specified in Engine Lubrication: Synthetic Oil.*

5. Start engine and carefully check for oil leaks around drain plug and oil filter.

Engine oil level should be checked only when engine is at normal operating temperature.

*NOTE:*

*The engine will require a longer warm up period in colder weather.*

### **CAUTION**


**Do not allow hot oil level to fall below Add/Fill mark on dipstick. Doing so can result in equipment damage and/or equipment malfunction. (00189a)**

### **CAUTION**

**Do not overfill oil tank. Doing so can result in oil carryover to the air cleaner leading to equipment damage and/or equipment malfunction. (00190a)**

- Check engine oil supply at each complete fuel refill.
- Refer to Regular Service Intervals: 2005 FLHTCSE2. Oil should be changed at specified intervals in normal service at warm or moderate temperatures.
- Oil change intervals should be shorter in cold weather or severe operating conditions. See Winter Lubrication.

om00310



## Changing Oil and Oil Filter: Touring Models

### CAUTION


**Do not switch lubricant brands indiscriminately because some lubricants interact chemically when mixed. Use of inferior lubricants can damage the engine. (00184a)**

Twin Cam equipped vehicles require the premium oil filter (Part No. 63798-99 Chrome or Part No. 63731-99 Black).

Refer to Regular Service Intervals: 2005 FLHTCSE2. Oil should be changed after the first 1000 miles (1600 kilometers) for a new engine and at regular intervals in normal service at warm or moderate temperatures.

1. Ride motorcycle until engine is warmed up to normal operating temperature. Turn engine off.
2. Locate oil filler plug/dipstick on right side of vehicle at top of transmission case. To remove the oil filler plug, pull steadily while moving plug back and forth.
3. See Oil Pan: Touring Models. Locate oil drain plug at front left side of the oil pan. Remove the oil drain plug. Do not remove Allen plug. Allow oil to drain completely.

om00311



1. Transmission drain plug (right side)
2. Engine oil drain plug and o-ring

**Oil Pan: Touring Models**

4. Inspect the oil drain plug o-ring for cuts, tears or signs of deterioration. Replace as necessary.

### **⚠ WARNING**

**Be sure that no lubricant gets on tires, wheels or brakes when changing fluid. Traction can be adversely affected, which could result in loss of control of the motorcycle and death or serious injury. (00047c)**

### **CAUTION**

**Use Harley-Davidson OIL FILTER WRENCH for filter removal. This tool can prevent damage to crankshaft position sensor and/or sensor cable. (00192a)**

5. See Oil Filter Wrench (Part No. HD-42311). Remove the oil filter using the OIL FILTER WRENCH (Part No. HD-42311 or Part No. HD-44062). The tool allows easy removal of the oil filter without risk of damage to the crankshaft position sensor or cable.
6. Place the jaws of the wrench over the oil filter with the tool oriented vertically. Using a 3/8 inch drive with a 4 inch extension, turn wrench in a counterclockwise direction. Do not use with air tools.

7. Clean the oil filter mount flange of any old gasket material.

*NOTE:*

*Dispose of oil and oil filter in accordance with local regulations.*

8. See Applying Thin Oil Film. Lubricate gasket with clean engine oil and install **new** oil filter on filter mount. Hand tighten oil filter 1/2-3/4 turn after gasket first contacts filter mounting surface. Do not use OIL FILTER WRENCH HD-42311 for oil filter installation.

*NOTE:*


*Use of the Premium 10 micron synthetic media oil filter is highly recommended. Order Chrome (Part No. 63798-99) or Black (Part No. 63731-99).*

9. Install engine oil drain plug and tighten to 14-21 ft-lbs (19.0-28.5 Nm).


10. Refer to Recommended Synthetic Engine Oils. With vehicle resting on jiffy stand, initially add 3.5 quarts (3.3 liters) engine oil. Use the proper grade of oil for the lowest temperature expected before the next oil change.

11. Verify proper oil level. See Checking Oil Level: Touring Models.

- a. Check engine oil level using **COLD CHECK** procedure.
- b. Start engine and carefully check for oil leaks around drain plug and oil filter.
- c. Check engine oil level using **HOT CHECK** procedure.



om00108



1. Thin oil film ONLY
2. Oil filter
3. Mounting plate

**Applying Thin Oil Film**

## Winter Lubrication

---

In colder climates, the engine oil change interval should be shorter than normal. Motorcycles used only for short runs must have the engine oil changed more frequently and have a thorough tank flush-out before **new** oil is put in. See an authorized dealer.

*NOTE:*

*The further below freezing the temperature drops, the shorter the oil change interval should be.*

Water vapor is a normal by-product of combustion in any engine. During cold weather operation, some of the water vapor condenses to liquid form on the cool metal surfaces inside the engine. In freezing weather this water will become slush or ice and, if allowed to accumulate too long, may block the oil lines and cause damage to the engine.

If the engine is run frequently and allowed to thoroughly warm up, most of this water will become vapor again and will be blown out through the crankcase breather.

If the engine is not run frequently and allowed to thoroughly warm up, this water will accumulate, mix with the engine oil and form a sludge that is harmful to the engine.

## Transmission Lubrication: FLHTCSE2

---

## General

---

The transmission lubricant level should be checked monthly.

Your motorcycle comes equipped with Screamin' Eagle SYN3 Synthetic Motorcycle Lubricant. For transmission lubrication, it is not recommended to mix SYN3 with other lubricant products.

Refer to Regular Service Intervals: 2005 FLHTCSE2. The transmission should be drained and refilled with fresh lubricant at specified intervals.

*NOTE:*

*When checking the transmission lubricant level, motorcycle should be standing STRAIGHT UP, not leaning on the jiffy stand. Keep motorcycle upright for a short period of time to equalize lubricant level in the transmission compartments.*

## Check Lubricant Level

---

1. Ride motorcycle until engine is warmed up to normal operating temperature.
2. When the engine reaches normal operating temperature, turn the engine off and position motorcycle STRAIGHT UP and LEVEL.
3. See Transmission Filler Plug/Dipstick Lubricant Level. Remove the threaded filler plug/dipstick.
4. Wipe off filler plug/dipstick. Place in filler hole and remove. (Dipstick should rest on lip of filler.) Do not screw in. Lubricant level should be at the F(ULL) mark on the plug/dipstick when removed.

*NOTE:*

*Lubricant level should be between the two marks on the dipstick.*

### **⚠ WARNING**

**Be sure that no lubricant gets on tires, wheels or brakes when changing fluid. Traction can be adversely affected, which could result in loss of control of the motorcycle and death or serious injury. (00047c)**



### **CAUTION**

**When draining or adding lubricant, do not allow dirt, debris or other contaminants to enter the engine. (00198a)**

5. Add lubricant, if necessary. Do not overfill or leakage may occur. The transmission fluid capacity is approximately 24 ounces (0.71 liters).
  - a. When filling the transmission, use Screamin' Eagle SYN3 Synthetic Motorcycle Lubricant.
  - b. If SYN3 is not available and addition of lubricant is required, SYN3 must be completely drained before using other lubricant products. A residual amount of fluid will remain. It is not required to flush out the residual fluid.



6. Inspect o-ring for tears or damage. Replace if required. Wipe any foreign material from plug.
7. Install threaded filler/check plug and tighten clockwise to 25-75 in-lbs (2.8-8.5 Nm).



## Changing Transmission Fluid

1. See Transmission Lubricant Check/Fill: FLHTCSE2. Remove the threaded check/filler plug.

2. See Oil Pan: Touring Models. Remove transmission drain plug from the right side of the oil pan and drain lubricant into a suitable container.

### CAUTION

**When draining or adding lubricant, do not allow dirt, debris or other contaminants to enter the engine. (00198a)**

### ⚠ WARNING

**Be sure that no lubricant gets on tires, wheels or brakes when changing fluid. Traction can be adversely affected, which could result in loss of control of the motorcycle and death or serious injury. (00047c)**

*NOTE:*

*Dispose of transmission lubricant in accordance with local regulations.*

3. Inspect o-ring for tears or damage on the drain plug. Replace if required. Wipe any foreign material from plug.
4. Install drain plug and tighten to 14-21 ft-lbs (19.0-28.5 Nm). Fill the transmission with 20-24 oz. (591.5-709.8 ml) of Harley-Davidson Screamin' Eagle SYN3 Synthetic Motorcycle Lubricant.

*NOTE:*

*Do not overfill or leakage may occur. The transmission fluid capacity is approximately 24 ounces (0.71 liters).*

5. Install threaded filler/check plug and tighten clockwise to 25-75 in-lbs (2.8-8.5 Nm).
6. Start engine and carefully check for oil leaks around drain plug.

## Primary Chaincase Lubrication: Synthetic Oil

---

Lubrication is a major factor in the performance and service life of the clutch components. Use the appropriate Harley-Davidson chaincase lubricant for all operating temperatures.

Your motorcycle comes equipped with Screamin' Eagle SYN3 Synthetic Motorcycle Lubricant. If SYN3 is not available and addition of lubricant to the primary chaincase is required, the first choice would be to add H-D Primary Chaincase Lubricant. Although H-D Primary Chaincase Lubricant is compatible with SYN3, we suggest the mixture of the fluids be changed as soon as possible.

*NOTE:*

*For model specific information regarding the primary chaincase capacity, refer to the appropriate Service Manual or see a Harley-Davidson dealer.*

## Chaincase Lubricant: FLHTCSE2

---

## General

---

Refer to Regular Service Intervals: 2005 FLHTCSE2. The chaincase lubricant should be drained and refilled with fresh lubricant at specified intervals.

*NOTE:*

*When checking the chaincase lubricant, motorcycle should be standing STRAIGHT UP, not leaning on the jiffy stand. Keep motorcycle upright for a short period of time to equalize lubricant level in the chaincase compartment.*

## Check Lubricant Level

---


1. Ride motorcycle until engine is warmed up to normal operating temperature.
2. When the engine reaches normal operating temperature, turn the engine off and position motorcycle STRAIGHT UP and LEVEL.
3. See Primary Chaincase Cover: Touring Models. Remove five screws (4) (with captive washers) to free clutch inspection cover (2) from primary chaincase cover.
4. Remove gasket. Wipe all lubricant from the gasket and examine for tears or signs of deterioration. Replace as necessary.
5. See Lubricant Level with Motorcycle Upright. With the vehicle standing upright, not leaning on the jiffy stand, the lubricant level must be visible in the bottom of the chaincase and must not be higher than the diaphragm spring.
6. Pour the proper amount and type of primary chaincase lubricant in through the clutch inspection cover opening, if required.
7. Refer to procedure in Changing Chaincase Lubricant to install gasket and clutch inspection cover.

### CAUTION

**Do not overfill the primary chaincase with lubricant. Overfilling can cause rough clutch engagement, incomplete disengagement, clutch drag and/or difficulty in finding neutral at engine idle. (00199b)**

*NOTE:*


*Use only Harley-Davidson Screamin' Eagle SYN3 Synthetic Motorcycle Lubricant.*



1. Primary chain inspection cover
2. Clutch inspection cover
3. Drain plug 36-60 in-lbs (4.1-6.8 Nm)
4. Screws with captive washer
5. Clutch cover torque sequence

**Primary Chaincase Cover: Touring Models**

om00113



Lubricant Level with Motorcycle Upright

## Changing Chaincase Lubricant

### CAUTION

**When draining or adding lubricant, do not allow dirt, debris or other contaminants to enter the engine. (00198a)**

1. Ride motorcycle until engine is warmed up to normal operating temperature.
2. See Primary Chaincase Cover: Touring Models. Remove magnetic drain plug (3) at bottom of primary chaincase cover. Drain lubricant into suitable container.

*NOTE:*

*Dispose of chaincase lubricant in accordance with local regulations.*

3. Remove five screws (4) (with captive washers) to free clutch inspection cover (2) from primary chaincase cover.
4. Clean drain plug. Remove debris from magnet and inspect o-ring for cuts tears or signs of deterioration. Replace as necessary. Install drain plug and tighten to 36-60 in-lbs (4.1-6.8 Nm). If plug has accumulated excess debris, inspect the condition of chaincase components.
5. Pour approximately 32 oz. (946.35 ml) of primary chaincase lubricant in through the clutch inspection cover opening.

6. See Lubricant Level with Motorcycle Upright. With the vehicle standing upright, not leaning on the jiffy stand, the lubricant level must not be higher than the spring.

### CAUTION

**Do not overfill the primary chaincase with lubricant. Overfilling can cause rough clutch engagement, incomplete disengagement, clutch drag and/or difficulty in finding neutral at engine idle. (00199b)**

### CAUTION

**When draining or adding lubricant, do not allow dirt, debris or other contaminants to enter the engine. (00198a)**

### ⚠ WARNING

**Be sure that no lubricant gets on tires, wheels or brakes when changing fluid. Traction can be adversely affected, which could result in loss of control of the motorcycle and death or serious injury. (00047c)**

*NOTE:*

*Use only Harley-Davidson Screamin' Eagle SYN3 Synthetic Motorcycle Lubricant.*

7. To avoid punching holes in the clutch inspection cover gasket or enlarging existing holes, install clutch inspection cover and new gasket as follows:
- a. Align the triangular shaped hole in the gasket with the top hole in the clutch inspection cover. Be sure the rubber molding and the words "towards clutch" face the motorcycle.
  - b. Insert screw (with captive washer) through clutch inspection cover and carefully thread it all the way through triangular shaped hole in gasket. Do not push screw through hole.
  - c. Hang the clutch inspection cover on the primary chaincase cover flange by starting the top cover screw.
  - d. Start the remaining four screws (with captive washers).
  - e. Attach clutch inspection cover using five screws (with captive washers). Tighten to 84-108 in-lbs (9.5-12.2 Nm). Follow torque sequence shown in Primary Chaincase Cover: Touring Models.

## Primary Chain Adjustment: Touring Models

---

### General

---

Refer to Regular Service Intervals: 2005 FLHTCSE2. Primary (front) chain adjustment should be inspected specified intervals and serviced as necessary. If the chain is allowed to run

loose, it will cause the motorcycle to jerk when running at low speed, and chain and sprockets will wear excessively. If this happens, see a Harley-Davidson dealer or proceed as follows.

**Primary Chain Adjustment: Touring Models**

<b>FREE PLAY</b>	<b>IN.</b>	<b>MM</b>
COLD engine	5/8-7/8	15.9-22.2
HOT engine	3/8-5/8	9.5-15.9

## Measure Chain Tension


---

1. Remove seat.

**⚠WARNING**

**To prevent accidental vehicle start-up, which could cause death or serious injury, disconnect negative (-) battery cable before proceeding. (00048a)**

2. Unthread bolt and remove battery negative cable (black) from battery negative (-) terminal.
3. See Primary Chain Inspection Cover: Touring Models. On the left side of the vehicle, remove the T27 TORX screws to free the primary chain inspection cover from the primary chaincase cover.
4. Check the primary chain tension. Push on the upper strand to verify that it has free up and down movement midway between the engine compensating sprocket (front) and the clutch sprocket (rear).
5. Refer to Primary Chain Adjustment: Touring Models. Measure the free play to be sure that it falls within the ranges specified for a hot or cold engine.




- 1. Primary chain inspection cover
- 2. Clutch inspection cover
- 3. Drain plug

**Primary Chain Inspection Cover: Touring  
Models**



om00116



1. Center bolt nut
2. Primary chain
3. Shoe assembly

**Chain Tensioner Assembly**

## Adjust Chain Tension

If the chain is too tight or too loose, then adjustment is necessary. Proceed as follows:

1. See Chain Tensioner Assembly. Locate the chain tensioner assembly and loosen the top center nut a maximum of two turns.
2. Refer to Primary Chain Adjustment: Touring Models. Raise or lower the chain tensioner assembly as necessary to obtain the specified free play.

**NOTES:**

- *As chains stretch and wear, they run tighter at one spot than another. Always adjust the free play at the tightest spot in the chain.*
- *Replace the primary chain if it is worn to the point where it cannot be properly adjusted.*

### **CAUTION**

**Do not adjust the primary chain tighter than specified. Running chain too tight will result in excessive wear. (00202a)**

**NOTE:**

*Allowing the chain to run loose will cause the motorcycle to jerk when running at low speed resulting in excessive chain and sprocket wear.*

3. Tighten the top center nut of the chain tensioner assembly to 21-29 ft-lbs (28.5-39.3 Nm).
4. Using a **new** gasket, position the primary chain inspection cover in the primary chaincase cover. Install four screws and tighten to 84-108 in-lbs. (9.5-12.2 Nm).

## Rear Drive Belt: Touring Models

---

The inner tooth surface of the secondary belt has a thin coating of polyethylene lubricant. During initial operation, this coating will wear off as it is burnished into the belt fabric. This is a normal condition and not an indication of belt wear.

Belt tension is set at the factory and should be checked after the first 1000 miles (1600 kilometers) and at regular intervals thereafter.


See Check Belt Deflection: Touring Models. With the rear wheel on the ground and vehicle on jiffy stand, use the BELT TENSION GAUGE HD-35381-3 to apply 10 lbs. (4.5 kg) of force at the midpoint of the bottom belt strand. Belt deflection should be 1/4-5/16 in. (6.3-7.9 mm) at the loosest spot at room temperature with transmission in neutral. If belt tension adjustment is necessary, see a Harley-Davidson dealer or follow the instructions given in the applicable Service Manual.

Check rear brake caliper position on rear brake disc. Disc should run true within brake caliper.

### **⚠WARNING**

**Be sure wheel and brake caliper are aligned. Riding with a misaligned wheel or brake caliper can cause the brake disc to bind and lead to loss of control, which could result in death or serious injury. (00050a)**

om00156



1. Transmission sprocket
2. Rear wheel sprocket
3. Force of 10 lbs (4.5 kg)
4. Deflection of 1/4-5/16 in. (7.6-9.5 mm)

**Check Belt Deflection: Touring Models**

## Chassis Lubrication

Refer to Regular Service Intervals: 2005 FLHTCSE2 for all maintenance schedules.

### CAUTION

**Do not switch lubricant brands indiscriminately because some lubricants interact chemically when mixed. Use of inferior lubricants can damage the engine. (00184a)**

1. Use recommended special purpose grease for steering head bearings. Use a multipurpose chassis grease for other applications.
2. Remove and lubricate handlebar throttle control grip sleeve with fresh graphite at proper intervals.
3. Lubricate throttle control cables and clutch control cable at proper intervals.
4. Lubricate front brake hand lever and clutch control hand lever only if necessary.
5. Inspect rear fork pivot shaft bearings.
6. Pack the steering head bearings with fresh grease at proper intervals.
7. Lubricate the jiffy stand mechanism with LOCTITE AEROSOL ANTI-SEIZE at proper intervals.

NOTE:

*For model specific information regarding the chassis lubrication, refer to the appropriate Service Manual or see a Harley-Davidson dealer.*

## Oil Applications

---

Refer to Regular Service Intervals: 2005 FLHTCSE2 for all control connections and parts. Vehicle should be oiled at regular intervals, particularly after washing motorcycle or driving in wet weather.

## Front Fork Oil

---

Refer to Regular Service Intervals: 2005 FLHTCSE2. Drain front fork oil and refill at proper intervals. If fork does not appear to be working properly or an appreciable amount of oil leakage should develop, see a Harley-Davidson dealer. If there is insufficient oil in either side of fork, the rebound action will be incorrect.

## Fuel Filter

---

## EFI Models Only

---

Fuel injected motorcycles have a fuel filter attached to the fuel pump.

NOTE:

*For model specific information regarding fuel filter maintenance, refer to the appropriate Service Manual or see a Harley-Davidson dealer.*

## Hydraulic Clutch: FLHTCSE2

---

The clutch is hydraulically actuated. Squeezing the left hand lever causes the clutch master cylinder to apply pressure to the clutch actuation cylinder mounted in the trans right side cover. The actuation cylinder push rod extends and contacts the clutch release bearing to release the clutch.

Refer to Regular Service Intervals: 2005 FLHTCSE2. Check the fluid level as follows:

1. Stand the motorcycle upright (not leaning on the jiffy stand) on a level surface, turn handlebar so the top of the clutch master cylinder is level.
2. Clean all dirt and debris from the clutch master cylinder cover. Remove the two clutch master cylinder cover screws and remove the cover.
3. Verify the fluid level in the clutch master cylinder reservoir is at the FULL LEVEL mark at the top of the ledge on the rear inside wall of the reservoir. If the fluid level is low, add D.O.T. 4 HYDRAULIC BRAKE FLUID (Part No. 99953-99A) approved for clutch system use and available from a Harley-Davidson dealer.

NOTE:

*Do not overfill the clutch master cylinder reservoir. As the clutch friction discs wear, the piston in the clutch cylinder will force fluid back into the reservoir which could cause fluid*

overflow.

### CAUTION

**D.O.T. 4 hydraulic brake fluid is used in the hydraulic clutch. Do not use other types of fluids as they are not compatible and could cause equipment damage. (00353a)**

### CAUTION

**Do NOT allow dirt or debris to enter the clutch master cylinder reservoir. Dirt or debris in the reservoir can cause improper operation of the clutch and equipment damage. (00205a)**

### ⚠ CAUTION

**Direct contact of D.O.T. 4 brake fluid with eyes can cause irritation. Avoid eye contact. In case of eye contact flush with large amounts of water and get medical attention. Swallowing large amounts of D.O.T. 4 brake fluid can cause digestive discomfort. If swallowed, obtain medical attention. Use in well ventilated area. KEEP OUT OF REACH OF CHILDREN. (00240a)**

4. Inspect the clutch master cylinder cover gasket for rips, cuts, cracks, or other signs of damage. Replace the gasket if necessary. Carefully place the cover and cover gasket on the master cylinder reservoir and secure with the two cover screws. Tighten the screws to 6-8 in-lbs (0.68-0.90 Nm).

*NOTE:*

*If the fluid level in the clutch master cylinder reservoir is correct but the clutch does not operate properly, refer to the service manual or see a Harley-Davidson dealer for service.*

## Hydraulic Lifters

---

The hydraulic lifters are self-adjusting. They automatically adjust length to compensate for engine expansion and valve mechanism wear. This keeps the valve mechanism free of lash when the engine is running.

When starting an engine which has been turned off even for a few minutes, the valve mechanism may be slightly noisy until the hydraulic units completely refill with oil. If at any time the valve mechanism becomes abnormally noisy, other than for a short period immediately after engine is started, it is an indication that one or more of the hydraulic units may not be functioning properly.

Always check the oil supply in the oil tank first since normal circulation of oil through the engine is necessary for proper operation of the hydraulic units.

If there is oil in the tank, the units may not be functioning properly because of dirt in the oil supply passages leading to the lifter units. See a Harley-Davidson dealer for service.

## Front Fork Bearings

---

### **⚠WARNING**

**Adjustments to front fork bearings should be performed by a Harley-Davidson dealer. Improperly adjusted bearings can adversely affect handling and stability, which could result in death or serious injury. (00051a)**

Refer to Regular Service Intervals: 2005 FLHTCSE2. Check front fork for proper bearing adjustment and lubricate bearings at proper intervals.

With motorcycle front end raised off the floor, be sure front fork turns freely without any binding or interference and that there is no appreciable front to rear fork shake indicating excessive bearing looseness. Steering head bearings should be adjusted according to Service Manual procedure, if necessary.

## Rear Fork Pivot Shaft

---

Refer to Regular Service Intervals: 2005 FLHTCSE2. Check the tightness of the rear fork pivot shaft fastener at proper intervals.

*NOTE:*

*For model specific information regarding the rear fork pivot shaft, refer to the appropriate Service Manual or see a Harley-Davidson dealer.*

## Brakes: Touring Models

---

### **⚠WARNING**

**Inspect brake pads for wear at service maintenance intervals. If you ride under adverse conditions (steep hills, heavy traffic, etc.), inspect more frequently. Excessively worn brake pads can lead to brake failure, which could result in death or serious injury. (00052a)**

*NOTES:*

- *Master cylinder cover specifies correct brake fluid.*
  - *When adding or changing brake fluid, be sure to use only the type specified for your motorcycle.*
  - *Use only Harley-Davidson D.O.T. 4 HYDRAULIC BRAKE FLUID (Part No. 99953-99A).*
  - *Do not mix D.O.T. 4 with D.O.T. 5 brake fluid.*
1. Refer to Regular Service Intervals: 2005 FLHTCSE2. Check brake pads and brake discs for wear at proper intervals.
  2. Check the fluid level in the master cylinder reservoirs at proper intervals.
  3. If level is low, clean dirt and debris from reservoir cover before removing.

## CAUTION

D.O.T. 4 brake fluid will damage painted and molded-in color surfaces it comes in contact with. Always use caution and protect surfaces from spills whenever brake work is performed. Failure to comply can result in cosmetic damage. (00239a)

## ⚠CAUTION

Direct contact of D.O.T. 4 brake fluid with eyes can cause irritation. Avoid eye contact. In case of eye contact flush with large amounts of water and get medical attention. Swallowing large amounts of D.O.T. 4 brake fluid can cause digestive discomfort. If swallowed, obtain medical attention. Use in well ventilated area. **KEEP OUT OF REACH OF CHILDREN.** (00240a)

4. Add D.O.T. 4 HYDRAULIC BRAKE FLUID (Part No. 99953-99A) if necessary.

*NOTE:*

*Use only D.O.T. 4 HYDRAULIC BRAKE FLUID (Part No. 99953-99A) approved for brake system use and available from your Harley-Davidson dealer.*

Harley-Davidson has provided your new motorcycle with the optimum brake pad friction material available. It is selected to give the best performance possible under dry, wet and high operating temperature conditions. It exceeds all regulatory requirements currently in effect. However, during some braking conditions you may experience noise. This is normal for this friction material.

## ⚠WARNING

**Brakes are a critical safety component. Contact a Harley-Davidson dealer for brake repair or replacement. Improperly serviced brakes can adversely affect brake performance, which could result in death or serious injury. (00054a)**

See Brake Friction Material. Visual inspection of brake pads can be made without removing the caliper. View the lower area of each caliper with a flashlight.

## ⚠WARNING

**Perform routine scheduled brake maintenance. Lack of maintenance at recommended intervals can adversely affect brake performance, which could result in death or serious injury. (00055a)**

## ⚠WARNING

**Always replace brake pads in complete sets for correct**

**and safe brake operation. Improper brake operation could result in death or serious injury. (00111a)**

**NOTES:**


- *If the brake pad friction material is 0.04 in. (1.02 mm) thick or less, the pads must be replaced immediately.*
- *Always replace brake pads in pairs.*

The rear brake outer pad on all models can be measured from the caliper bracket side using a thin plastic 6.0 in. (152.4 mm) rule. Place the rule against the brake disc through the space alongside the caliper.

The outer surface of the brake pad backing plate should measure 0.04 in. (1.02 mm) or more away from the brake disc.

**NOTE:**

*Replace pads if brake friction material (1) is 0.04 in. (1.02 mm) or less above the backing plate.*



## Tires

See Specifications: 2005 FLHTCSE2 Models for tire pressures and sizes.

- Be sure to keep tires properly inflated.
- Follow tire data for correct cold tire inflation pressures.
- Check before riding when tires are cold.



- Do not over-inflate tires.

**⚠WARNING**

**Do not inflate tire beyond maximum pressure as specified on sidewall. Over inflated tires can blow out, which could result in death or serious injury. (00027a)**

**⚠WARNING**

**Match tires, tubes, air valves and caps to the correct wheel rim. Contact a Harley-Davidson dealer. Mismatching can result in damage to the tire bead, allow tire slippage on the rim or cause tire failure, which could result in death or serious injury. (00023a)**

Check inflation pressure and inspect tread for punctures, cuts, breaks, etc., at least weekly if in daily use. Check before each trip if used occasionally.

**⚠WARNING**

**Be sure tires are properly inflated, balanced and have adequate tread. Inspect your tires regularly and see a Harley-Davidson dealer for replacements. Riding with excessively worn, unbalanced or under-inflated tires can adversely affect stability and handling, which could result in death or serious injury. (00014a)**

Same as original equipment tires should be used. Other tires may not fit correctly, could adversely affect handling, and may be hazardous to use.

**⚠WARNING**

**Tires are a critical safety component. Contact a Harley-Davidson dealer for tire repair or replacement. Improper tire service can adversely affect stability and handling, which could result in death or serious injury. (00057a)**

**⚠WARNING**

**Replace punctured or damaged tires. In some cases, small punctures in the tread area may be repaired from within the demounted tire by a Harley-Davidson dealer. Speed should NOT exceed 50 mph (80 km/h) for the first 24 hours after repair, and the repaired tire should NEVER be used over 80 mph (130 km/h). Failure to follow this warning could result in death or serious injury. (00015a)**

**⚠WARNING**

**Striking an object, such as a curb, can cause internal tire damage. If an object is struck, remove and inspect both the inside and outside of the tire. A damaged tire can adversely affect stability and handling, which could result in death or serious injury. (00058a)**

## **Tire Replacement**

---

### **Inspection**

---

#### **⚠WARNING**

**Harley-Davidson tires are equipped with wear bars that run horizontally across the tread. When wear bars become visible and only 1/32 in. (0.8 mm) tread depth remains, replace tire immediately. Using a worn tire can adversely affect stability and handling, which could result in death or serious injury. Use only Dunlop Harley-Davidson replacement tires. (00090a)**

See Tire Sidewall. Arrows on tire sidewalls pinpoint location of wear bar indicators.

Tread wear indicator bars will appear on tire tread surfaces when 1/32 in. (0.8 mm) or less of tire tread remains. See Tread Surface. Always replace tires before the tread wear indicator bars appear.


### **When To Replace Tires**

---

New tires are needed if any of the following conditions exist:


1. Tread wear indicator bars become visible on the tread surfaces.
2. Tire cords or fabric become visible through cracked sidewalls, snags or deep cuts.
3. A bump, bulge or split in the tire.
4. Puncture, cut or other damage to the tire that cannot be repaired.

om00120



Tire Sidewall

om00121



Tread Surface

## Vehicle Alignment

## Isolation Mounted Engine Models

---

Refer to Regular Service Intervals: 2005 FLHTCSE2. Vehicle alignment should be checked at regular intervals. This includes whenever the rear wheel is removed and installed or when the rear drive belt is adjusted. The stabilizer links and engine mounts should be checked for wear according to Service Manual procedures at proper intervals.

Vehicle alignment is important. Vehicle stability is adversely affected if wheels are out of alignment. Major alignment of the front and rear wheel is partially controlled by one stabilizer link at the top of the engine. See a Harley-Davidson dealer for this service.

**⚠WARNING**

**Do not change stabilizer link adjustment. Changing adjustment can adversely affect stability, which could result in death or serious injury. (00059a)**

**⚠WARNING**

**Only a Harley-Davidson dealer should perform vehicle alignment. Improper alignment can adversely affect stability and handling, which could result in death or serious injury. (00060a)**

## **Shock Absorbers**

---

Refer to Regular Service Intervals: 2005 FLHTCSE2. Inspect shock absorbers and rubber bushings for leaks and bushing deterioration at proper intervals.

## **Spark Plugs**

---

Refer to Regular Service Intervals: 2005 FLHTCSE2. Check the spark plugs at proper intervals.

**⚠CAUTION**

**Do NOT pull on any electrical wires. Pulling on electrical wires may damage the internal conductor causing high resistance, which may result in minor or moderate injury. (00168a)**

Disconnect spark plug cables from plugs by pulling on the molded connector caps. To reconnect, simply snap-on spark plug cables to tops of spark plugs.

Refer to Ignition System: 2005 FLHTCSE2 before servicing spark plugs.

1. Check spark plug type. Only use those spark plugs specified for your model motorcycle.
2. Check spark plug gap against table specifications.
3. Always tighten to the proper torque. Spark plugs must be tightened to the torque specified for proper heat transfer.

NOTE:

*If a torque wrench is not available, tighten plugs finger tight and then tighten an additional one quarter turn with a spark plug wrench.*

## Ignition

---

The engine in your motorcycle has been designed specifically to achieve optimum fuel economy within exhaust emission controls. Factory programmed ignition characteristics provide maximum engine performance and driveability.

NOTE:

*The ignition control unit monitors engine load. In certain transient load conditions (as the throttle is opened), the timing changes from normal to fully advanced. At this point, the operator can sometimes hear a noise that is similar to pre-ignition detonation.*

*This noise should not be confused with detonation which can be stopped by the use of a higher grade fuel. It is caused by the instant pressure rise in the combustion chambers as the spark advances rapidly. This noise doesn't affect engine performance.*

## Air Cleaner

---

See Air Cleaner: Twin Cam Models. The engine air cleaner is a paper/wire mesh air filter element.

Refer to Regular Service Intervals: 2005 FLHTCSE2. Remove air cleaner cover and inspect filter element at proper intervals. Under dusty conditions, inspect more often.

The paper/wire mesh air filter element should be washed in luke warm water with a mild detergent.

### **⚠ WARNING**


**Compressed air can pierce the skin and flying debris from compressed air could cause serious eye injury. Wear safety glasses when working with compressed air. Never use your hand to check for air leaks or to determine air flow rates. (00061a)**

- Allow filter to either air dry or blow it dry, from the inside, with low pressure air.
- Do not use an air cleaner filter oil on the Harley-Davidson paper/wire mesh air filter element.

### **CAUTION**

**Install air filter before running engine. Failure to do so can draw debris into the engine and could result in engine damage. (00207a)**

om00122



1. Backplate
2. Filter element
3. Cover
4. Cover screw
5. Screws

**Air Cleaner: Twin Cam Models**

## Headlamp

See Headlamp Bulb. The headlamp assembly uses a replaceable quartz halogen bulb.

*NOTE:*

*Refer to Bulb Chart: 2005 FLHTCSE2 and see a service manual for more details.*

### CAUTION


**When replacement is required, use only the specified sealed beam unit or bulb, available from a Harley-Davidson dealer. An improper wattage sealed beam or bulb, can cause charging system problems. (00209a)**

### CAUTION

**Never touch the quartz bulb. Fingerprints will etch the glass and decrease bulb life. Grab the bulb with paper or a clean, dry cloth. Failure to do so could result in bulb damage. (00210a)**

### ⚠WARNING

**Handle bulb carefully and wear eye protection. Bulb contains Halogen gas under pressure, which, if not handled carefully, could cause serious eye injury. (00062a)**



## Headlamp Alignment: FLHTCSE2

---

### Check Alignment

---

#### **⚠WARNING**

**The automatic-on headlamp feature provides increased visibility of the rider to other motorists. Be sure headlamp is on at all times. Poor visibility of rider to other motorists can result in death or serious injury. (00030b)**

1. Verify correct front and rear tire inflation pressure. Refer to Tire Pressures: 2005 Touring Models.
2. Place the motorcycle on a level floor or pavement in an area with minimum light.
3. See Check Headlamp Alignment: Touring Models. Point the front of the motorcycle toward a screen or wall which is 25 feet (7.6 meters) from where patch of front tire contacts floor (i.e. - directly below front axle).
4. Draw a horizontal line on screen or wall (1) that is exactly the same height above the floor as the headlamp center.


5. Have a person whose weight is roughly the same as that of the principal rider sit on the motorcycle seat. The weight of the rider will compress the vehicle suspension slightly.
6. Stand the motorcycle upright with both tires resting on the floor and with the front wheel held in straight alignment (directly forward).
7. Turn the ignition/headlamp key switch to IGNITION. Set the Light Switch on the left handlebar to Hi(gh) beam.
8. Verify and correct headlamp adjustment if necessary.
  - a. Check the light beam for proper height alignment. The center of the main beam of light should be even with the horizontal line on the screen or wall.
  - b. Check the light beam for proper lateral alignment. The main beam of light should be directed straight ahead (i.e., equal area of light to right and left of center).

## Adjust Headlamps


NOTE:

*Headlamp adjustment can be performed without removing the headlamp door (chrome ring).*

1. Insert Phillips screwdriver between headlamp housing and rubber gasket.
2. See Adjust Headlamp Alignment: FLHTCSE2. Adjust beam.
  - a. Turn the vertical adjusting screw (1) to adjust headlamp vertically.
  - b. Turn the horizontal adjusting screw (2) to adjust headlamp horizontally.







## License Plate Lamps: FLHTCSE2

---

### Replacement

---

1. With a 7/64 in. hex wrench, remove two screws from bottom side of license plate bulb assembly.
2. Replace bulb as needed.

## Turn Signal Bulbs: Bullet Style

---

### Replacement


---

1. See Lens Cap Notch. To access the front or rear turn signal bulbs for replacement, locate a notch on the turn signal lens cap.
2. Insert a coin in the lens cap notch, and carefully twist until the lens cap pops out of the lamp housing.
3. Push in and twist the lamp bulb counterclockwise and pull lamp bulb out of the socket.
4. Orient index pins on **new** lamp bulb with pin guides inside bulb socket.
5. Push lamp bulb in and turn clockwise to lock in place.
6. Snap lens cap back into the lamp holder.

## Alignment

---

Refer to service manual for alignment procedure.



## Alternator/Voltage Regulator

---

### Charging Rate

---

The alternator output is controlled and changed to direct current by the voltage regulator.

- The voltage regulator increases charging rate when battery is low or lamps are lit.
- The voltage regulator decreases charging rate when no lamps are lighted and when battery charge is up.

### CAUTION

**It is possible to overload your motorcycle's charging system by adding too many electrical accessories. If your combined electrical accessories operating at any one time consume more electrical current than your vehicle's charging system can produce, the electrical consumption can discharge the battery and cause vehicle electrical system damage. See a Harley-Davidson dealer for advice about the amount of current consumed by additional electrical accessories, or for necessary wiring changes. (00211b)**

A battery voltage LED in the dash will light up when voltage is either too low or too high.

NOTES:

- *This unit requires no interval attention. If any electrical system trouble is experienced that might be traceable to the alternator or voltage regulator, the motorcycle should be taken to a Harley-Davidson dealer who has the necessary electrical testing equipment to give the required attention.*
- *For model specific information regarding the voltage regulator, refer to the appropriate Service Manual or see a Harley-Davidson dealer.*

## Battery: General

---

### Type

---

Your motorcycle uses a permanently sealed, maintenance-free, lead/calcium and sulfuric acid battery. All batteries are shipped precharged and ready to be put into service. Do not attempt to open the battery for any reason.

#### Antidotes for Battery Acid

CONTACT	TREATMENT
External	Flush with water.
Internal	Drink large quantities of milk or water, followed by milk of magnesia, vegetable oil or beaten eggs. Get immediate medical attention.
Eyes	Flush with water. Get immediate medical attention.

#### **⚠WARNING**

Batteries contain sulfuric acid, which could cause severe burns to eyes and skin. Wear a protective face shield, rubberized gloves and protective clothing when working with batteries. **KEEP BATTERIES AWAY FROM CHILDREN.** (00063a)

#### **⚠WARNING**

Explosive hydrogen gas, which escapes during charging, could cause death or serious injury. Charge battery in a well-ventilated area. Keep open flames, electrical sparks and smoking materials away from battery at all times. **KEEP BATTERIES AWAY FROM CHILDREN.** (00065a)

#### **⚠WARNING**

Batteries, battery posts, terminals and related accessories contain lead and lead compounds, and other chemicals known to the State of California to cause cancer and birth

defects or other reproductive harm. Wash hands after handling. (00019d)

## ⚠ WARNING

Never remove warning label attached to top of battery.  
Failure to read and understand all precautions contained in warning, could result in death or serious injury. (00064a)

100010000

**1** **2** **3** **4** **5** **6**

**NON-SPILLABLE**  
This is a ready filled, activated, SEALED BATTERY. NEVER remove strip. Refer to owner's manual for charging instructions.  
If battery is put into service 12 months after date shown, charge for minimum of 1 hour at 4-10 amps. (See side of battery for data.)


**⚠ DANGER/POISON**

EXPLOSIVE GASES CAN CAUSE BLINDNESS OR INJURY. SHIELD EYES. NO SPARKS, FLAMES, SMOKING. SULFURIC ACID CAN CAUSE BLINDNESS OR SEVERE BURNS. FLUSH EYES IMMEDIATELY WITH WATER. GET MEDICAL HELP FAST.

KEEP OUT OF REACH OF CHILDREN. DO NOT OPEN BATTERY.

1. Contents are corrosive
2. Wear safety glasses
3. Contents are explosive
4. Keep flames away
5. Read instructions
6. Keep away from children

**Battery Warning Label**



## Voltmeter Test

---

You must remove the battery from the vehicle before testing. See Battery: Touring Models.

Refer to Voltmeter Test. The voltmeter test provides a general indicator of battery condition. Check the voltage of the battery to verify that it is in a 100 percent fully charged condition. If the open circuit (disconnected) voltage reading is below 12.6V, charge the battery and then re-check the voltage after the battery has set for one to two hours.

Voltmeter Test

READING IN VOLTS	PERCENT OF CHARGE
12.8	100
12.6	75
12.3	50
12.0	25
11.8	0

## Cleaning and Inspection

---

Battery top must be clean and dry. Dirt and electrolyte on top of the battery can cause battery to self-discharge.

1. Clean battery top with a solution of baking soda (sodium bicarbonate) and water. Use 5 teaspoons baking soda per quart or liter of water.
2. When the solution stops bubbling, rinse off the battery with clean water.
3. Clean cable connectors and battery terminals using a wire brush or fine grit sandpaper to remove any oxidation.
4. Inspect and clean the battery screws, clamps and cables. Check for breakage, loose connections and corrosion.
5. Check the battery posts for melting or damage caused by overtightening.
6. Inspect the battery for discoloration, a raised top or a warped or distorted case. This might indicate that the battery has been frozen, overheated or overcharged.
7. Inspect the battery case for cracks or leaks.

## Charging

---

Never charge a battery without first reviewing the instructions for the charger being used. In addition to the manufacturer's instructions, follow these general safety precautions.

Charge the battery if any of the following conditions exist:

- Vehicle lamps appear dim.
- Electric starter sounds weak.
- Battery has not been used for an extended period of time.

**⚠WARNING**

**Explosive hydrogen gas, which escapes during charging, could cause death or serious injury. Charge battery in a well-ventilated area. Keep open flames, electrical sparks and smoking materials away from battery at all times. KEEP BATTERIES AWAY FROM CHILDREN. (00065a)**

**⚠WARNING**

**Batteries contain sulfuric acid, which could cause severe burns to eyes and skin. Wear a protective face shield, rubberized gloves and protective clothing when working with batteries. KEEP BATTERIES AWAY FROM CHILDREN. (00063a)**

1. Perform a voltmeter test to determine the state of charge. If battery needs to be charged, proceed to the next step.

**CAUTION**

**Remove battery from motorcycle before charging. Electrolyte leakage will damage motorcycle parts. (00213a)**

2. Remove the battery from the motorcycle. See Battery: Touring Models.
3. Place the battery on a level surface.

**⚠WARNING**

**Unplug or turn OFF battery charger before connecting charger cables to battery. Connecting cables with charger ON can cause a spark and battery explosion, which could result in death or serious injury. (00066a)**

**⚠WARNING**

**Connect positive (+) battery cable first. If positive (+) cable should contact ground with negative (-) cable connected, the resulting sparks can cause a battery explosion, which could result in death or serious injury. (00068a)**

**⚠WARNING**

**Disconnect negative (-) battery cable first. If positive (+) cable should contact ground with negative (-) cable**

**connected, the resulting sparks can cause a battery explosion, which could result in death or serious injury. (00049a)**

### **CAUTION**

**Do not reverse the charger connections described in the following steps or the charging system of the motorcycle could be damaged. (00214a)**

*NOTES:*

- *The figures listed in the Amp-hour table assume that the battery is charging at room temperature. If warmer than room temperature, use a slightly shorter charging time. If colder, use a slightly longer charging time.*
- *The use of constant current chargers to charge sealed maintenance free batteries is not recommended. Any overcharge will cause dry-out and premature battery failure. If a constant current charger is the only type available, do not exceed the charge times listed in 28 Amp-Hour Battery Charging Rate/Times and do not continue charging the battery if it gets hot. When charging, never exceed 15 volts.*

4. Connect the red battery charger lead to positive (+) terminal of the battery.
5. Connect the black battery charger lead to negative (-) terminal of the battery.

*NOTE:*

*If the battery is still in the vehicle, connect the negative lead to the chassis ground. Make sure that the ignition and all electrical accessories are turned off.*

6. Step away from the battery and turn on the charger.

### **⚠ WARNING**

**Unplug or turn OFF battery charger before disconnecting charger cables from battery. Disconnecting clamps with charger ON can cause a spark and battery explosion, which could result in death or serious injury. (00067a)**

7. After the battery is fully charged, turn OFF the charger and disconnect the black battery charger lead to the negative (-) terminal of the battery.
8. Disconnect the red battery charger lead to the positive (+) terminal of the battery.
9. Mark the charging date on the battery.

READING (VOLTS)	PERCENT OF CHARGE	3 AMP CHARGER	6 AMP CHARGER	10 AMP CHARGER	20 AMP CHARGER
12.8	100	-	-	-	-
12.6	75	2.5 hours	1.25 hours	45 minutes	25 minutes
12.3	50	5 hours	2.5 hours	1.5 hours	50 minutes
12.0	25	7.5 hours	3.75 hours	2.25 hours	70 minutes
11.8	0	10 hours	5 hours	3 hours	1.5 hours

## Storage

### CAUTION

Turn engine over a few times to be sure there is no oil in the crankcase and that all oil has been pumped back into the oil tank. Stop engine and re-check oil level. Failure to do so can result in engine damage. (00071a)

### CAUTION


Do not allow battery to completely discharge. The electrolyte in a discharged battery will freeze. The more discharged a battery is, the more easily it can freeze and crack the battery case. (00218a)

If the motorcycle will not be operated for several months, such as during the winter season, remove the battery from the motorcycle and fully charge.

Self-discharge is a normal condition and occurs continuously. The rate of self-discharge depends on the ambient temperature and the battery's state of charge.

- Batteries discharge at a faster rate at higher ambient temperatures.
- To reduce the self-discharge rate, store battery in a cool (not freezing), dry place.
- Charge the battery every month if stored at temperatures below 60° F. (16° C).
- Charge the battery more frequently if stored in a warm area above 60° F. (16° C).





## Battery: Touring Models

## Disconnection and Removal

Before you can inspect or disconnect your battery you must read the section containing information about seat removal.

### **⚠WARNING**

**Disconnect negative (-) battery cable first. If positive (+) cable should contact ground with negative (-) cable connected, the resulting sparks can cause a battery explosion, which could result in death or serious injury. (00049a)**

1. Unthread bolt and remove battery negative cable (black) from battery negative (-) terminal.
2. Unthread bolt and remove battery positive cable (red) from battery positive (+) terminal.
3. Loosen bolt to move lip of hold-down clamp off edge of battery.
4. Remove battery from battery box.

## Installation and Connection

---

### CAUTION

Connect the cables to the correct battery terminals. Failure to do so could result in damage to the motorcycle electrical system. (00215a)

### ⚠WARNING

Connect positive (+) battery cable first. If positive (+) cable should contact ground with negative (-) cable connected, the resulting sparks can cause a battery explosion, which could result in death or serious injury. (00068a)

### ⚠WARNING

Do not allow positive (+) battery cable to contact ground with negative (-) cable connected. Resulting sparks can cause a battery explosion, which could result in death or serious injury. (00069a)

1. Place the fully charged battery into the battery box, terminal side forward.

### CAUTION

Do not over-tighten bolts on battery terminals. Use recommended torque values. Over-tightening battery terminal bolts could result in damage to battery terminals. (00216a)

2. Insert bolt through battery positive cable (+) (red) into threaded hole of battery positive (+) terminal.
3. Tighten bolt to 60-96 in-lbs (6.8-10.8 Nm).
4. Insert bolt through battery negative cable (black) into threaded hole of battery negative (-) terminal.
5. Tighten bolt to 60-96 in-lbs (6.8-10.8 Nm).

### CAUTION

Keep battery clean and lightly coat terminals with petroleum jelly to prevent corrosion. Failure to do so could result in damage to battery terminals. (00217a)

6. Apply a light coat of petroleum jelly or corrosion retardant material to both battery terminals.
7. Rotate the hold-down clamp so that the lip (with rubber pad) rests on the edge of the

battery.

8. Tighten the clamp bolt to 15-20 ft-lbs (20.3-27.1 Nm).

### **⚠WARNING**

**After installing seat, pull upward on front of seat to be sure it is in locked position. While riding, a loose seat can shift causing loss of control, which could result in death or serious injury. (00070a)**

9. Install seat.

## **Jump Starting**

---

Harley-Davidson does not recommend jump-starting a motorcycle. However, there may be circumstances when it is necessary to do so. Therefore, we suggest jump-starting be performed as follows:

### **⚠WARNING**

**Be sure jumper cables touch only appropriate battery terminals or ground. Allowing jumper cables to touch each other can result in sparks and a battery explosion, which could result in death or serious injury. (00072a)**

### **⚠WARNING**

**Explosive hydrogen gas, which escapes during charging, could cause death or serious injury. Charge battery in a well-ventilated area. Keep open flames, electrical sparks and smoking materials away from battery at all times. KEEP BATTERIES AWAY FROM CHILDREN. (00065a)**

### **CAUTION**

**Harley-Davidson motorcycles have a 12 Volt battery. Be sure the booster vehicle has a 12 Volt system. Failure to do so could result in vehicle damage. (00220a)**

*NOTE:*

*This procedure presumes the BOOSTER battery is in another vehicle.*

1. Turn off all unnecessary lamps and accessories.

## **Positive Cable**

---

2. See Jump Start Cable Connections. Connect one end of a jumper cable to the DISCHARGED battery positive (+) terminal (1).

3. Connect the other end of the same cable to the BOOSTER battery positive (+) terminal (2).

## Negative Cable

---

### **⚠WARNING**

**Do not connect negative (-) cable to or near the discharged battery negative (-) terminal. Doing so could cause a spark and explosion, which could result in death or serious injury. (00073a)**


4. Connect one end of a jumper cable to the BOOSTER battery negative (-) terminal (3).

### **CAUTION**

**Do not connect the negative (-) cable to painted or chrome parts. Doing so could result in discoloration at the attachment point. (00221a)**

5. Connect other end of the same cable (4) to a safe ground, (away from the DISCHARGED battery).
6. Start motorcycle.
7. Disconnect cables in reverse order of steps 2, 3, 4, 5. That is: steps 5, 4, 3, 2.

om00381




1. Discharged battery positive (+) terminal
2. Booster battery positive (+) terminal
3. Booster battery negative (-) terminal
4. Ground

**Jump Start Cable Connections**

## **Seat: FLHTCSE2**

### **Removal**

1. Remove saddlebag.
2. See Passenger Seat Strap Mounting: FLHTCSE2. Remove fastener (with flat washer) to remove passenger seat strap and saddlebag front mounting bracket from chrome frame tube cover.
3. Remove Phillips screw to detach seat mounting bracket from top of rear fender.
4. See Seat Tongue. Push seat rearward to free tongue at front of seat from slot in frame backbone.



## Installation

1. See Seat Mounting Slot. Place seat on frame backbone.
2. See Seat Tongue. Firmly push front of seat downward and forward until tongue engages slot in frame backbone.
3. Push seat forward until rear fender seat retention nut is centered in hole of mounting bracket.
4. Install fastener.

*NOTE:*


*If the seat retention nut is damaged or lost, see Seat Retention Nut Replacement in the appropriate service manual for instructions.*

**⚠ WARNING**

**After installing seat, pull upward on front of seat to be sure it is in locked position. While riding, a loose seat can shift causing loss of control, which could result in death or serious injury. (00070a)**

5. Pull up on seat to verify that it is properly secured.


om00133



- 1. Tongue
- 2. Seat bottom

**Seat Tongue**

om00324



- 1. Slot
- 2. Frame backbone

**Seat Mounting Slot**


## Rider Backrest: FLHTCSE2

---


### Removal

---

1. See Rider Backrest: FLHTCSE2. Spread the seat covering at the base of the backrest exposing the two spring loaded support arms.
2. See Rider Backrest Removal: FLHTCSE2. Using two hands, squeeze together the spring loaded support arms.
3. Pull upward to remove the backrest from the bracket.







## Installation


---

1. See Rider Backrest Installation: FLHTCSE2. Spread the seat opening to expose the keyed backrest support bracket.
2. Squeeze together the two spring loaded support arms on the backrest.
3. See Rider Backrest Mounting Bracket: FLHTCSE2. Insert the support arms into the keyed support bracket.
4. Test to assure the seat is secured into the bracket.

**NOTE:**

*The backrest is spring loaded to assist the passenger in getting on and off the vehicle.*


om00428



1. Support arms
2. Spring

**Rider Backrest Installation: FLHTCSE2**

om00429



1. Seat
2. Keyed support bracket

**Rider Backrest Mounting Bracket:**  
**FLHTCSE2**

## **Passenger Backrest: FLHTCSE2**

---

### **Removal**

---


1. See Passenger Backrest: FLHTCSE2. Using your thumb, push in the spring loaded locking latch and pull the swivel latch rearward.
2. Lift the assembly off the motorcycle by lifting the backrest upward and toward the rear of the motorcycle.

### **Installation**

---

1. See Passenger Backrest: FLHTCSE2. Locate the slotted bushing for the backrest just to the rear and both sides of the seat.
2. Slide the "C" bracket guides into the slotted bushing.
3. With the latches aligned to accept the bushing, push down on the rear of the backrest bracket and lock in place.
4. Verify that the passenger backrest is locked in place before riding the motorcycle.

om00430



1. Rear latch
2. C bracket guides

Passenger Backrest: FLHTCSE2

## Detachable Tour-Pak: FLHTCSE2

---

### Operation

---


See Tour-Pak Lock and Draw Catch. Open lock and release draw catch to open the Tour-Pak.

#### **⚠ CAUTION**

**Do NOT pull on any electrical wires. Pulling on electrical wires may damage the internal conductor causing high resistance, which may result in minor or moderate injury. (00168a)**

See Tour-Pak Mounting Points. The Tour-Pak and rack assembly attaches to two rear mounting points on each side of the vehicle. The Tour-Pak may be removed from the motorcycle if the radio antenna wiring is rerouted.


om00283



1. Key
2. Lock
3. Draw catch

**Tour-Pak Lock and Draw Catch**

om00437



1. Rear Tour-Pak mount
2. Front Tour-Pak mount
3. Passenger backrest mounts

**Tour-Pak Mounting Points**

## Removal


Before removing the Tour-Pak the antenna cable and internal light power harness must be disconnected. See Radio Antenna Installation: FLHTCSE2.

1. Locate Tour-Pak power connector between seat and fender strut cover on left side of motorcycle.
2. Unplug power connector and tuck cable assembly between seat and fender strut cover.

*NOTE:*

*See Coaxial Adapter For Antenna. With the antenna mast mounted on the Tour-Pak antenna mount, the coaxial adapter allows connecting the antenna cable to the chassis antenna mount. With Tour-Pak removed, the adapter may be removed and antenna mast threaded directly onto the chassis antenna mount.*

3. See Upper Antenna Cable. Unscrew upper antenna cable from coaxial adapter.
4. See Tour-Pak Rotary Latch. To remove the Tour-Pak, press the release buttons shown (both right and left sides of rack) and pull the rotary latch lever back.
5. Carefully lift the rear of the Tour-Pak up and pull toward the rear to disengage front docking points.
6. Place Tour-Pak on a work bench.




## Installation

1. See Tour-Pak Mounting Points. While standing behind the motorcycle, place the Tour-

Pak front rack notches into the front docking points. This may require some gentle squeezing or spreading of the rack legs.

2. See Tour-Pak Rotary Latch. Pull the rotary latches back into their rearmost position. Position the rear rotary latches over the rear docking points, making certain the latches and rack legs fit into the neck of the rear docking points. This may require some gentle squeezing or spreading of the rack legs or docking point brackets.
3. Push downward and close the rotary latches by pressing the latch lever as far forward as it will go. You will hear a click when the latch is in place. If the latch does not easily close, do not force. Recheck alignment as described in Step 2.
4. Reconnect power connector and antenna cable.





## Radio Antenna Installation: FLHTCSE2

---

### General

---

When Tour-Pak is installed, the antenna is mounted on left rear of Tour-Pak. With Tour-Pak removed, the antenna may be mounted on the chassis antenna mount.


### Installing Antenna with Tour-Pak Removed

---

1. See Radio Antenna and Tour-Pak. With 2 mm hex wrench, remove lower setscrew and unscrew antenna from Tour-Pak mount.
2. See Coaxial Adapter. Unscrew coaxial adapter from antenna chassis mount.
3. Place coaxial adapter in Tour-Pak so it is available for installation when Tour-Pak is installed.
4. See Radio Antenna without Tour-Pak. Screw antenna onto chassis mount and tighten set screw.



om00433




**Radio Antenna and Tour-Pak**

om00434



**Coaxial Adapter**



## Installing Antenna with Tour-Pak Installed

---

1. See Radio Antenna without Tour-Pak. With 2 mm hex wrench remove lower setscrew and unscrew antenna from chassis mount.
2. See Coaxial Adapter. Screw coaxial adapter on antenna chassis mount.
3. See Radio Antenna and Tour-Pak. Screw antenna onto Tour-Pak mount and tighten set screw.
4. Pull enough coaxial cable from Tour-Pak to reach coaxial adapter on antenna chassis mount. Allow for a small amount of slack in the cable.
5. See Coaxial Adapter Installed. Screw coaxial cable connector into coaxial adapter on antenna chassis mount. Finger-tighten securely.



## Electrical Protection: FLHTCSE2

---

## System Fuse Removal

---

### CAUTION



**Do not skip any steps for fuse replacement. Skipping fuse replacement steps can result in damage to the sound system and/or other motorcycle systems. (00223a)**

All Touring models have fuses located under left side cover.

For electrical problems, it is best to see a Harley-Davidson dealer who has necessary parts and equipment to perform electrical services.

*NOTE:*

*See Left Side Cover Removed: Touring Models. Removal of side covers during electrical service requires no tools. Gently pull side cover to remove. Align barbed studs on side cover with grommets in frame and push to install.*



1. Place the ignition/headlamp key switch in the OFF position.

2. Remove left saddlebag and side cover.
3. To remove of maxi-fuse holder from cover, slide rearward to disengage.
4. Pull fuse blocks from tabs on mounting panel. Tabs on panel fit into slots on each side of fuse block cover.
5. To remove cover, raise latches slightly to disengage tabs on fuse blocks.
6. Remove fuse and inspect the element.

### CAUTION


**Always use replacement fuses that are of the correct type and amperage rating. Use of incorrect fuses can result in damage to electrical systems. (00222a)**

7. Replace the fuse if the element is burned or broken.

*NOTES:*

- *Automotive type ATO fuses are used for replacements. Two spare fuses can be found in the fuse block.*
- *The fuse labeled security provides basic turn signal functionality on vehicles without a factory-installed security system. Do not remove this fuse or use it as a replacement fuse for other systems.*

8. Slide cover over fuse blocks until latches fully engage tabs on blocks.
9. Slide fuse blocks into position on mounting panel.
10. Tabs on panel fit into slots on each side of fuse block cover.
11. Install maxi-fuse holder to the main fuse block.
12. Install left sidecover and saddlebag.



## EFI Fuse Removal

---

1. Remove right saddlebag and side cover.
2. Gently pull side cover from frame downtubes (no tools required).
3. See Electrical Bracket Assembly: Right Side Cover for EFI Models. Locate painted white dot on inboard side of fuse block. Pressing on dot, gently tug on conduit to release tabs on fuse block from slots in bracket.
4. See EFI Fuse Block. Pull fuses from slots in fuse block and inspect for damage. Replace fuse if the element is burned or broken. automotive type ATO fuses are used.


*NOTE:*

*One extra 15 amp fuse is located in the EFI fuse block.*

## EFI Fuse Installation

---


1. See EFI Fuse Block. Insert fuse in the appropriate slot.
2. Engage tabs on fuse block with slots in bracket. Slide fuse block up into cavity. Gently tug on conduit to verify that fuse block is locked in place.



- 1. EFI fuse block
- 2. Release

**Electrical Bracket Assembly: Right Side**  
**Cover for EFI Models**

om00328



1. Spare fuse (15 amp.)
2. Fuel pump fuse (15 amp.)
3. ECM power fuse (15 amp.)
4. EFI system relay

**EFI Fuse Block**

## Maxi-Fuse


See Maxi-Fuse. All models have a 40 amp fuse to protect the electrical components.

*NOTE:*

*Removal of the maxi-fuse will disable all systems except the starter motor/solenoid.*



om00162



Maxi-Fuse

## Maxi-Fuse Removal

---

1. Remove left saddlebag and side cover.
2. Depress latches on maxi-fuse holder and then slide cover rearward to disengage tongue from groove in fuse block cover.
3. See Maxi-Fuse Assembly. Pull maxi-fuse from holder.

## Maxi-Fuse Installation

---


1. See Maxi-Fuse Assembly. Insert maxi-fuse into holder.
2. Slide cover forward to engage tongue in groove of fuse block cover and then insert maxi-fuse holder into cover until latches engage.
3. Install left side cover and saddlebag.

## Tour-Pak Fuse

---

The Tour-Pak light is connected to the B+ connector under the seat. An in-line two amp fuse (Part No. 54305-98) is adjacent to the B+ connection.


om00322



1. Latches
2. Fuse holder
3. Cover

**Fuse Block Cover and Maxi-Fuse**

om00323



**Maxi-Fuse Assembly**

## Remote Control Garage Door Opener

# FCC Notices

---

*NOTE:*

*Changes or modifications to this unit not expressly approved by the manufacturer could void the user's authority to operate the equipment.*

This equipment has been tested and found to comply with the limits for Class B digital devices pursuant to Part 15, Subpart B of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential environment. This equipment generates, uses, and can radiate radio frequency energy, and if not installed and used in accordance with the instruction manual, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures.

1. Reorient or relocate the receiving antenna.
2. Increase the distance between the equipment and the receiver.
3. Connect the equipment to an outlet on a circuit different from that to which the receiver is connected.
4. Consult dealer or experienced radio/TV technician for help.

## Install the Receiver

---

1. Unplug the power cord from the garage door drive unit to prevent door activation during installation.
2. Find an unswitched 110V power outlet in the garage that is located either highest in the garage, or the closest to the front of the garage, or both. Locate the Harley-Davidson remote control garage door opener receiver here.

*NOTES:*

- *With some brands of garage door opener systems, it may be necessary to plug in the Harley-Davidson receiver at a location some distance from the door opener. If the Harley-Davidson receiver is plugged in too close to the original opener receiver, effective transmission range may be significantly reduced on both systems.*
  - *Opener may not function properly with steel buildings.*
3. Find the two garage door activation switch terminals on one of these locations.
    - a. The existing wall mounted, hand wired garage door opener button.
    - b. The garage door drive unit to which the garage door opener button is connected.
  4. Fasten the stripped end of the Harley-Davidson garage door opener receiver wires to the door opener terminals that activate the door opener drive unit. Refer to the door opener manufacturer's documentation for terminal locations and connections.

*NOTE:*

*Do not remove original wires from the original connections on the door opener button or on*

*the drive unit terminals.*

5. Assemble and install the garage door opener button in its original location.
6. Route the Harley-Davidson garage door opener receiver wires connected in Step 4 to the power outlet selected in Step 2.
7. See *Garage Door Opener Receiver: Back View*. Plug the connector on the Harley-Davidson garage door opener receiver wires into the back of the Harley-Davidson garage door opener receiver.
8. Plug the garage door opener receiver into the selected power outlet.
9. Plug the power cord from the garage door drive unit into the power outlet.
10. Press the wall mounted garage door opener button to set the button operation.

## **Program the Receiver and Transmitter**

---

The receiver must be programmed to receive the transmitter frequency. This process may require two people depending on how far apart the receiver and transmitter are during the programming process.

1. Check that a red light is visible on the front of the Harley-Davidson garage door opener receiver, indicating power to the receiver.
2. See *Garage Door Opener Receiver: Front View*. Press and hold the Set button the Harley-Davidson garage door opener receiver. The LED blinks continuously while the Set button is pressed.
3. Set the motorcycle ignition switch to IGN. Switch the headlamp beam switch using one of these sequences. When the receiver receives a signal from the transmitter, the LED on the transmitter turns off.
  - a. Starting from Low beam, switch High, then Low.
  - b. Starting from High beam, switch Low, then High.
4. Release the Set button on the receiver.

*NOTE:*

*Clear all obstructions away from between the transmitter and receiver before testing the operation of the garage door opener.*


5. Test the garage door opener, high beam, and low beam headlamp operation.

*NOTE:*

*When the transmitter is activated by toggling the headlamp switch, the red LED on the transmitter illuminates for one second to indicate that the transmitter is functioning correctly.*


6. Set the motorcycle ignition switch to OFF.

om00431



**Garage Door Opener Receiver: Back View**

om00432



**Garage Door Opener Receiver: Front View**

## Placing Motorcycle in Storage

---

### CAUTION

**Proper storage is important for the trouble-free operation of your motorcycle. See your Owner's Manual for storage recommendations or see a Harley-Davidson dealer. Improper storage procedures can lead to equipment damage. (00046a)**

If the motorcycle will not be operated for several months, such as during the winter season, there are several tasks which should be performed. These steps will protect parts against corrosion, preserve the battery and prevent the build-up of gum and varnish in the fuel system.

### ⚠WARNING

**Do not store motorcycle with gasoline in tank within the home or garage where open flames, pilot lights, sparks or electric motors are present. Gasoline is extremely flammable and highly explosive, which could result in death or serious injury. (00003a)**

#### NOTE:

*Make a list of everything you do and fasten it to a handgrip. When you take the motorcycle out of storage, this list will be your reference/checklist to get your motorcycle in operating condition.*

1. Fill fuel tank and add a gasoline stabilizer. Use one of the commercially available gasoline stabilizers and follow the manufacturer's instructions.
2. Warm motorcycle to operating temperature. Change oil and turn engine over to circulate the new oil.
3. Turn fuel supply valve OFF (if applicable).
4. Adjust the belt.
5. Check tire inflation. Adjust to proper inflation pressure.
6. To protect the vehicle's body panels, engine, chassis and wheels from corrosion, follow the cosmetic care procedures described in the Accessory Maintenance section of this owner's manual prior to storage.
7. Prepare battery for winter storage. See Battery: General.

### ⚠WARNING

**Explosive hydrogen gas, which escapes during charging, could cause death or serious injury. Charge battery in a well-ventilated area. Keep open flames, electrical sparks and smoking materials away from battery at all times. KEEP BATTERIES AWAY FROM CHILDREN. (00065a)**

8. If the motorcycle is to be stored with security system armed, it will be necessary to connect a Battery Tender to maintain battery charge. If security system will not be armed and a Battery Tender is not available, either:
  - a. Disconnect negative battery cable.
  - b. Remove Maxi-fuse (if applicable).
9. If motorcycle is to be covered, use a material such as light canvas that will breathe. Plastic materials that do not breathe promote the formation of condensation.

## Removing Motorcycle From Storage

---

### **⚠WARNING**

**The clutch failing to disengage can cause loss of control, which could result in death or serious injury. Prior to starting after extended periods of storage, place transmission in gear and push vehicle back and forth several times to assure proper clutch disengagement. (00075a)**

1. See Battery: General for proper battery care. Charge and install the battery.
2. Remove and inspect the spark plugs. Replace if necessary.
3. Clean the air cleaner element.
4. Start the engine and run until it reaches normal operating temperature. Turn off engine.
5. Check amount of oil in the oil tank.
6. Check the transmission lubricant level.
7. Check controls to be sure they are operating properly. Operate the front and rear brakes, throttle, clutch and shifter.
8. Check steering for smoothness by turning the handlebars through the full operating range.

### **⚠WARNING**

**Be sure tires are properly inflated, balanced and have adequate tread. Inspect your tires regularly and see a Harley-Davidson dealer for replacements. Riding with excessively worn, unbalanced or under-inflated tires can adversely affect stability and handling, which could result in death or serious injury. (00014a)**

9. Check tire pressure. Incorrect pressure will result in poor riding characteristics and can affect handling and stability.
10. Check all electrical equipment and switches including the stop lamp, turn signals and horn for proper operation.

11. Check for any fuel, oil or brake fluid leaks.

### **CAUTION**

**Turn engine over a few times to be sure there is no oil in the crankcase and that all oil has been pumped back into the oil tank. Stop engine and re-check oil level. Failure to do so can result in engine damage. (00071a)**

## **Accessories Maintenance**

### **General Maintenance**

---

Maintain chrome and aluminum regularly to check that they retain their original shine and luster. Take care to keep your new Harley-Davidson motorcycle cleaned and waxed as often as possible to inhibit rust and corrosion.

### **Cleaning Your Motorcycle**

---

To aid you in keeping your motorcycle clean, see your Harley-Davidson dealer for cleaning, polishing and waxing products.

Harley-Davidson recommends the following products:

- SUNWASH (Part No. 94659-98): for general cleaning/washing of all surfaces.
- BUG REMOVER (Part No. 94657-98): for removing bugs from all surface finishes.
- HARLEY SPRAY CLEANER (Part No. 99817-99): all purpose cleaner and quick detailer for metal surfaces.
- HARLEY GLOSS (Part No. 94627-98): all purpose surface protectant provides UV protection and a gloss finish.

### **⚠WARNING**

**Observe warnings on labels of cleaning compounds. Failure to follow warnings could result in death or serious injury. (00076a)**

### **⚠WARNING**

**Do not wash brake discs with cleaners containing chlorine or silicone. Cleaners containing chlorine and silicone can impair brake function, which could result in death or serious injury. (00077a)**

### **⚠WARNING**

**Do not let the brakes, engine, mufflers or air cleaner to get wet when washing your motorcycle. Allowing these components to get too wet can adversely affect their**



**performance, which could result in death or serious injury. Start engine immediately after washing, and make sure brakes and engine are operating properly before riding in traffic. (00078a)**

## Leather Care

---

NOTE:

*Many Harley-Davidson accessories and seats are either made of leather or have leather inserts. Natural materials age differently and require different care than man-made materials. Seat covers and panels made of leather will gain "character", such as wrinkles, with age. Leather is porous and organic and each leather product will settle into its own distinct form with use. Your leather product will mature into its own custom shape and style from the sun, rain and the miles. This maturing is natural and will enhance the custom quality of your Harley-Davidson motorcycle.*

Leather must be periodically cleaned and treated to maintain its appearance and extend its life. Clean and treat leather once a season or more frequently under adverse conditions.

### CAUTION

**Do not use bleach or detergents containing bleach on saddlebags, seats, tank panels or painted surfaces. Doing so can result in equipment damage. (00229a)**

- Do not use ordinary soap to clean leather or fur. It could dry or remove the oils from the leather.
  - Use ONLY a good quality saddle soap to clean leather. Be sure you rinse saddle soap off thoroughly before treating leather.
  - Never try to dry leather quickly, using artificial means. Always let leather dry naturally, at room temperature.
1. Vacuum or blow dust off.
  2. Thoroughly clean leather with a good quality saddle soap, following manufacturer's directions. Rinse thoroughly with clean sponge or cloth and water. Allow leather to dry.
  3. Once leather is dry, treat with a good quality leather treatment, such as LEATHERCARE (Part No. 98261-91).
  4. Always allow leather to dry completely before using.

## Whitewall Tires

---

Use a good quality, commercial whitewall cleaner and follow the manufacturer's directions.

## Wheel Care: FLHTCSE2

---

### ⚠WARNING

**Be careful not to get the brakes wet when washing vehicle. Wet brake pads and/or discs can adversely affect brake performance, which could result in death or serious injury.**

## (00079a)

Your motorcycle has chrome plated wheels. Damage from harsh chemicals, acid based wheel cleaners, brake dust and lack of maintenance can occur. Regular washing and the use of a corrosion protectant will help to maintain their original appearance. Harley-Davidson WHEEL AND TIRE CLEANER (Part No. 94658-98) is recommended for cleaning wheels and tires. Then use HARLEY GLOSS (Part No. 94627-98) to protect the wheel surfaces.

### NOTES:

- *It is imperative that the wheels are cared for weekly to guard against pitting and corrosion.*
- *Corrosion of these components is not considered to be a defect in materials or workmanship.*

Harley-Davidson recommends the following products:

- WHEEL AND TIRE CLEANER (Part No. 94658-98): cleaner/degreaser for wheels, tires and engine.
- HARLEY GLOSS (Part No. 94627-98): all purpose surface protection the provides UV protection and a gloss finish.

See a Harley-Davidson dealer for cleaning, polishing and waxing products.

## Windscreens

---

### CAUTION

**Harley-Davidson windshields are made of Lexan. Lexan is a more durable and distortion-resistant material than other types of motorcycle windshield material, but still requires attention and care to maintain. Failure to maintain Lexan properly can result in damage to the windshield. (00230a)**

### CAUTION

**Do not use harsh chemicals including rain sheeting products on Harley-Davidson windshields. They can cause dulling or hazing. If you want to use a windshield protectant on your windshield, try Harley Glaze Polish and Sealant (00231a)**

### CAUTION

**Do not use benzine, paint thinner, gasoline or any other type of harsh cleaner on the windshield. Doing so will damage the windshield surface. (00232a)**

### NOTES:

- *To remove minor surface scratches use NOVUS No. 2 SCRATCH REMOVER (Part No. 99836-94T).*
- *Covering the windscreen with a clean, wet cloth for approximately 15-20 minutes before washing will make dried bug removal easier.*

1. Use mild soap and warm water to wash the windscreen.
2. Wipe dry with a soft, clean towel.

NOTE:

To treat your Lexan windscreen with water repellent use WINDSHIELD WATER REPELLENT TREATMENT (Part No. 99841-02).

## Miscellaneous Lubrication


---

### Hinges, Latches, Etc.

---

Lubricate the rub points of latches and hinges using either Lubit-8 Tufoil (Part No. 94968-85TV) or Tri-flow as required.

See Saddlebag Latches. Lubricate the fingers on the saddlebag latches where they engage the hinge.



## Troubleshooting

### Troubleshooting: General

---

## **⚠WARNING**

**The troubleshooting section of the Owner's Manual is a guide to diagnose problems. Read the service manual before performing any work. Improper repair and/or maintenance could result in death or serious injury. (00080a)**

The following checklist of possible operating troubles and their probable causes will be helpful in keeping your motorcycle in good operating condition. More than one of these conditions may be causing trouble and should be carefully checked.

### **Engine**

---

#### **Starter Does Not Operate or Does Not Turn Engine Over**

---

1. Engine run switch in OFF position.
2. Ignition switch not ON.
3. Discharged battery or loose or corroded connections (solenoid chatters).

#### **Engine Turns Over But Does Not Start**

---

1. Fuel tank empty.
2. Fuel valve turned OFF (If applicable).
3. Fuel vacuum line disconnected (If applicable).
4. Fuel valve or filter clogged (If applicable).
5. Discharged battery or loose or broken battery terminal connections.
6. Fouled spark plugs.
7. Spark plug cable connections loose or in bad condition and shorting.
8. Loose or corroded wire or cable connection(s) at coil or battery.
9. Engine flooded with fuel as a result of over-enrichening.
10. Throttle held open when enrichener is used (If applicable).
11. Fuel pump inoperative (If applicable).

#### **Starts Hard**

---

1. Spark plugs in bad condition, have improper gap, or are partially fouled.
2. Spark plug cables in bad condition and leaking.

3. Battery nearly discharged.
4. Loose wire or cable connection(s) at one of the battery terminals or at coil.
5. Carburetor not adjusted correctly (If applicable).
6. Engine oil too heavy (winter operation).
7. Fuel tank vent plugged or fuel line closed off, restricting fuel flow.
8. Water or dirt in fuel system.
9. Fuel pump inoperative (If applicable).

## **Starts But Runs Irregularly or Misses**

---

1. Spark plugs in bad condition or partially fouled.
2. Spark plug cables in bad condition and leaking.
3. Spark plug gap too close or too wide.
4. Battery nearly discharged.
5. Damaged wire or loose connection at battery terminals or coils.
6. Intermittent short circuit due to damaged wire insulation.
7. Water or dirt in fuel system, filter or carburetor.
8. Fuel vent system plugged. See dealer.
9. One or more injectors fouled.

## **A Spark Plug Fouls Repeatedly**

---

1. Excessive enrichener use (If applicable).
2. Fuel mixture too rich (If applicable).
3. Incorrect spark plug.

## **Pre-ignition or Detonation (Knocks or Pings)**

---

1. Incorrect fuel.
2. Incorrect spark plug for the kind of service.

## **Overheats**

---

1. Insufficient oil supply or oil not circulating.

2. Heavy carbon deposit from lugging engine. See dealer.
3. Insufficient air flow over cylinder heads during extended periods of idling or parade duty.

---

## **Excessive Vibration**

1. Rear fork pivot shaft nuts loose. See dealer.
2. Front engine mounting bolts loose. See dealer.
3. Engine to transmission mounting bolts loose. See dealer.
4. Broken frame. See dealer.
5. Front chain or links tight as a result of insufficient lubrication or belt badly worn.
6. Wheels and/or tires damaged. See dealer.
7. Vehicle not properly aligned. See dealer.

---

## **Electrical System**

---

### **Alternator Does Not Charge**

1. Module not grounded. See dealer.
2. Engine ground wire loose or broken. See dealer.
3. Loose or broken wires in charging circuit. See dealer.

---

### **Alternator Charge Rate is Below Normal**

1. Weak battery.
2. Excessive use of add-on accessories.
3. Loose or corroded connections.
4. Extensive periods of idling or low speed riding.

---

## **Transmission**

---

### **Transmission Shifts Hard**

1. Bent shifter rod. See dealer.
2. Transmission shifting mechanism needs adjustment. See dealer.

---

### **Transmission Jumps Out of Gear**

---

1. Shifter rod improperly adjusted. See dealer.
2. Shifter forks (inside transmission) improperly adjusted. See dealer.
3. Worn shifter dogs in transmission. See dealer.

## **Clutch Slips**

---

1. Clutch controls improperly adjusted. See dealer.
2. Worn friction discs. See dealer.
3. Insufficient clutch spring tension. See dealer.

## **Clutch Drags or Does Not Release**

---

1. Clutch controls improperly adjusted. See dealer.
2. Insufficient clutch spring tension. See dealer.
3. Primary chaincase overfilled.
4. Clutch discs warped. See dealer.

## **Clutch Chatters**

---

1. Friction discs or steel discs worn or warped. See dealer.

## **Brakes**

---

### **Brakes Do Not Hold Normally**

---

1. Master cylinder low on fluid. See dealer.
2. Brake line contains air bubbles. See dealer.
3. Master or wheel cylinder piston worn. See dealer.
4. Brake pads contaminated with grease or oil. See dealer.
5. Brake pads badly worn. See dealer.
6. Brake disc badly worn or warped. See dealer.
7. Brake fades because of heat build up. Excessive braking or brake pads dragging. See dealer.
8. Brake drags. Insufficient hand lever free play. See dealer.

## **Warranties and Responsibilities**

## Warranty and Maintenance

---

This Owner's Manual contains your new motorcycle warranty.

It is the owner's responsibility to follow the scheduled mileage intervals as specified; all of the specified maintenance services must be performed to keep your warranty valid.

1. Make an appointment with a Harley-Davidson dealer for inspection and service just before you have ridden 1000 miles (1600 kilometers).
2. Bring this Owner's Manual with you when you visit your dealer to have your motorcycle inspected and serviced.
3. Have the dealer technician sign at the proper mileage interval. The records should be retained by the owner as proof of proper maintenance.
4. Keep receipts covering any parts, service or maintenance performed. These records should be transferred to each subsequent owner.

### **⚠ WARNING**

**Do not use aftermarket parts and custom made front forks which can adversely affect performance and handling. Removing or altering factory installed parts can adversely affect performance and could result in death or serious injury. (00001a)**

Harley-Davidson dealerships are independently owned and operated and may sell parts and accessories that are not manufactured or approved by Harley-Davidson. Therefore, you should understand that we are not and cannot be responsible for the quality, suitability, or safety of any non-Harley-Davidson part, accessory or design modification, including labor, which may be sold and/or installed by our dealers.

## Keeping It All Harley-Davidson

---

1. Keep your Harley-Davidson completely Harley-Davidson.
2. Insist that your dealer uses only Genuine replacement parts to keep your Harley-Davidson motorcycle and its warranty intact.

Exact design and stringent testing ensure performance and warranty coverage. Again, insist on Genuine parts for your genuine Harley-Davidson motorcycle.

### *NOTE:*

*Installing off-road or competition parts to enhance performance may void all or part of your new motorcycle warranty. See the Harley-Davidson Limited Warranty in this manual or a Harley-Davidson dealer for details.*

### **CAUTION**

**It is possible to overload your motorcycle's charging**



**system by adding too many electrical accessories. If your combined electrical accessories operating at any one time consume more electrical current than your vehicle's charging system can produce, the electrical consumption can discharge the battery and cause vehicle electrical system damage. See a Harley-Davidson dealer for advice about the amount of current consumed by additional electrical accessories, or for necessary wiring changes. (00211b)**

## **Important Moving Information**

---

If you move from your present address, or sell your motorcycle, please fill out and mail the post card at the back of this manual. This is necessary in the event that the Company needs to contact the owner concerning information that could affect the safe operation of this motorcycle.

## **California Evaporative Emission Controls: 2005 Models**

---

All new model year 2005 Harley-Davidson motorcycles sold in the State of California are equipped with an evaporative emission control system. This system is designed to meet the CARB regulations in effect at the time of manufacture.

The system requires a small amount of maintenance. Periodic inspection is required to make sure hoses are properly routed, not kinked or blocked and that all fittings are secure. Mounting hardware should also be checked periodically for tightness.

## **EPA Noise Regulations**

---

EPA noise regulations require that the following statements be included in the Owner's Manual.

**TAMPERING WITH NOISE CONTROL SYSTEM PROHIBITED:** Federal law prohibits the following acts or the causing thereof: (1) The removal or rendering inoperative by any person other than for purposes of maintenance, repair, or replacement of any device or element of design incorporated into any new vehicle for the purpose of noise control prior to its sale or delivery to the ultimate purchaser or while it is in use, or (2) the use of the vehicle after such device or element of design has been removed or rendered inoperative by any person.

**AMONG THOSE ACTS PRESUMED TO CONSTITUTE TAMPERING ARE THE ACTS LISTED BELOW.**

1. Replacing the muffler(s) and/or the entire exhaust system with parts not certified to be noise legal for street use.
2. Removing or modifying the muffler internal baffles in any way.
3. Replacing the air intake/cleaner assembly with one not certified to be noise legal for street use.
4. Modifying the air intake/cleaner assembly in such a way as to make the vehicle no longer noise legal for street use.

Harley-Davidson recommends that any and all noise related maintenance be done by an authorized Harley-Davidson dealer using genuine Harley-Davidson parts.

## Warranty/Service Information

---

Any authorized Harley-Davidson dealer is responsible for providing the warranty repair work on your motorcycle. If you have any questions regarding warranty obligations contact your selling dealer.

For normal service work or warranty work under the above conditions, you may obtain the name and location of your nearest U.S. Harley-Davidson dealer by calling 1-800-490-9635 (toll free), in any state except Alaska and Hawaii.

*NOTE:*

*The number shown above is accessible only with a touch-tone phone.*

## Reporting Safety Defects

---

Safety defects must be reported to the National Highway Traffic Safety Administration (NHTSA) and Harley-Davidson.

## NHTSA Statement

---

If you believe that your vehicle has a defect which could cause a crash or could cause injury or death, you should immediately inform the National Highway Traffic Safety Administration (NHTSA) in addition to notifying Harley-Davidson.

If NHTSA receives similar complaints, it may open an investigation, and if it finds that a safety defect exists in a group of vehicles, it may order a recall and remedy campaign. However, NHTSA cannot become involved in individual problems between you, your dealer, or Harley-Davidson.

To contact NHTSA, refer to NHTSA Contacts.

### NHTSA Contacts

ITEM	DATA
Phone	Call the Auto Safety Hot Line toll-free at 1-888-DASH-2DOT
Mail	National Highway Traffic Safety Administration, Attn: Administrator, 400 Seventh Street S.W., Washington, D.C. 205090
Web site	<a href="http://www.nhtsa.dot.gov">www.nhtsa.dot.gov</a>

You can also obtain other information about motor vehicle safety from the hot line.

## Owner Transfer Identification Form

---

When purchasing a pre-owned Harley-Davidson or Buell, we encourage you to submit an Owner Transfer Notification Form. It is critical that new owner information is communicated to Harley-Davidson. New owner information is required to be on file with Harley-Davidson to transfer an

Extended Service Plan Contract. Harley-Davidson is also required by the National Traffic and Motor Vehicle Safety Act to notify all owners in the event of a recall. The form may be obtained at any Harley-Davidson dealer.

## **Required Documentation for Imported Motorcycles**

---

If a Harley-Davidson is imported into the United States, additional documentation is required to be eligible for the United States Manufacturer's Limited Warranty. A Harley-Davidson dealer can provide a form explaining the requirements.

## **Limited Motorcycle Warranty**

### **2005 HARLEY-DAVIDSON MOTORCYCLE LIMITED WARRANTY**

---

## **24 Months/Unlimited Miles**

---

Harley-Davidson warrants for any new 2005 Harley-Davidson motorcycle/sidecar that an authorized Harley-Davidson dealer will repair or replace without charge any parts found under normal use to be defective in factory materials or workmanship. Such repair and replacement will be Harley-Davidson's sole obligation and the customer's sole remedy under this warranty.

THERE IS NO OTHER EXPRESS WARRANTY (OTHER THAN THE SEPARATE EMISSIONS AND NOISE WARRANTIES) ON THE MOTORCYCLE. ANY IMPLIED WARRANTY OF MERCHANTABILITY OR FITNESS FOR PARTICULAR PURPOSE IS LIMITED TO THE DURATION OF THIS WARRANTY.

Some states do not allow limitations on how long an implied warranty lasts, so the above limitation may not apply to you.

The following terms and conditions apply to this warranty:

### **Duration**

---

1. The duration of this limited warranty is twenty four months, measured from the date of initial retail purchase and delivery from an authorized Harley-Davidson dealer. Your dealer will submit an electronic Sales and Warranty Registration form to initiate your warranty.
2. Any unexpired portion of this limited warranty will be transferred to subsequent owners, upon the resale of the motorcycle/sidecar during the warranty period.

### **Owner's Obligations**

---

To obtain warranty service, return your motorcycle/sidecar at your expense within the warranty period to an authorized dealer. Our dealer should be able to provide warranty service during normal business hours and as soon as possible, depending upon the workload of the dealer's service department and the availability of necessary parts.

Harley-Davidson Motor Company, P.O. Box 653, Milwaukee, Wisconsin 53201, U.S.A.

## Exclusions

---

This warranty will not apply to any motorcycle/sidecar as follows:

1. Which has not been operated or maintained as specified in the Owner's Manual.
2. Which has been abused, misused, improperly stored, used "off the highway," or used for racing or competition of any kind.
3. Which is not manufactured to comply with the laws of the market in which it is registered.
4. Installing off-road or competition parts to enhance performance may void all or part of your new motorcycle warranty. See a Harley-Davidson dealer for details.

## Other Limitations

---

This warranty does not cover:

1. Parts and labor for normal maintenance as recommended in the Owner's Manual, or the replacement of parts due to normal wear and tear including such items as the following: tires, lubrication, oil and filter change, fuel system cleaning, battery maintenance, engine tune-up, spark plugs, brake, clutch and chain/belt adjustment (including chain replacement).
2. Cosmetic concerns that arise as a result of owner abuse, lack of proper maintenance or environmental conditions (except concerns that result from defects in material or workmanship, which are covered by this warranty for the duration of the warranty period).
3. Any cosmetic condition existing at the time of retail delivery that has not been documented by the selling dealer prior to retail delivery.
4. Defects or damage to the motorcycle caused by alterations outside of Harley-Davidson factory specifications.

## Important: Read Carefully

---

1. Our dealers are independently owned and operated and may sell other products. Because of this, HARLEY-DAVIDSON IS NOT RESPONSIBLE FOR THE SAFETY, QUALITY, OR SUITABILITY OF ANY NON-HARLEY-DAVIDSON PART, ACCESSORY OR DESIGN MODIFICATION INCLUDING LABOR WHICH MAY BE SOLD AND/OR INSTALLED BY OUR DEALERS.
2. TO THE FULLEST EXTENT ALLOWED BY LAW, HARLEY-DAVIDSON AND ITS DEALERS SHALL NOT BE LIABLE FOR LOSS OF USE, INCONVENIENCE, LOST TIME, COMMERCIAL LOSS OR OTHER INCIDENTAL OR CONSEQUENTIAL DAMAGES.
3. Some states do not allow the exclusion or limitation of incidental or consequential damages, so the above limitation or exclusion may not apply to you. This warranty gives you specific legal rights, and you may have other rights which vary from state to state.
4. This warranty is a contract between you and the manufacturer. It is separate and apart from any warranty you may receive or purchase from the dealer. The dealer is not authorized to alter, modify, or in any way change the terms and conditions of this warranty.

5. Any warranty work or parts replacement authorized by the manufacturer will not preclude the manufacturer from later relying on any exclusion where applicable.

## **Limited Noise Warranty**

### **2005 Harley-Davidson Noise Control System Limited Warranty**

---

The following warranty applies to the noise control system, is in addition to the MOTORCYCLE LIMITED WARRANTY and EMISSION CONTROL SYSTEM LIMITED WARRANTY, and applies only to motorcycles sold in the U.S.

Harley-Davidson Motor Company warrants that this vehicle is designed and built so as to conform at the time of sale with applicable regulations of the U.S. Environmental Protection Agency (as tested following F-76 Drive-By test procedure) and that it is free from defects in materials and workmanship which would cause this motorcycle not to meet U.S. Environmental Protection Agency Standards within 1 year or 3,730 miles (6,000 kilometers) whichever expires first. Any unexpired portion of this limited warranty will be transferred to subsequent owners, upon the resale of the motorcycle during the warranty period.

THERE IS NO OTHER EXPRESS WARRANTY (OTHER THAN THE SEPARATE MOTORCYCLE AND EMISSIONS WARRANTIES) ON THE MOTORCYCLE. ANY IMPLIED WARRANTY OF MERCHANTABILITY OR FITNESS FOR PARTICULAR PURPOSE IS LIMITED TO THE DURATION OF THIS WARRANTY.

Some states do not allow limitations on how long an implied warranty lasts, so the above limitation may not apply to you.

The warranty period shall begin on the date the motorcycle is delivered to the first retail purchaser or, if the motorcycle is placed in service as a demonstrator or company vehicle prior to sale at retail, on the date it is first placed in service.

THE FOLLOWING ITEMS ARE NOT COVERED BY THE NOISE CONTROL SYSTEM WARRANTY

1. Failures which arise as a result of misuse, alterations, or accident as specified in the Owner's Manual.
2. Replacing, removing, or modifying any portion of the NOISE CONTROL SYSTEM (consisting of the exhaust system and air intake/cleaner assembly) with parts not certified to be legal for street use.
3. Any motorcycle on which the odometer mileage has been changed so that the mileage cannot be determined.
4. TO THE FULLEST EXTENT ALLOWED BY LAW, HARLEY-DAVIDSON AND ITS DEALERS SHALL NOT BE LIABLE FOR LOSS OF USE, INCONVENIENCE, LOST TIME, COMMERCIAL LOSS OR OTHER INCIDENTAL OR CONSEQUENTIAL DAMAGES.

Some states do not allow the exclusion or limitation of incidental or consequential damages, so the above limitation or exclusion may not apply to you.

## **Other Rights**

---

This warranty gives you specific legal rights, and you may have other rights which vary from state to state.

## **Recommendations for Required Maintenance**

---

It is recommended that any noise system maintenance be performed by an authorized Harley-Davidson dealer using genuine Harley-Davidson replacement parts. The maintenance, replacement or repair of the noise control system may be performed by any other qualified service outlet or individual. Non-genuine parts may be used only if such parts are certified to comply with U.S. Environmental Protection Agency Standards.

Harley-Davidson Motor Company, P.O. Box 653, Milwaukee, Wisconsin 53201, U.S.A.

## **Limited Emission Warranty**

### **2005 Harley-Davidson Emission Control System Limited Warranty**

---

The following warranty applies to the emission control system, is in addition to the LIMITED MOTORCYCLE WARRANTY and NOISE CONTROL SYSTEM LIMITED WARRANTY, and applies only to motorcycles sold in the U.S.

Harley-Davidson Motor Company warrants that this vehicle is designed and built so as to conform at the time of sale with applicable regulations of the U.S. Federal Environmental Protection Agency, and that it is free from defects in materials and workmanship which would cause this motorcycle not to meet U.S. Environmental Protection Agency Standards within 5 years or 18,641 miles (30,000 kilometers) whichever expires first. Any unexpired portion of this limited warranty will be transferred to subsequent owners, upon the resale of the motorcycle during the warranty period.

THERE IS NO OTHER EXPRESS WARRANTY (OTHER THAN THE SEPARATE MOTORCYCLE AND NOISE WARRANTIES) ON THE MOTORCYCLE. ANY IMPLIED WARRANTY OF MERCHANTABILITY OR FITNESS FOR PARTICULAR PURPOSE IS LIMITED TO THE DURATION OF THIS WARRANTY.

Some states do not allow limitations on how long an implied warranty lasts, so the above limitation may not apply to you.

The warranty period shall begin on the date the motorcycle is delivered to the first retail purchaser or, if the motorcycle is placed in service as a demonstrator or company vehicle prior to sale at retail, on the date it is first placed in service.

THE FOLLOWING ITEMS ARE NOT COVERED BY THE EMISSION CONTROL SYSTEM WARRANTY

1. Failures which arise as a result of misuse, alterations, accident or non-performance of maintenance as specified in the Owner's Manual.
2. The replacement of parts (such as spark plugs, fuel and oil filters, etc.) used in required maintenance.
3. Any motorcycle on which the odometer mileage has been changed so that the mileage cannot be determined.

4. TO THE FULLEST EXTENT ALLOWED BY LAW, HARLEY-DAVIDSON AND ITS DEALERS SHALL NOT BE LIABLE FOR LOSS OF USE, INCONVENIENCE, LOST TIME, COMMERCIAL LOSS OR OTHER INCIDENTAL OR CONSEQUENTIAL DAMAGES.

Some states do not allow the exclusion or limitation of incidental or consequential damages, so the above limitation or exclusion may not apply to you.

## **Other Rights**

---

This warranty gives you specific legal rights, and you may have other rights which vary from state to state.

## **Recommendations for Required Maintenance**

---

It is recommended that any emission system maintenance be performed by an authorized Harley-Davidson dealer using genuine Harley-Davidson replacement parts. The maintenance, replacement or repair of the emissions control system may be performed by any other qualified service outlet or individual. Non-genuine parts may be used only if such parts are certified to comply with U.S. Environmental Protection Agency Standards.

Harley-Davidson Motor Company, P.O. Box 653, Milwaukee, Wisconsin 53201, U.S.A.

## **Limited Radio Warranty**

### **2005 Limited Radio Warranty**

---

Harley-Davidson Motor Company warrants that this Harley-Davidson radio will be free from factory defects in material and workmanship, under normal use and service, for a period of twenty four (24) months from date of purchase. Any unexpired portion of this limited warranty will be transferred to subsequent owners, upon the resale of the motorcycle during the warranty period. This warranty does not cover defects or damage due to abuse, misuse or improper installation.

To obtain warranty service, return your motorcycle/sidecar with sound system intact, at your expense, within the warranty period to the Selling dealer, or to any other authorized dealer if you have moved a long distance, or are touring a long distance. Our dealer should be able to provide warranty service during his normal business hours and as soon as possible, depending upon his service department's workload and the availability of necessary parts.

The remedy for breach of this warranty is expressly limited to the repair or replacement, without charge for parts and labor, of any part that proves to be defective, AND DOES NOT EXTEND TO LIABILITY FOR CONSEQUENTIAL DAMAGES, COSTS OR EXPENSES, INCLUDING LOSS OF TIME, INCONVENIENCE OR LOSS OF USE OF THE VEHICLE, RESULTING FROM ANY PART THAT PROVES TO BE DEFECTIVE.

THERE IS NO OTHER EXPRESS WARRANTY ON THE RADIO. ANY IMPLIED WARRANTY RELATING TO THIS RADIO, INCLUDING WARRANTIES OR MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE, IS EXPRESSLY LIMITED TO TWENTY FOUR (24) MONTHS.

(Some states do not allow the limitation of the length of an implied warranty or the exclusion or limitation of incidental or consequential damages, so the above limitations or exclusions may not

apply to you.)

## Other Rights

---

This warranty gives you specific legal rights, and you may have other rights which vary from state to state.

Harley-Davidson Motor Company, P.O. Box 653, Milwaukee, Wisconsin 53201, U.S.A.

## Maintenance Scheduling

### Regular Service Intervals

---

Regular lubrication and maintenance will help keep your new Harley-Davidson operating at peak performance. Your Harley-Davidson dealer knows best how to service your motorcycle with factory approved methods and equipment assuring you of thorough and competent workmanship.

*NOTES:*

- *Refer to Regular Service Intervals: 2005 FLHTCSE2. Regular maintenance interval operations are required to keep your new motorcycle warranty in force. The use of other than Harley-Davidson approved parts and service procedures may void the warranty. Any alterations to the emission system components, such as the carburetor and exhaust system, may be in violation of Federal and State laws.*
- *Refer to Owner's Maintenance Records. When servicing your motorcycle, bring this owner's manual to the dealership and complete information needed in the blank columns listed.*

### **⚠WARNING**

**Perform the service and maintenance operations as indicated in the regular service interval table. Lack of regular maintenance at the recommended intervals can affect the safe operation of your motorcycle, which could result in death or serious injury. (00010a)**

### **⚠WARNING**

**If you operate your motorcycle under adverse conditions (severe cold, extreme heat, very dusty environment, very bad roads, through standing water, etc.), you should perform the regular maintenance intervals more frequently to ensure the safe operation of your motorcycle. Failure to maintain your motorcycle could result in death or serious injury. (00094a)**



ITEM SERVICED	PROCEDURE	1000 MI.	5000 MI.	10,000 MI.	15,000 MI.	20,000 MI.	25,000 MI.	NOTES
		1600 KM	8000 KM	16,000 KM	24,000 KM	32,000 KM	40,000 KM	
Engine oil and filter	Replace	X	X	X	X	X	X	
Oil lines and brake system	Inspect for leaks	X	X	X	X	X	X	1
Air cleaner	Inspect, service as required	X	X	X	X	X	X	
Tires	Check pressure, inspect tread	X	X	X	X	X	X	
Wheel spokes	Check tightness	X	X			X		1, 4
Primary chaincase lubricant	Replace	X	X	X	X	X	X	
Transmission lubricant	Replace	X	X	X	X	X	X	
Clutch	Check adjustment	X	X	X	X	X	X	1
Primary chain	Check adjustment	X	X	X	X	X	X	
Rear belt and sprockets	Inspect, adjust belt	X	X	X	X	X	X	1
Throttle, brake and clutch controls	Check, adjust and lubricate	X	X	X	X	X	X	1, 4
Jiffy stand	Inspect and lubricate	X	X	X	X	X	X	1
Fuel lines and fittings	Inspect for leaks	X	X	X	X	X	X	1, 4
Fuel tank filter screen	Replace						X	1
Brake fluid	Check levels and condition	X	X	X	X	X	X	5
Brake pads and discs	Inspect for wear	X	X	X	X	X	X	
Spark plugs	Inspect	X	X		X		X	
	Replace			X		X		
Electrical equipment and switches	Check operation	X	X	X	X	X	X	
Engine idle speed	Check adjustment	X	X	X	X	X	X	1
Front fork oil	Replace							1, 2
Steering head bearings	Lubricate	X		X		X		2
	Adjust						X	1
Air suspension	Check pressure,	X	X	X	X	X	X	1

	operation and leakage							
Cruise control	Inspect disengage switch and components	X	X	X	X	X	X	1
Fuel door, Tour-Pak, saddlebags	Lubricate hinges and latches	X	X	X	X	X	X	
Critical fasteners	Check tightness	X		X		X		1
Engine mounts and stabilizers	Inspect			X		X		1
Battery	Check battery and clean connections							3
Road test	Verify component and system functions	X	X	X	X	X	X	
<b>NOTES:</b>	<p>1. Should be performed by an authorized Harley-Davidson dealer, unless you have the proper tools, service data and are mechanically qualified.</p> <p>2. Disassemble, lubricate and inspect every 50,000 miles (80,000 kilometers).</p> <p>3. Perform annually.</p> <p>4. Not all vehicles are equipped with an enrichener, fuel valve or spoke wheels. Consult appropriate topic in service manual.</p> <p>5. Change D.O.T. 4 and flush brake system every two years.</p>							

**Owner's Maintenance Records**

SERVICE MILE INTERVAL	DATE	DEALER NUMBER	TECHNICIAN NAME	TECHNICIAN SIGNATURE
1000 mi. (1600 km)				
5000 mi. (8000 km)				
10,000 mi. (16,000 km)				
15,000 mi. (24,000 km)				
20,000 mi. (32,000 km)				
25,000 mi. (40,000 km)				
30,000 mi. (48,000 km)				
35,000 mi. (56,000 km)				
40,000 mi. (64,000 km)				
45,000 mi. (72,000 km)				
50,000 mi. (80,000 km)				

**Service Literature**

Refer to Service Literature: 2005 FLHTCSE2. Visit a Harley-Davidson dealer or [www.harley-davidson.com](http://www.harley-davidson.com) to purchase a service or parts manual for your motorcycle. Factory authorized

manuals are the most complete and detailed source of information outside of your Harley-Davidson dealer.

**Service Literature: 2005 FLHTCSE2**

<b>DOCUMENT</b>	<b>LANGUAGE</b>	<b>PART NUMBER</b>
FLHTCSE2 Service Supplement	English	99500-05
FLHTCSE2 Service Supplement	French	99500-05F
FLHTCSE2 Service Supplement	German	99500-05G
FLHTCSE2 Service Supplement	Spanish	99500-05S
FLHTCSE2 Service Supplement	Italian	99500-05I
Touring Service Manual	English	99483-05
Touring Electrical Diagnostics Manual	English	99497-05
Touring Service and Electrical Diagnostics Manual	French	99483-05F
Touring Service and Electrical Diagnostics Manual	German	99483-05G
Touring Service and Electrical Diagnostics Manual	Spanish	99483-05S
Touring Service and Electrical Diagnostics Manual	Italian	99483-05I
FLHTCSE2 Parts Catalog	English	99428-05